


Model 380950 80A Mini AC/DC Clamp Meter



Introduction

Congratulations on your purchase of the Extech 80A Mini AC/DC Clamp Meter. The Model 380950 measures AC/DC Current, AC/DC Voltage, Resistance, Frequency, Capacitance, Duty Cycle, Diode Test, and Continuity. This clamp meter is shipped fully tested and calibrated and, with proper use, will provide years of reliable service.

Safety

International Safety Symbols



This symbol, adjacent to another symbol or terminal, indicates the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present



Double insulation

SAFETY NOTES

- Do not exceed the maximum allowable input range of any function.
- Do not apply voltage to meter when resistance function is selected.
- Set the function switch OFF when the meter is not in use.
- Remove the battery if meter is to be stored for longer than 60 days.

WARNINGS


- Set function switch to the appropriate position before measuring.
- When measuring volts do not switch to current/resistance modes.
- Do not measure current on a circuit whose voltage exceeds 240V.
- When changing ranges always disconnect the test leads from the circuit under test.

CAUTIONS

- Improper use of this meter can cause damage, shock, injury or death. Read and understand this user manual before operating the meter.
- Always remove the test leads before replacing the battery or fuses.
- Inspect the condition of the test leads and the meter itself for any damage before operating the meter. Repair or replace any damage before use.
- Use great care when making measurements if the voltages are greater than 25VAC rms or 35VDC. These voltages are considered a shock hazard.
- Always discharge capacitors and remove power from the device under test before performing Diode, Resistance or Continuity tests.
- Voltage checks on electrical outlets can be difficult and misleading because of the uncertainty of connection to the recessed electrical contacts. Other means should be used to ensure that the terminals are not "live".
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Meter Description

- Conductor jaws
- Jaw opening trigger
- Function select switch
- LCD Display
- ZERO button
- Data Hold and Backlight Button
- Mode select button
- Range select button
- Hz/%/Duty Cycle button
- COM input jack
- V/ Ω /Hz jack
- Battery cover (rear)



- AC** AC (alternating current)
- DC** DC (direct current)
- Minus sign
- AUTO** AutoRange mode
- ZERO** ZERO mode
-)))** Audible Continuity
- HOLD** Data Hold mode
- Low Battery icon** Low Battery icon
- Diode test mode** Diode test mode
- m** milli
- V** Volts
- A** Amps
- K** kilo
- M** Mega
- Ω** Ohms




Operation

Notice: Read and understand all **WARNING** and **CAUTION** statements listed in the safety section of this operation manual prior to using this meter. Set the function select switch to the OFF position when the meter is not in use.

DC/AC Current Measurements

Warning: Disconnect the test leads from the meter before making current clamp measurements.

1. Set the Function switch to the **80ADC, 4ADC, 80AAC or 4AAC** range. If the range of the measured is not known, select the higher range first then move to the lower range if necessary.
2. For DC current measurement, press the ZERO key to null the meter display.
3. Press the trigger to open jaw. Fully enclose one conductor to be measured.
4. The clamp meter LCD will display the reading.



DC/AC Voltage Measurements

1. Set the rotary function switch to the **V** position.
2. Insert the black test lead banana plug into the negative (COM) jack. Insert the red test lead banana plug into the positive (V/Ω/Hz) jack.
3. Select AC or DC with the **MODE** button.
4. Connect the test leads to the circuit under test.
5. Read the voltage on the display. The display will indicate the proper decimal point and value.



Resistance Measurements

1. Set the function switch to the **Ω** position.
2. Insert the black test lead banana plug into the negative (COM) jack. Insert the red test lead banana plug into the positive (V/Ω/Hz) jack.
3. Touch the test probe tips across the circuit or part under test. It is best to disconnect one side of the part under test so the rest of the circuit will not interfere with the resistance reading.
4. Read the resistance on the display. The display will indicate the proper decimal point and value.



Continuity Check

1. Set the function switch to the **Ω** position.
2. Push the mode button to indicate **•)))** on the display.
3. Insert the black lead banana plug into the negative (COM) jack. Insert the red test lead banana plug into the positive (V/Ω/Hz) jack.
4. Touch the test probe tips to the circuit or wire you wish to check.
5. If the resistance is less than approximately 150Ω, the audible signal will sound. If the circuit is open, the display will indicate "OL."



Diode Test

1. Turn the rotary switch to the $\Omega \rightarrow \bullet)))$ CAP position.
2. Insert the black test lead banana plug into the negative (COM) jack
Insert the red test lead banana plug into the positive (V Ω Hz) jack.
3. Push the mode button to indicate $\rightarrow$ on the display.
4. Touch the test probes to the diode under test. Typically for a normal diode, forward voltage will indicate 0.4V to 0.7V. Reverse voltage will indicate "OL". Shorted devices will indicate near 0V and an open device will indicate "OL" in both polarities.



Capacitance Measurements

Warning: To avoid electrical shock, disconnect power to the unit under test and discharge all capacitors before taking any capacitance measurements. Remove the batteries and unplug the line cords.

1. Set the function switch to the $\Omega \rightarrow \bullet)))$ CAP position.
2. Push the mode button to indicate nF on the display.
3. Insert the black lead banana plug into the negative (COM) jack
Insert the red test lead banana plug into the positive (V Ω Hz) jack.
4. Press the ZERO key to null the meter display.
5. Touch the test probe tips to the capacitor you wish to check.
6. Read the capacitance value on the display.



Frequency or % Duty Cycle Measurements


1. Turn the rotary switch to the Hz % position.
2. Insert the black test lead banana plug into the negative (COM) jack and the red test lead banana plug into the positive (V Ω Hz) jack.
3. Select Hz or % with the HZ/% button.
4. Touch the test probe tips to the circuit under test.
5. Read the frequency on the display.



Analog Signal Output

1. Turn the rotary switch to the DCA or ACA ranges.
2. Insert the black test lead banana plug into the negative (COM) jack and the red test lead banana plug into the positive (V Ω Hz) jack.
3. Connect the test leads to a multimeter, oscilloscope or chart recorder inputs.
4. Press the trigger to open the jaw. Fully enclose the conductor to be measured.
5. The analog voltage signal is output to the measuring device.

Note: When measuring DCA, the output signal is DCV. When measuring ACA, the output signal is both ACV and DCV.



Auto/Manual Ranging

The meter turns on in Autoranging mode. Press the **RANGE** button to enter manual ranging. Each press of the range button will step to the next range as indicated by the units and decimal point location. Press and hold the **RANGE** button for two seconds to return to Autoranging mode.

Note: Manual ranging does not function in AC Current or Diode and Continuity check functions. In Temperature function, it will change the resolution from 0.1° to 1°.

Data Hold

To freeze the LCD meter reading, press the **HOLD** button. While data hold is active, the **HOLD** display icon appears on the LCD. Press the HOLD button again to return to normal operation.

Backlight

Press and hold the **HOLD** button for >2 seconds to turn the backlight on/off.

Note: The HOLD feature will activate when the backlight is turned on. Press the HOLD button again to exit the Hold feature.

Zero Button

Zeros Capacitance and DC Current measurements. Also allows the user to offset the meter by using the displayed value as the zero reference value. Press the ZERO key momentarily to activate and to exit Zero mode.

Specifications

Function	Range & Resolution	Accuracy (of reading)
DC Current	4.000 ADC	± (2.8% + 10 digits)
	80.0 ADC	± (3.0% + 8 digits)
AC Current (50/60Hz)	4.000 AAC	± (3.0% + 10 digits)
	80.0 AAC	± (3.0% + 8 digits)
DC Voltage	400.0mV	± (1.0% + 15 digits)
	4.000V	± (1.0% + 3 digits)
	40.00V	± (1.5% + 3 digits)
	400.0V	
	600V	± (2.0% + 3 digits)
AC Voltage (50/60Hz)	400.0mV	± (1.0% + 30 digits)
	4.000V	± (2.0% + 5 digits)
	40.00V	
	400.0V	
	600V	
Resistance	400.0Ω	± (1.0% + 4 digits)
	4.000kΩ	± (1.5% + 2 digits)
	40.00kΩ	
	400.0kΩ	
	4.000 MΩ	± (2.5% + 3 digits)
	40.00MΩ	± (3.5% + 5 digits)
Capacitance	40.00nF	± (5% + 30 digits)
	400.0nF	± (3% + 5 digits)
	4.000μF	± (3.5% + 5 digits)
	40.00μF	± (5% + 5 digits)
	100.0μF	
Frequency	5.000Hz	± (1.5% + 5 digits)
	50.00Hz	± (1.2% + 2 digits) Sensitivity: 10Vrms min.
	500.0Hz	
	5.000KHz	
	50.00KHz	
	500.0KHz	
	5.000MHz	
	10.00MHz	
Duty Cycle	0.5% to 99.0%	± (1.2% + 2 digits)
	Pulse Width: 100μs-100ms, Frequency: 5Hz to 150KHz	
Analog Output (ACA & DCA ranges)	10mV/Amp (4 Amp range), 1mV/Amp (80 Amp range) 10mV/Amp ; Accuracy: ± (5%rdg + 2mV); Output impedance: approx 3kΩ	



Jaw size	12.7mm (0.5") approx.
Display	4000 count LCD
Continuity	Audible tone < 150Ω approx.
Diode Test	Open circuit voltage < 1.5VDC; Test current <1mA (typical)
AC V bandwidth	50Hz to 400Hz
AC A bandwidth	50/60Hz
Low battery indication	"  " is displayed
Overrange indication	"OL" is displayed
Auto Power OFF	After 25 minutes
Measurement rate	2 per second, nominal
Input Impedance	7.8MΩ (V DC and V AC)
Operating Temperature	-10°C to 50°C (14°F to 122°F)
Storage Temperature	-30°C to 60°C (-22°F to 140°F)
Operating Humidity	Max 80% up to 31°C (87°F) decreasing linearly to 50% at 45°C (113°F)
Storage Humidity	<80%
Operating Altitude	2000meters (6560ft) operating
Batteries	(2) 1.5V AAA batteries
Weight	200g (0.44lb)
Size	200x50x35mm (7.87" x 1.97" x 1.38")
Safety	For indoor use and in accordance with the requirements for double insulation to IEC1010-1 (1995): EN61010-1 (1995) Overvoltage Category III, Pollution Degree 2.

PER IEC1010 OVERVOLTAGE INSTALLATION CATEGORIES

OVERVOLTAGE CATEGORY I

Equipment of OVERVOLTAGE CATEGORY I is equipment for connection to circuits in which measures are taken to limit the transient overvoltages to an appropriate low level.

Note – Examples include protected electronic circuits.

OVERVOLTAGE CATEGORY II

Equipment of OVERVOLTAGE CATEGORY II is energy-consuming equipment to be supplied from the fixed installation.

Note – Examples include household, office, and laboratory appliances.

OVERVOLTAGE CATEGORY III

Equipment of OVERVOLTAGE CATEGORY III is equipment in fixed installations.

Note – Examples include switches in the fixed installation and some equipment for industrial use with permanent connection to the fixed installation.

OVERVOLTAGE CATEGORY IV

Equipment of OVERVOLTAGE CATEGORY IV is for use at the origin of the installation.

Note – Examples include electricity meters and primary over-current protection equipment

Maintenance

WARNING: To avoid electrical shock, disconnect the meter from any circuit, remove the test leads from the input terminals and turn OFF the meter before opening the case. Do not operate with open case.

Cleaning and Storage

Periodically wipe the case with a damp cloth and mild detergent; do not use abrasives or solvents. If the meter is not to be used for periods of longer than 60 days, remove the batteries and store them separately

Battery Replacement

1. Remove the two rear battery cover Phillips head screws
2. Open the battery compartment
3. Replace the two 1.5V AAA batteries.
4. Re-assemble the meter
- 5.



You, as the end user, are legally bound (**EU Battery ordinance**) to return all used batteries, **disposal in the household garbage is prohibited!** You can hand over your used batteries / accumulators at collection points in your community or wherever batteries / accumulators are sold!

Disposal: Follow the valid legal stipulations in respect of the disposal of the device at the end of its lifecycle

Copyright © 2012-2015 FLIR Systems, Inc.

All rights reserved including the right of reproduction in whole or in part in any form

ISO-9001 Certified

www.extech.com