

INSTALLATION

The transmitter is intended for DIN rail mounting. Its drawing is presented in Fig. 03.




Fig. 03 – Transmitter dimensions

ELECTRICAL CONNECTIONS

Fig. 04 below shows the transmitter connections to the sensor and power supply. Terminals 1, 2 e 3 are used for sensor input. For 2-wire Pt100, terminals 2 and 3 shall be connected together.




Fig. 04 – Transmitter wiring – Pt100




Fig. 05 – Transmitter wiring (Thermocouple, mA, Vdc)

The **LOAD** represents voltage metering instrument (indicator, controller, register, etc.).

Electrical Connections – 0-10 Vdc input

For 0-10 Vdc input, the transmitter requires an internal hardware configuration change. Please open the instrument case and change the jumper shown in Fig. 06.

- Position 1-2: 0-10 Vdc input
- Position 2-3: al other input types (factory setting).




Fig. 06 – Jumper position for 0-10 Vdc input

OPERATION

All input types and the 0-10 Vdc output are factory calibrated.

However, a manual offset trim is implemented to provide fine adjustments to the signal in the field. This is accomplished by the front keys ZERO+ and ZERO-. Using a small tool, press and hold the desired key for at least 2 seconds to increase or decrease the output. The offset adjustment is capable of varying the output current by an amount equal to $\pm 5\%$ relative to the original calibration.

The offset correction can also be accomplished by the TxConfig software. See in Fig. 02 the **Zero Correction** field for this purpose. The serial adaptor can be connected to the transmitter while it is operating in the process.

The input types are listed in Table 1, along with the maximum and minimum ranges accepted by each one. The TxConfig software will allow only configurations that are consistent with the data in this table.

Please note that the specified accuracy is referenced to the maximum span of each input type. For instance, for the Pt100 input, the 0.2 % accuracy results in 1.7 °C total accuracy $[(650 - (-200)) \times 0.2]$.

Note: when using a Pt100 simulator, make sure the transmitter Pt100 excitation current (0.18 mA) is compatible with the simulator specification.

MICROPROCESSOR
BASED TEMPERATURE TRANSMITTER
TxIsoRail 0-10 Vdc
INSTALLATION AND OPERATING MANUAL



SPECIFICATIONS

Sensor input: User defined. The supported sensors are listed in Table 01, along with their maximum ranges.

- Thermocouples:** Types J, K, R, S, T, N, E and B, to IEC 60584 (ITS-90). Impedance >> 1 MΩ
- Pt100:** Excitation: 180 μA, 2 or 3-wire connection (for 2-wire sensors, tie terminals 2 and 3 together). α= 0.00385, according to IEC 60751 (ITS-90).
- Voltage:** 0 to 50 mVdc, 0 to 10 Vdc; Impedance: > 1 MΩ
- Current:** 0 to 20 mAdc, 4 to 20 mAdc; Impedance: 15.0 Ω (+ 1.9 Vdc)

Sensor Type	Range	Minimum measurement span
Thermocouple K	-150 to 1370 °C / -238 to 2498 °F	100 °C
Thermocouple J	-100 to 760 °C / -148 to 1400 °F	100 °C
Thermocouple R	-50 to 1760 °C / -58 to 3200 °F	400 °C
Thermocouple S	-50 to 1760 °C / -58 to 3200 °F	400 °C
Thermocouple T	-160 to 400 °C / -256 to 752 °F	100 °C
Thermocouple N	-270 to 1300 °C / -454 to 2372 °F	100 °C
Thermocouple E	-90 to 720 °C / -130 to 1328 °F	100 °C
Thermocouple B	500 to 1820 °C / 932 to 3308 °F	400 °C
Pt100	-200 to 600 °C / -328 to 1112 °F	40 °C
Voltage	0 to 50 mV	5 mV
	0 to 10 V	1 V
Current	0 to 20 mA	2 mA
	4 to 20 mA	2 mA

Table 01 – Transmitter input sensors

- Output:** 0 to 10 Vdc, linear with respect to the measured temperature.
- Resolution:** 0.0006 V (14 bits)
- Maximum Current (Load):** 2 mA
- Total Accuracy:** 0.25 % of the maximum span for thermocouples, ± 1 °C; 0.15 % for Pt100, mA and voltage (for voltage output above 100 mV).
- Response Time:** < 500 ms
- Power Supply:** 18 to 30 Vdc
- Operating Temperature:** -40 to 85 °C
- Humidity:** 0 to 90 % UR
- Eletromagnetic Compatibility:** EN 50081-2, EN 50082-2
- Isolation** between the sensor and the 4-20 mA loop (1000 V / 1 min).
- Internal protection** against polarity inversion.
- Cold junction compensation** for thermocouples.
- Housing:** ABS plastic. Dimensions: Refer to Fig. 03.
- Certifications:** CE, UKCA.

CONFIGURATION

If the transmitter is already configured as required by the application (sensor type, range, etc), it may be installed and used right away. However, if a distinct configuration is required, this can be done through the TxConfig software and the TxConfig Interface.

The TxConfig Interface and Software can be purchased separately one of its distributors. The latest release of this software can be downloaded from our web site. Do not save the TxConfig software into a file which contains accent marks. To install,

run the Tx_setup.exe and follow the instructions. To install the configurator, run the Tx_setup.exe file.

The TxConfig interface connects the transmitter to the PC, as shown in Fig. 01.




Fig. 01 – TxConfig Interface USB connections

Once the connection is accomplished, the software shows the configuration options of the transmitter model attached. Access the Help for usage instructions.

The TxConfig screen is shown in Fig. 02.



Fig 02 – TxConfig main screen

The fields in the screen mean:

- Sensor Input:** Choose the desired temperature sensor among the available options. See Table 01.
- Measuring Range:** Defines the output scale for the input sensor. Program here the measurement **Lower Range Value** and the **Upper Range Value**.
When the Lower Range Value is configured with a value higher than the Upper Range Value the voltage output swings from 10 to 0 V.
The values configured in these fields can not be beyond the sensor measuring range. The minimum span value has to be observed as well (see Table 01).
- Line Noise Rejection:** The transmitter incorporates a digital filter to cancel the induced noise from the 50 or 60 Hz systems. For better performance, select the line frequency used in your country.
- Sensor Failure Detection:** Establishes the transmitter output behavior (upscale or down-scale) in the presence of a sensor fail..

- Zero Correction:** Allows for small sensor corrections.
 - Device Information:** The *Device Information* box contains relevant data concerning a particular transmitter. Please pass along this information when contacting the technical assistance department.
 - Apply:** Sends a new configuration to the transmitter.
 - Read Configuration:** Brings to the screen the Transmitter parameters configuration.
- Note:** The factory default configuration is (unless otherwise specified or ordered):
- Pt100 input, 0 to 100 °C
 - 60 Hz filtering and upscale (20 mA) output for sensor fail.

During the configuration, the transmitter requires to be powered. Depending on the PC used, the power can be supplied by the serial port. To assure proper communication, it is recommended to apply external power to the transmitter.

The TxConfig interface has a complex electronic circuit. Do not use any other interface or cable connection to USB; the product will be damaged and this damage is not covered under warranty.

It is important to follow the recommendations below

- Signal wires should be installed in grounded conduits and away from power or contactor wires.
- The instrument should have its own power supply wires, which should not be shared with electrical motors, coils, contactors, etc.
- Installing RC filters is strongly recommended at contactor coils or any other inductors.
- System failure should always be taken into account when designing a control panel to avoid irreversible damage to equipment or people.