User Manual

9140 Series

Triple Output Multi-Range DC Power Supplies









Safety Summary

The following safety precautions apply to both operating and maintenance personnel and must be followed during all phases of operation, service, and repair of this instrument.



Before applying power to this instrument:

- Read and understand the safety and operational information in this manual.
- Apply all the listed safety precautions.
- Verify that the voltage selector at the line power cord input is set to the correct line voltage. Operating the instrument at an incorrect line voltage will void the warranty.
- Make all connections to the instrument before applying power.
- Do not operate the instrument in ways not specified by this manual or by B&K Precision.

Failure to comply with these precautions or with warnings elsewhere in this manual violates the safety standards of design, manufacture, and intended use of the instrument. B&K Precision assumes no liability for a customer's failure to comply with these requirements.

Category rating

The IEC 61010 standard defines safety category ratings that specify the amount of electrical energy available and the voltage impulses that may occur on electrical conductors associated with these category ratings. The category rating is a Roman numeral of I, II, III, or IV. This rating is also accompanied by a maximum voltage of the circuit to be tested, which defines the voltage impulses expected and required insulation clearances. These categories are:

Category I (CAT I): Measurement instruments whose measurement inputs are not intended to be

connected to the mains supply. The voltages in the environment are typically

derived from a limited-energy transformer or a battery.

Category II (CAT II): Measurement instruments whose measurement inputs are meant to be connected

> to the mains supply at a standard wall outlet or similar sources. Example measurement environments are portable tools and household appliances.

Category III (CAT III): Measurement instruments whose measurement inputs are meant to be

connected to the mains installation of a building. Examples are measurements

inside a building's circuit breaker panel or the wiring of permanently-installed motors.



Category IV (CAT IV): Measurement instruments whose measurement inputs are meant to be connected to the primary power entering a building or other outdoor wiring.



Do not use this instrument in an electrical environment with a higher category rating than what is specified in this manual for this instrument.



You must ensure that each accessory you use with this instrument has a category rating equal to or higher than the instrument's category rating to maintain the instrument's category rating. Failure to do so will lower the category rating of the measuring system.

Electrical Power

This instrument is intended to be powered from a CATEGORY II mains power environment. The mains power should be 115 V RMS or 230 V RMS. Use only the power cord supplied with the instrument and ensure it is appropriate for your country of use.

Ground the Instrument



To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical safety ground. This instrument is grounded through the ground conductor of the supplied, three-conductor AC line power cable. The power cable must be plugged into an approved three-conductor electrical outlet. The power jack and mating plug of the power cable meet IEC safety standards.

WARNING

Do not alter or defeat the ground connection. Without the safety ground connection, all accessible conductive parts (including control knobs) may provide an electric shock. Failure to use a properlygrounded approved outlet and the recommended three-conductor AC line power cable may result in injury or death.



WARNING

Unless otherwise stated, a ground connection on the instrument's front or rear panel is for a reference of potential only and is not to be used as a safety ground. Do not operate in an explosive or flammable atmosphere.

WARNING

Do not operate the instrument in the presence of flammable gases or vapors, fumes, or finely-divided particulates.

WARNING

The instrument is designed to be used in office-type indoor environments. Do not operate the instrument

- In the presence of noxious, corrosive, or flammable fumes, gases, vapors, chemicals, or finely-divided particulates.
- In relative humidity conditions outside the instrument's specifications.
- In environments where there is a danger of any liquid being spilled on the instrument or where any liquid can condense on the instrument.
- In air temperatures exceeding the specified operating temperatures.
- In atmospheric pressures outside the specified altitude limits or where the surrounding gas is not air.
- In environments with restricted cooling air flow, even if the air temperatures are within specifications.
- In direct sunlight.

This instrument is intended to be used in an indoor pollution degree 2 environment. The operating temperature range is 0°C to 40°C and 20% to 80% relative humidity, with no condensation allowed. Measurements made by this instrument may be outside specifications if the instrument is used in nonoffice-type environments. Such environments may include rapid temperature or humidity changes, sunlight, vibration and/or mechanical shocks, acoustic noise, electrical noise, strong electric fields, or strong magnetic fields.

Do not operate instrument if damaged

WARNING

If the instrument is damaged, appears to be damaged, or if any liquid, chemical, or other material gets on or inside the instrument, remove the instrument's power cord, remove the instrument from service, label



it as not to be operated, and return the instrument to B&K Precision for repair. Notify B&K Precision of the nature of any contamination of the instrument.

Clean the instrument only as instructed



Do not clean the instrument, its switches, or its terminals with contact cleaners, abrasives, lubricants, solvents, acids/bases, or other such chemicals. Clean the instrument only with a clean dry lint-free cloth or as instructed in this manual. Not for critical applications

WARNING

This instrument is not authorized for use in contact with the human body or for use as a component in a life-support device or system.

Do not touch live circuits

WARNING

Instrument covers must not be removed by operating personnel. Component replacement and internal adjustments must be made by qualified service-trained maintenance personnel who are aware of the hazards involved when the instrument's covers and shields are removed. Under certain conditions, even with the power cord removed, dangerous voltages may exist when the covers are removed. To avoid injuries, always disconnect the power cord from the instrument, disconnect all other connections (for example, test leads, computer interface cables, etc.), discharge all circuits, and verify there are no hazardous voltages present on any conductors by measurements with a properly-operating voltagesensing device before touching any internal parts. Verify the voltage-sensing device is working properly before and after making the measurements by testing with known-operating voltage sources and test for both DC and AC voltages. Do not attempt any service or adjustment unless another person capable of rendering first aid and resuscitation is present.

Do not insert any object into an instrument's ventilation openings or other openings.

WARNING

Hazardous voltages may be present in unexpected locations in circuitry being tested when a fault condition in the circuit exists.

WARNING

Fuse replacement must be done by qualified service-trained maintenance personnel who are aware of the instrument's fuse requirements and safe replacement procedures. Disconnect the instrument from



the power line before replacing fuses. Replace fuses only with new fuses of the fuse types, voltage ratings, and current ratings specified in this manual or on the back of the instrument. Failure to do so may damage the instrument, lead to a safety hazard, or cause a fire. Failure to use the specified fuses will void the warranty.

Servicing




Do not substitute parts that are not approved by B&K Precision or modify this instrument. Return the instrument to B&K Precision for service and repair to ensure that safety and performance features are maintained.

For continued safe use of the instrument

- Do not place heavy objects on the instrument.
- Do not obstruct cooling air flow to the instrument.
- Do not place a hot soldering iron on the instrument.
- Do not pull the instrument with the power cord, connected probe, or connected test lead.
- Do not move the instrument when a probe is connected to a circuit being tested.

Compliance Statements

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other **European countries with separate collection systems)**



This product is subject to Directive 2002/96/EC of the European Parliament and the Council of the European Union on waste electrical and electronic equipment (WEEE), and in jurisdictions adopting that Directive, is marked as being put on the market after August 13, 2005, and should not be disposed of as unsorted municipal waste. Please utilize your local WEEE collection facilities in the disposition of this product and otherwise observe all applicable requirements.



Safety Symbols

Symbol	Description
▲ DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
A WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
A CAUTION	Indicates a hazardous situation which, if not avoided, will result in minor or moderate injury.
\triangle	Refer to the text near the symbol.
A	Electric Shock hazard
~	Alternating current (AC)
h	Chassis ground
<u></u>	Earth ground
Д	Indicates the In position of the power switch when instrument is ON.
П	Indicates the Out position of the power switch when instrument is OFF.
NOTICE	Indicates practices not related to physical injury.

 Table 1
 Safety Symbols

Contents

1 I	ntroduction	11
1.1	Product Overview	11
1.2	Contents	12
1.3	Features	12
1.4	Dimensions	13
1.5	Rackmount Installation	14
1.6	Front Panel	15
1.7	Display	16
1.8	Rear Panel	17
2 (Getting Started	18
2.1	Input Power and Fuse Requirements	18
2.2	Fuse Requirements	19
2.3	Check or Replace Fuse	19
2.4	Preliminary Check	21
2.5	Self test Errors	22
3 E	Basic Front Panel Operation	23
3.1	Keys	23
3.1.1	Main Keys	23
3.1.2	Soft Keys	24
3.1.3	Numeric Keys	24
3.1.4	Output Control	24
3.2	Display	25
3.3	Check Model and Firmware Version	28
3.4	Setting Voltage and Current	29
4 (Output Configuration	30
4.1	Protection Settings	30
4.1.1	Over Voltage Protection (OVP)	30
4.1.2	Over Current Protection (OCP)	30
4.1.3	Over Temperature Protection & Over Temperature Warning (OTP & OTW)	30
4.1.4	Vmax/Vmin	31
4.1.5	Protection Clear	31
4.2	Output Settings	31
4.2.1	Remote Sense	31
4.2.2	Output Timer	32
4.2.3	Voltage Slew	33
4.2.4	Current Slew	33

EK PRECISION	9
4.2.5 On/Off Delay	33
4.3 Operating Mode and Coupling	34
4.3.1 Normal Mode	34
4.3.2 Series Mode	36
5 List Mode	47
5.1 List Setup	47
5.2 Edit List	49
5.2.1 Load/Save List5.2.1 List Number	50 51
5.2.2 Next	52
5.2.3 Repeat	52
5.2.4 Steps	52
5.3 List Run	55
5.5 EIST TUT	55
6 Data Logger	58
6.1 Using the Data Logger Function	58
6.2 Parameters	59
6.2.1 Sampling Interval	59
6.2.2 File Path	59
6.2.3 T. Stamp Filename	59
6.2.4 Log Data	60
6.2.5 Status Code	61
6.2.6 Trigger Source	61
6.2.7 Datalog Start/Stop	62
7 Utilities Menu	63
7.1 User Settings	63
7.1.1 Key Lock Output	63
7.1.2 Beep Sound	63
7.1.3 Date	64
7.1.4 Time	64
7.1.5 Screen Intensity	64
7.1.6 Language	64
7.2 Remote Interface	65
7.2.1 USB Settings	66
7.2.2 LAN	67
7.3 GPIB (optional)	73
7.4 Digital I/O	74
7.4.1 Functions	75 70
7.4.1 Polarity	76 70
7.4.1 Inhibit Mode	76
7.5 Test/Admin	77 77
7.5.1 Self Test	77

BK PRI	ECISION	10
7.5.2 Sec	eurity	77
7.6 Error L	_og	79
7.7 Help		81
7.8 On Sc	reen Help	82
8 Key Lock	κ	83
9 Save/Re	ecall	84
9.1 Save t	the Output Settings	84
9.2 Recall	the Instrument's Settings	85
9.3 Power	r-On Settings	86
9.4 Screen	nshot	87
10 Calibration	on Adjustment Procedure	89
10.1 Voltag	e Calibration Adjustment	90
10.2 Currer	nt Calibration Adjustment	91
10.3 OVP C	Calibration Adjustment	92
10.4 OCP (Calibration Adjustment	93
10.5 RTC C	Calibration Adjustment	94
11 Performa	ance Verification	95
12 Specifica	ations	98
13 Service	Information	99
14 LIMITED	THREE-YEAR WARRANTY	100

Introduction

1.1 Product Overview





9140: 32 V / 8 A / 300 W

9141: 60 V / 4 A / 300 W

Figure 1.1 Front View

The 9140 Series triple output multi-range DC power supplies combine industry-leading power density and performance with an extensive set of features in a compact 2U form factor.

Three isolated output channels each produce 100 W of clean power with exceptionally low ripple and noise characteristics. Combine channels to output up to 300 W, distributing the power across all three channels. Multiple outputs paired with advanced list mode programming, data logging, and protection features make these power supplies suitable for a wide range of benchtop or test system applications.

Model	9140	9141		
Voltage per Channel	0 to 32 V	0 to 60 V		
Current per Channel	0 to 8 A	0 to 4 A		
Maximum Power per Channel	100) W		
Maximum Combined Power	300) W		

Table 1.1 Models



1.2 Contents

Please inspect the instrument mechanically and electrically upon receiving it. Unpack all items from the shipping carton, and check for any obvious signs of physical damage that may have occurred during transportation. Report any damage to the shipping agent immediately. Save the original packing carton for possible future reshipment. Every power supply is shipped with the following contents:

- 1 x 9140 or 9141 Power Supply
- 1 x AC Power Cord
- 1 x Certificate of Calibration
- 1 x Test Report

Note:

Ensure the presence of all the items above. Contact the distributor or B&K Precision if anything is missing.

1.3 Features

- Three independent galvanically isolated, floating output channels providing up to 100 W per channel or 300 W total when combining all three channels
- High power density, compact 2U half-rack form factor
- Multi-ranging operation delivers rated power at various voltage/current combinations
- Combine outputs in parallel or series to increase current or voltage (up to 24 A or 180 V depending on the model)
- Advanced list mode programming with internal storage for up to 10 list mode programs and list sequencing capabilities
- Digital I/O block offers external triggering, voltage fault and remote inhibit capabilities
- Overvoltage (OVP), overcurrent (OCP), overtemperature (OTP), and includes a key-lock function
- NISPOM-compliant sanitization procedure to securely erase and return the instrument to factory settings



- USB (USBTMC-compliant) and LXI compliant LAN interfaces standard, GPIB optional
- LabVIEW TM , IVI-C, and IVI.NET drivers provided

1.4 Dimensions

The 9140 power supply's dimensions are approximately: 213 mm (8.4 in) x 88.2 mm (3.47 in) x 330 mm (13 in) (W x H x D).



Figure 1.2 Dimensions



1.5 Rackmount Installation

The 9140 Series is compatible with the optional 19-inch rackmount kit model RK2US. The RK2US installation instructions can be downloaded from bkprecision.com



Figure 1.3 Dimensions



1.6 Front Panel



Figure 1.4 Front Panel

Item	Name	Description			
1	Power Button	Power the instrument ON or OFF			
2	Function Keys	See section ?? for details.			
3	USB Host Port	USB port used to connect flash drives.			
4	Display	Visual presentation of the device function and measurements.			
5	Numeric Keypad	Used to enter precise values.			
6	Rotary Knob	Used to navigate menues or configure parameters.			
7	Output	Isolated and floating output channel supporting sheathed banana plugs and spade lug type connectors			
8	Soft Keys	Used to invoke any functions displayed above them.			

Table 1.2 Front Panel



1.7 Display

lcon	Description
@	The output is disabled.
<	The output is enabled and in constant voltage mode
©	The output is enabled and in constant current mode
	Data loggin is enabled but not recording.
	Data logging is enabled and recording.
品	The instrument is connected to a network.
=	An issue occured when attempting to connect to a network.
<u> </u>	The instrument is not connected to a network.
1	All keys excluding softkey F6 are locked.
OV	Over voltage protection was triggered.
OC	Over current protection was triggered.
ОТ	Over temperature protection was triggered.
RMT	The instrument is set to remote mode
Sense	Remote sense is enabled.
Sense	Remote

Table 1.3 Display Icons



1.8 Rear Panel




Figure 1.5 Rear Panel

Item	Name	Description
1	Output/Sense	Rear panel output with remote sense. Internal relays switch between local and remote sensing.
2	Kensington security slot	Lock the instrument to a fixed location using the security lock via the lock hole. Lock is not included.
3	GPIB Interface (Optional)	Connect a GPIB cable to remotely control the unit `
4	Digital I/O	Send or receive a signal to or from an external device.
5	USB interface	Connect a USB type B to type A to remotely control the unit.
6	LAN interface	Connect a Cat 5/6 Ethernet straight-through patch cable to remotely control the unit.
7	Chassis ground	Provides a zero potential voltage reference and a dissipation point for interference, transient voltages and static.
8	AC power input & fuse box	Houses the fuse as well as the AC input.

Table 1.4 Rear Panel

Getting Started

Before connecting and powering up the instrument, please review and go through the instructions in this chapter.

2.1 Input Power and Fuse Requirements

The supply has a universal AC input that accepts line voltage input within:

	9140	9141
AC Line Input	100 - 240 VAC \pm 1	0%, 47 to 63 Hz
AC Line Phase	Single F	Phase
Maximum Rated Input Power	500	VA

Before connecting to an AC outlet or external power source, be sure that the power switch is in the OFF position and verify that the AC power cord, including the extension line, is compatible with the rated voltage/current and that there is sufficient circuit capacity for the power supply. Once verified, connect the cable firmly.



The included AC power cord is safety certified for this instrument operating in rated range. To change a cable or add an extension cable, be sure that it can meet the required power ratings for this instrument. Any misuse with wrong or unsafe cables will void the warranty.



SHOCK HAZARD

The power cord provides a chassis ground through a third conductor. Verify that your power outlet is of the three-conductor type with the correct pin connected to earth ground.



2.2 Fuse Requirements

An AC input fuse is necessary when powering the instrument. The below table shows the fuse required for all models.

Model	Fuse Specification
9140	3.15 AT, 250 V
9141	3.15 AT, 250 V

2.3 Check or Replace Fuse



For safety, no power should be applied to the instrument while changing line voltage operation. Disconnect all cables connected to the instrument before proceeding.

- Locate the fuse box next to the AC input connector in the rear panel. (See figure 1.5)
- Insert a small flathead screwdriver into the fuse box slit to pull and slide out the fuse box as indicated below.
- Check and replace fuse if necessary. (See figure 2.1)




Figure 2.1 Fuse Removal





Any disassembling of the case or changing the fuse not performed by an authorized service technician will void the warranty of the instrument



SHOCK HAZARD:

Hazardous voltages may exist at the outputs and the load connections when using a power supply with a rated output greater than 60 V. To protect personnel against accidental contact with hazardous voltages, ensure that the load and its connections have no accessible live parts. Ensure that the load wiring insulation rating is greater than to the maximum output voltage of the power supply.

The rear output terminals can accept wire sizes AWG 24 to AWG 12 (See Table 2.1). However, we recommend using 12 AWG if current output is between 5 to 10 A. Refer to Table 2 below to determine the proper wire size.

Wire Gauge Rating										
AWG	10	12	14	16	18	20	22	24	26	28
lmax (A)	40	25	20	13	10	7	5	3.5	2.5	1.7
$m\Omega/meter$	3.3	5.2	8.3	13.2	21	33.5	52.8	84.3	133.9	212.9

Table 2.1 Wire Gauge Rating

Output Isolation

The output terminals of the 9240 Series are isolated from earth ground. An earth ground terminal is provided on the front panel for convenience. Any output terminal may be grounded. However, output terminals must not exceed ±200 VDC.



SHOCK HAZARD:

Floating voltage must not exceed 200 VDC.





2.4 Preliminary Check

Complete the following steps to verify the Power supply is ready for use.

Verify AC Input Voltage

Verify and check to make sure proper AC voltages are available to power the instrument. The AC voltage range must meet the acceptable specification as explained in section "2.1 Input Power and Fuse Requirements".

Connect Power & Self-Test

Connect AC power cord to the AC receptacle in the rear panel and press the power button. It will run through a self-test procedure initially before booting to the main screen.

After Power on, during the self-test, the following should be displayed:




Figure 2.2 Initializing

After the system scan is complete the LCD will display as shown in Figure 2.3

Note:

The initial power on state is based on the settings set on Power-ON





Figure 2.3 Home Display

2.5 Self test Errors

The following errors will be displayed if the self-test did not complete successfully:

Error Message	Description
EEPROM Fail	The internal EEPROM is corrupted or damaged.
System Lost	Last system settings within the EEPROM are lost.
Module Fail	Channel response failure.
Cal Lost	Calibration data within the EEPROM is lost.
Fact Loss	Factory calibration data is lost.
Model Lost	Channel initialization failed.

Table 2.2 Error Message

If any of these errors occur, please contact B&K Precision.

Basic Front Panel Operation

At power-on, the power supply will automatically enter the front-panel operation mode and the instrument can be controlled via the front panel keys and knob.

3.1 Keys

3.1.1 Main Keys

There are three main keys:



Navigates the 5 available screens. When navigating any menu returns the key will return "Home" main display

5 available displays:

- Main page: Overview of the 3 outputs.
- Single Channel Display 1 to
 - 3: Detailed channel overview.
- Live Output Monitoring: Oscilloscope like overview of the measured output parameters.

SAVE RECALL

Opens up a menu giving access to various save and load options, regardless of the current display of the screen.



Opens the main menu bar. If a menu bar is already open, pressing Utility will navigate to the main menu bar.

More information on each display in 3.2.



3.1.2 Soft Keys

The unit has six soft keys, which are located beneath the screen. Each key selects the corresponding function. Functions will vary depending on the current menu or display.



Soft Keys Figure 3.1

3.1.3 Numeric Keys

The numeric keys allow the configuration of various parameters. Using the numeric keys provides a fast and precise input. The Enter key can be found with the numeric keys. Pressing enter will assign the selected value to the desired parameter.



Figure 3.2 Numeric Keys

3.1.4 Output Control

The button toggles the output On/Off. When output is enabled, the ON button will turn green and the supply will display the state of the channel.



represents constant current mode. represents constant voltage mode. This is indicated for each channel independently. When output is disabled, the channel state will display

The On/Off key toggles all the channels On/Off simultaneously. Its function may vary depending on the coupling state of the channels. For more information go to Coupling.



3.2 Display

These power supplies have three main display modes: three channel display, single channel display, and live output monitoring display. Press the Display button to cycle between the different display modes or to return home when viewing any other menu.

Vset

Three Channel Display

Provides information of the outputs': Allows configuration of:

State

Run time **Iset**

Voltage

Current

Power




Figure 3.3 Three Channel Display



Single Channel Display

Provides information of the outputs':

- State
- Run time
- Voltage
- Current
- Power
- Vmax/Vmin
- OVP/OCP
- OnDelay/OffDelay

Allows configuration of:

- Vset
- **Iset**
- Vmax/Vmin
- OVP/OCP
- OnDelay/OffDelay



Figure 3.4 Single Channel Display



Live Output Monitoring

The live output monitoring display shows metered output voltage and current over time. It is always active and will continuously plot and overwrite the oldest value when the display graph is full.




Figure 3.5 Live Output Monitoring Display

The Live output display can be configured by setting the: Voltage, Current, and Time Scale.

Voltage Scale

The voltage scale of each output can be set from 10 mV/Div up to 20 V/Div.

- 1. While in Live Output Display use the softkeys to select Voltage Scale.
- 2. Select a channel to configure.
- 3. Use the rotary knob to navigate through the available scales.

Current Scale

The current scale of each output can be set from 10 mA/Div up to 3 A/Div.

- 1. While in Live Output Display use the softkeys to select Current Scale.
- 2. Select a channel to configure.
- 3. Use the rotary knob to navigate through the available scales.



Time Scale

The time scale of each output can be set from 1 s/Div up to 10 min/Div.

- 1. While in Live Output Display use the softkeys to select Time Scale.
- 2. Use the rotary knob to navigate through the available scales.

Voltage Offset

A voltage offset can be added to each output. The offset can be set from 0 V up to 60.6 V on the 9141 and 0 V up to 32.2 V on the 9140.

- While in Live Output Display use the softkeys to select Voltage Offset.
- 2. Select a channel to configure.
- 3. Use the rotary knob to navigate through the available scales.

Current Offset

A current offset can be added to each output. The offset can be set from 0 A up to 4.4 A on the 9141 and 0 A up to 8.8 A on the 9140.

- 1. While in Live Output Display use the softkeys to select Current Offset.
- Select a channel to configure.
- 3. Use the rotary knob to navigate through the available scales.

3.3 Check Model and Firmware Version

The firmware version, model, and serial number can be verified by entering the security settings. Press button then use the soft keys to select Utilities > Help > System Info to view model and firmware information.





3.4 Setting Voltage and Current

Follow the steps below to set the output voltage or current. The values can be entered using the numeric keypad or the rotary knob.

- 1. **Using the keypad**: Use the soft keys to select the channel VSET or ISET settings beneath channel view on the display. Then use the numeric keypad to input the voltage or current value then press Enter to confirm.
- 2. Using the rotary knob: Use the soft keys to select the channel VSET or ISET settings beneath the channel view on display. Then turn the knob clockwise to increment or counter-clockwise to decrement the value.
 - a. Use the below the rotary knob to move the cursor. Press the knob in to confirm.

Output Configuration

4.1 Protection Settings

4.1.1 Over Voltage Protection (OVP)

Over voltage protection is always enabled, however the user can set the OVP voltage limits.

- 1. Press the Utility button then use the soft keys to select Output config > Protection settings
- 2. Use the soft keys to select a channel to adjust.
- 3. Select OVP Limit.
- 4. Use the numeric keypad or rotary knob to set the desired OVP limit.

When OVP protection is tripped during operation, the output will be de-rated to 0 V and the icon will appear between the wattage and Vset.



4.1.2 Over Current Protection (OCP)

Over current protection state and limit can be set in the protection settings.

- 1. Press the Utility button then use the soft keys to select Output config > Protection settings
- 2. Use the soft keys to select a channel to adjust.
- Press OCP State to toggle the over current protection on or off.
- 4. Select **OCP Limit** and use the numeric keypad or rotary knob to set limit value.

When OCP protection is tripped during operation, the output will be de-rated to 0 V and the icon will appear between the wattage and Vset.



4.1.3 Over Temperature Protection & Over Temperature Warning (OTP & OTW)

The state and limit of both OTP & OTW cannot be set or configured in the protection settings. OTP is set to 85 °C and OTW is set to 75 °C. If the temperature reaches either OTW, the OT icon will blink on the display with a low period beep sound. If temperature reaches OTP the OT icon will show on the display and the output will turn off. The output will not be allowed to turn on until the temperature drops to 75 °C.

Fan Speed Control		
2 A	0%	
2 to 5 A	25%	
5 A	100%	



4.1.4 Vmax/Vmin

Configure the maximum or minimum voltage value the user can set from the protection settings.

- 1. Press the Utility button then use the soft keys to select Output config > **Protection settings**
- 2. Use the soft keys to select a channel to adjust.
- 3. Select Vmax or Vmin and set a maximum or minimum value using the numeric keypad or rotary knob.

4.1.5 Protection Clear

Protections are cleared from the output configuration settings as shown in the following steps.

- 1. Press the Utility button then use the soft key to select **Output config** > **Protection Clear.**
- 2. Press the soft key to clear the protection for the corresponding channel, or select All CH Clear to clear protections on all three channels.

4.2 Output Settings

4.2.1 Remote Sense

Remote sense can be used to compensate for voltage drops (up to 1 V) due to resistance from test leads connected to your device under test (DUT), thus providing more accurate output voltage. When remote sense is enabled, the positive (+S) and positive lead (+) of the DC output are connected to the positive (+) of the load. Similarly, the negative sense (-S) and negative lead (-) of the DC output are connected to the negative (-) end of the load shown in figure 4.1




Figure 4.1 Remote Sense





Never connect any power source into any of the terminals at any time during operation.

When output is enabled, DO NOT use your hands to touch the terminals or the screws that are designed to tighten wires to the terminals. Doing so may create a shock hazard under high voltage output conditions.



DO NOT at any time disconnect the wires from the S+ and S- terminals to the DUT while output is enabled (ON). Doing so may damage the power supply and cause unstable output.

Remote sense is disabled by default, see the following steps to enable remote sense:

- 1. Press the Utility button then use the soft key to select **Output config > Output Settings**.
- 2. Select a desired channel to configure.
- Press Remote Sense using the soft key to enable remote sense.

4.2.2 Output Timer



Output timer can be set for each channel individually. When the output timer is enabled, an hourglass icon will be displayed next to the channel number. The timer countdown will begin when the channel output is enabled. The output is disabled when the countdown reaches 0. The timer can be set from 1 second to 99 hours 59 minutes and 59 seconds.

Follow the steps below to enable and set the output timer:

- 1. Press the Utility button then use the soft key to select Output config > Output Settings.
- 2. Select a desired channel to configure. Push Timer State to enable the timer.
- 3. Select Timer Setting and set a desired time for the output to be enabled using the numeric keypad or rotary knob. The timer format is: HH:MM:SS. Use the keys to move the cursor.



4.2.3 Voltage Slew

The rising voltage slew rate can be set in volts per second. The voltage slew range can be set from 0.001 V/s to 3200.0 V/s.

- 1. Press the Utility button then use the soft key to select Output config > Output Settings.
- 2. Select a desired channel to configure.
- 3. Select Voltage Slew and use the numeric keypad or rotary knob to adjust the slew rate value. Press to confirm input.

4.2.4 Current Slew

The rising current slew rate can be set in amps per second. The current slew range can be set from 1 A/s to 800 A/s.

- 1. Press the Utility button then use the soft key to select Output config > Output Settings.
- Select a desired channel to configure.
- 3. Select Next Pg. > Current Slew and use the numeric keypad or rotary knob to adjust the slew rate value. Press Enter to confirm input.

4.2.5 On/Off Delay

A channel on or off delay in seconds can be applied to any channel. These delays can be set from 0.001 s to 3600.0 s.

- 1. Press the Utility button then use the soft key to select Output config > Output Settings.
- 2. Select a desired channel to configure.
- 3. Select Next Pg. > On Delay to set an on delay or Off Delay to set an off delay.
- 4. Use the numeric keypad or rotary knob to adjust the delay value. Press Enter to confirm input.



4.3 Operating Mode and Coupling

Set the operation mode or coupling.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > Operation Mode.



4.3.1 Normal Mode

Sets operation mode to Normal.

Normal mode sets the instrument to operate as a true triple output power supply.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > **Operation Mode > Normal.**

9140	9141		
Individual CH	Individual CH		
32 V 8 A	60 V 4 A		



Figure 4.2 Normal Mode



In **Normal mode** the main page will display the three outputs.



Toggles through CH1, CH2, CH3, and live output monitoring display.



Figure 4.3 Normal Mode Main Page

Single CH displays more information about the output, and allows configuration of more parameters.




Figure 4.4 Single Channel



4.3.2 Series Mode

Set operation mode to **Series**.


Series mode changes the UI to accurately represent the possible outputs configurations.

Series mode does not internally wire the outputs. The outputs must be connected externally to increase the available voltage range.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > Operation Mode > Series.



The image below illustrates the external wiring required to connect all channels in series. If CH1+ CH2 is chosen CH2's positive terminal does not connect to CH3's negative terminal.



9140		9141	
CH1 + CH2	All CHs	CH1 + CH2	All CHs
64 V	96 V	120 V	180 V



CH1 + CH2

Operation mode will be set to Series 1 + 2. Changing operation mode will undo previous coupling configuration.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > Operation Mode > Series > CH1 + CH2.




Figure 4.5 Series 1+2

In Series CH1 + 2 the main page will display the output of the combined outputs, as well as the output of the individual CH3. The Display button will toggle through single channel display for Series CH1 + 2, CH 3, and live output monitoring.



Figure 4.6 Series CH1+2 Main Page



Single CH displays more information about the output, and allows configuration of more parameters. The voltage configurations will now range from 0 v to 64 V for model 9140 and 0 V to 120 V for model 9141.




Figure 4.7 Series CH1+2 Single Channel Display

Protection Setting menu will also adjust the configurable values.




Figure 4.8 Series CH1+2 Protection Settings



Series All

Operation mode will be set to **Series All**. Coupling will not be available in **Series All** mode.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > Operation Mode > Series > Series All.



Figure 4.9 Series All

In Series All mode Display will only toggle between the Series All display and live output monitoring. Series All CH display will adjust to voltage configuration between 0 V and 96 V for model 9140 and 0 V to 180 V for model 9141.




Figure 4.10 Series All Main Page

Protection Setting menu will also adjust the configurable values.





Parallel Mode

Set operation mode to **Parallel**.


Parallel Mode does not internally wire the outputs. The outputs must be connected externally to increase the available current range.

Parallel Mode changes the UI to accurately represent the possible output configurations.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > Operation Mode > Parallel.



The image below illustrates the external wiring required to connect all channels in Parallel. If CH1+ CH2 is chosen CH2's terminals do not connect to CH3's terminals.



Parallel CH1+2 **Parallel All**

9140		9141		
CH1 + CH2	All CHs	CH1 + CH2	All CHs	
16 A	24 A	8 A	12 A	

Table 4.1 Parallel Mode



CH1 + CH2

Operation mode will be set to Parallel 1 + 2. Selecting an operation mode will undo previous coupling configuration.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > Operation Mode > Parallel > CH1 + CH2.




Figure 4.11 Parallel CH 1+2

In Parallel CH1 + 2 Mode the main page will display the output of the combined outputs, as well as the output of the individual CH3. The Display button will toggle through single channel display for Parallel CH1 + 2, CH 3, and live output monitoring.




Figure 4.12 Parallel CH 1+2 Main Display 9141



The Single CH display will adjust to allow current configuration between .030 A to 16 A for model 9140 and .030 A to 8 A for model 9141.




Figure 4.13 Parallel CH 1+2 Single Channel Display

Protection Setting menu will also adjust the configurable range of each parameter.




Figure 4.14 Parallel CH 1+2 Protection Settings



Parallel All

Operation mode will be updated based on selected mode. Coupling is not available.




Figure 4.15 Parallel All Operation Mode

In Parallel All Mode the Display button will only toggle between the Parallel All display and live output monitoring.

Parallel All CH display will adjust to allow value configuration of .045 to 24 A for model 9140 and .045 A to 12 A for model 9141.




Figure 4.16 Parallel All Main Page

Protection Setting menu will also adjust the configurable values.






Figure 4.17 Parallel All Main Page

Tracking

Voltage levels are tracked on either CH1+2 or All Channels.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling > **Operation Mode > Tracking.**



Tracking mode allows real time voltage tracking across all channels or between CH1 and CH2.

When tracking mode is enabled, list mode will still operate independently on the channel that has list enabled. Tracking channels will not track the list changes.




Figure 4.18 Tracking Mode





Coupling

Enable or disable the output coupling between multiple output channels, by using the soft keys to toggle individual channel coupling On or Off.

Press the Utility button then use the soft key to select Output Config > Op. Mode/Coupling

If coupling is enabled, on/off will follow the coupling settings. Channel output On/Off buttons will also follow the coupling settings if the correlated channel is coupled to another channel.

Example:

If CH1 and CH2 are coupled and the coupled CHs are on, On/Off will not turn on CH3. It will turn off CH1 and CH2.

However, if all channels are OFF on/off will turn all CHs ON.

If all CHs are ON On/Off will turn all CHs OFF.




Figure 4.19 Parallel All Main Page

Output Sequencing




Figure 4.20 Sequencing

Combine CH Coupling with Output On and Off Delay to toggle the outputs in a set sequence.

To configure a sequence:

- 1. Set voltage and current output of the participating channels. Reference section Setting Voltage and Current.
- 2. Synchronize output state by coupling of all participating channels. Reference section Coupling
- 3. Configure the turn on order of the outputs using the **On** and **Off Delay**. Reference section Output Timer

Begin the sequence by turning on any of the participating outputs.

List Mode

The 9140 and 9141 are capable of storing up to 10 programmable lists in the internal memory. Each list can have up to 100 configurable steps.

List memory is shareable across all 3 channels, allowing the channels to run the same list or different list simultaneously.

If all ten list numbers are taken, a list can also be saved to a USB. Lists can be loaded from a USB, allowing for a larger collection of programmed lists.

5.1 List Setup

Press the Utility button then use the soft key to select List Setup.

Use the softkeys to select one of the channels CH1, CH2, or CH3.




Figure 5.1 List Setup

Use the softkeys to set the following parameters.





List State:

Toggle list state On/Off for the selected channel.

List Number:

Select a list program from the memory to run on the channel. Use the numeric keypad or rotary knob to select list number.

Press Enter to assign the list to a channel.

Pace:

Set the pace in which steps are executed.

- a. **Dwell**: The next step outputs once the dwell time elapsed.
- b. **Trigger**: After the dwell time elapsed, wait for a trigger before outputting the next step.

Trigger Source

Set the trigger source.

a. Manual: Select to use a manual trigger. The Trigger softkey will be available once List State is on and exit out of the menu to the main display. Press it to manually trigger the list program. If the step dwell time has not elapsed, then Trigger will not have a white background. When dwell time elapses, Trigger background color will turn white to indicate the trigger is ready.



Figure 5.2 Waiting for Trigger





- b. Digital IO: Select to use the digital I/O pins to receive a trigger. To assign trigger input function to a pin see 7.4.1.
- c. **Remote**: Select to receive a trigger from the remote interface.

After List

Sets the voltage and current settings at the end of the list program.



- a. **DC**: Returns to the last DC output voltage and current setting prior to enabling list mode.
- b. Last: Retains the last step voltage and current setting after the list program ends.

Note:

If the list is aborted, the output will return to the last set voltage and current output values before the list began, even if After List is set to Last.

5.2 Edit List

Press the Utility button then use the soft key to select List Setup > Edit List.

Use the softkeys to set the following parameters.

Load/Save	List	Mayet	Danast	Ctono	Dono
List	Number	Next	Repeat	Steps	Done



5.2.1 Load/Save List

Save to USB

Save the selected list program to a USB.

Use the rotary knob to navigate through the file paths of the USB. Use the Enter button to expand folders. Once the desired location has been found select **Save** by pressing the softkey furthest to the left.




Figure 5.3 Save to USB



Load from USB

Load a previously saved list from a USB to selected **List Number**.

Use the rotary knob to navigate through the file paths of the USB. Use the Enter button to expand folders. Once the desired location has been found select **Load** by pressing the softkey furthest to the left.




Figure 5.4 Load from USB

Note:

The list must be saved/overwritten at the selected list number location before it is able to be assigned.

5.2.1 List Number

- 1. Select a list program from the internal memory.
- 2. Use the numeric keypad or rotary knob to select a list (0 to 9).
- 3. Press Enter



5.2.2 **Next**

Set the next list program to run after the current list elapse.

- a. To make a list run continuously and indefinitely, set **Next** to the same number as **List Number**.
- b. To run different list sequences continuously, set **Next** to each other.

Example Set Next on List 1 to 2. Set Next on List 2 to 1.

5.2.3 Repeat

To repeat a list, set **Repeat** using the numeric keypad or rotary knob and press Enter

5.2.4 Steps

Add, delete, clear all, or edit steps.

Add Step

Use the softkeys to add a step to the list. The step added will be a duplication of the step selected before pressing **Add Step**.

To select a step to duplicate, use the rotary knob to navigate the available steps. If the list is new, only one default step will be available. Pressing **Add Step** will duplicate the default step.




Figure 5.5 Default Step In New List





Delete Step

Delete the step selected before pressing **Delete Step**.

Use the rotary knob to navigate between each step.

Clear All

Clear all list parameters. See fig 5.5

Edit Step

Use the rotary knob to navigate the steps available.(select a row)

To edit parameters of the step, use the keys.(selects a column)

See figure 5.6 for the parameter each row edits.

Press Enter to toggle enable/disable BOST and/or EOST.



Figure 5.6 List Configuration

Step Parameters

Voltage Sets Vset value.

When setting Vset the list will not limit the voltage range based on mode.

Therefore, Vmax will be 96.960 for model 9140 and 180.800 for model 9141.

To prevent a protection trip, verify the Vset and Iset values in the list is within the range of the configured operation mode before running the list.

Current Sets Iset value.

When setting lset the list will not limit the current range based on mode.

Therefore, Imax will be 24.240 for model 9140 and 12.120 for the 9141.

To prevent a protection trip, verify the Vset and Iset values in the list is within the range of the configured operation mode before running the list.

BOST	Press the knob or to	enable/disable a	ı trigger-out	t signal at th	ne beginning c	of the step	(BOST)
------	----------------------	------------------	---------------	----------------	----------------	-------------	--------

EOST Press the knob or to enable/disable a trigger-out signal at the beginning of the step (EOST).

Dwell Sets the dwell time of the selected step.



5.3 List Run

List allows a sequence of outputs with up to 100 configurable steps. With sharable memory across all three channels, a list can run simultaneously on various channels. This allows for a list to be compatible in normal, parallel or series mode.

Before running a list its parameters must be configured.

- 1. Configure the parameters of each step. See 5.2
- 2. Set the settings of the channel which will output the list. See 5.1
 - a. Enable List State on desired channel.
 - b. Assign a List Number to the channel.
 - c. Select Pace (Dwell or Trigger).
 - d. Select **Trigger Source** {Manual, Digital IO, or Remote }.
 - e. Select After List output {DC or Last}.
- 3. After configuring the list and channel parameters press Display to return to the main page.
 - Vset will be replaced with List Start if List State was enabled.




Figure 5.7 List State Disabled

- 4. Select List start to start the list.
 - Once the list begins List Start will change to Abort List






Figure 5.8 List State Enabled CH 1

- The interaction with the list will vary depending on the chosen **Pace**. See **5.1**
- 5. Select List Abort to end the list before all steps elapse. If the all steps elapse the list will end and the output will be set to chosen After List parameter.
 - If **After List** is set to **DC** the output will output the Vset and Iset values.
 - If After List is set to Last the output will output the values of the last step in the list.

Note:

While the list is running the user can adjust the current step output by setting Vset or Iset on the main display. Doing so will immediately change the value of the ongoing output. However, the set value will not be saved to the list. Once the dwell time of the step has elapsed the list will continue and output the next step.

If Trigger source is set to manual, Vset/Iset will not be available. The rotary knob and numeric keypad can be used to adjust the selected value. To adjust both Vset/Iset navigate to the single CH display of

the output using the Display

key. Vset/Iset will be available as shown in figure 5.9.





Figure 5.9 Single Channel Display Vset/Iset

Data Logger

The data logger can record the output voltage, current, and error codes of all three channels. Log data can be configured to record either Voltage only, Current only, or both.

Connect a USB flash drive to the front panel USB port. Max. Recording time will vary based on the flash drive size and the amount of the data being logged.




Figure 6.1 Data Logger Max Time

6.1 Using the Data Logger Function

Press the Utility button then use the soft key to select **Data logger**. The **Data Logger** settings can be selected in this menu.

Before starting the **Data Logger** its settings must be adjusted.

- 1. Set the desired **Sampling Interval** See **6.2.1**
- 2. Select a File Path to determine where to store the collected data. see 6.2.2
- 3. Enable or disable **T. Stamp Filename**. See **6.2.3**
- 4. Choose what data to record. See 6.2.4
- 5. Enable or disable Status Code. See 6.2.5
- 6. Select a **Trigger Source**. See **6.2.6**
- 7. After setting all desired parameters press **datalog Start/Stop** to begin recording. Staring data log will vary based on chosen trigger. See**6.2.7**



6.2 Parameters

6.2.1 Sampling Interval

Press the Utility button then use the soft key to select Data logger > Sampling Interval.

Use the numeric keypad or rotary motor to select the sampling interval. Press Enter to assign the selected value. (.2s to 300s)

6.2.2 File Path

Press the Utility button then use the soft key to select **Data logger** > **File Path**.

Using the rotary knob and Enter navigate through the file path of the USB. Once the desired location has been found select **save** by pressing the softkey furthest to the left.

Verify that the correct path was chosen in the Data Logger menu.




Figure 6.2 File Path Selected

6.2.3 T. Stamp Filename

Press the Utility button then use the soft key to select Data logger > T. Stamp Filename Toggle to enable/disable time and date on the file name.

> **Example** Enabled 9140_log_20201017002307 Disabled 9140 log



6.2.4 Log Data

Press the Enter button then use the soft key to select **Data logger > Next Pg. > Log Data**.

Select data to be logged.

- All: Record both voltage and current output of all channels.
- Voltage: Record the voltage output of all channels.
- Current: Record the current output of all channels.

9241 XXXXXXXX	Datalog		
Sample interval	: 0.2		
Log data:All			
Date: 2021-04-03	1 13:54:18		
00:00:00.00	0	0	0x0000
00:00:00.20	0	0	0x0000
00:00:00.40	0	0	0x0000
00:00:00.60	0	0	0x0000
00:00:00.80	0	0	0x0000
00:00:01.00	0	0	0x0000
00:00:01.20	0	0	0x0000
00:00:01.40	0	0	0x0000
00:00:01.60	0	0	0x0000
00:00:01.80	0	0	0x0000
00:00:02.00	0	0	0x0000
00:00:02.20	0	0	0x0000
00:00:02.40	0	0	0x0000
00:00:02.60	0	0	0x0000
00:00:02.80	0	0	0x0000
00:00:03.00	0	0	0x0000
00:00:03.20	0	0	0x0000
00:00:03.40	0	0	0x0000
00:00:03.60	0	0	0x0000

Figure 6.3 Log Data All

The data is recorded in the following order:						
CH1 Voltage	CH1 Current	CH2 Voltage	CH2 Current	CH3 Voltage	CH3 Current	Status Code

Table 6.1 Data Order





Note:

Data order will vary depending on Log Data selected.

6.2.5 Status Code

Press the Enter button then use the soft key to select Data logger > Status Code. Toggle to enable/disable status code.

Enabled **Status Code** will record all codes reported. See **6.3** for an example. In figure **6.3** the code 0x0001 is returned. This indicates OVP has been triggered.

Table **6.2** defines each code.

Code	Description
0x0001	Over Voltage Protection Triggered
0x0002	Over Current Protection Triggered
0x0004	Over Temperature
	Protection Triggered
0x0008	Sense not connected

Table 6.2 Status Code

6.2.6 Trigger Source

Press the Enter button then use the soft key to select **Data logger > Trigger Source.**

Datalog can be triggered in three ways: **Manual**, **Digital IO**, and **Remote**.

- Manual: Select to use manual trigger. The trigger softkey will be available as Datalog Start/Stop.
 See section 6.2.7
- **Digital IO**: Select to use the digital I/O pins to receive a trigger. To assign a function to a pin see section**7.4.1**.



Remote: Select to receive a trigger from a remote interface.

Note:

For Digital IO and Remote the first trigger will turn Data log on. A second trigger will begin data will be displayed on the top right when data is being logged. See 6.2.7 recording.

6.2.7 Datalog Start/Stop

Press the Enter button then use the soft key to select **Data logger > Datalog Start/Stop**. Toggle to turn datalog On/Off.

will be displayed on the top right when data logger is on but not recording.



The command INIT:IMM:DLOG will turn on data logger.

For **Digital IO** press **Datalog Start/Stop** to turn data logger on.



will be displayed on the top right when data logger is recording.

The command TRIG:DLOG:IMM will begin the recording.

For **Digital IO** an input high signal to the set pin will turn data logger on.

If Trigger Source is set to manual pressing Datalog Start/Stop will start/stop recording without a second signal.

Utilities Menu

Configure the settings in the following menus:

- User Settings
- Remote Interface
- I/O Configuration
- Test/Admin
- Error Log
- Help

7.1 User Settings

Press the Utility button then use the soft key to select Utilities > User Settings.

The system's settings can be configured here.

7.1.1 Key Lock Output

Press the Utility button then use the soft key to select Utilities > User Settings > Key Lock Output.

Toggle to enable/disable the key lock.

- Enabling Key Lock Output changes the function of Key Lock.
- For more information see chapter 8
- Default: OFF

7.1.2 Beep Sound

Press the Utility button then use the soft key to select Utilities > User Settings > Beep Sound.

Toggle to enable/disable the beeper sound.

Default: ON



7.1.3 Date

Press the Utility button then use the soft key to select Utilities > User Settings > Date. Use the number pad to set the date. YY/MM/DD

7.1.4 Time

Press the Utility button then use the soft key to select Utilities > User Settings > Time.

Use the number pad to set the time.

HH:MM:SS

7.1.5 Screen Intensity

Press the Utility button then use the soft key to select Utilities > User Settings > Next Pg. > Screen Intensity.

Use the rotary knob or number pad to set the screen brightness.

Lowest 1

Highest 10

7.1.6 Language

Press the Utility button then use the soft key to select Utilities > User Settings > Next Pg. > Language. Set the language for the On Screen Help guide. It does not change the language for the menus. For more information about On Screen Help see section 7.8



7.2 Remote Interface

The 9140 series supports remote communication on up to three interfaces: USB, LAN, and GPIB (optional).

While in remote mode the screen displays "RMT" in the upper right corner. Switching to remote mode does not impact the supply's output parameters.

In remote mode, front panel operation is disabled. Only the Local button is enabled. Revert to manual mode by pressing the key or by sending the command SYST:LOC.

The webserver remote interface requires the password **BK** to login.

Select and configure the following interfaces:

- **USB**
- LAN
- **GPIB**



7.2.1 USB Settings

Press the Utility button then use the soft key to select Utilities > I/O Config > USB Settings. The USB device port is located in the rear-panel. See 1.8

The 9140 series are both USBTMC and USB VCP compliant.

In the **USB Settings** menu use the soft keys to select either:

- **USBVCP**
- USBTMC

Default: USBVCP



Figure 7.1 USB Details

The VISA Resource string gives USB0::<Vendor ID>::<Product ID>::<Serial Number>:INSTR

```
Example From figure 7.1:
           \langle Vendor ID \rangle = 0x3121
           Product ID = 0x0001 for 9140 or 0x0002 for 9141
           <Serial Number> = 583k20101
```

When using USBVCP set the port setting to:






Figure 7.2 USB Port Settings

7.2.2 LAN

To configure the LAN Settings

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings. The following settings are available in LAN Settings:

- **IP Mode**
- **IP Address**
- Subnet Mask
- **Gateway IP**
- **Primary DNS**
- Hostname
- **LAN Reset**
- **Restore Default**
- **LAN Status**




Figure 7.3 LAN Settings



Note:

To access the webserver remote interface enter the default password **bk**.

IP Mode

Select **Dynamic Host Configuration Protocol** (**DHCP**) or **Manual** to set how the LAN settings will be configured.

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > IP MODE.

The easiest way to configure the LAN settings is to set the IP Mode to **DHCP.DHCP** will automatically assign an IP address to the instrument.

The settings can manually be configured by selecting Manual.

IP Address

The **IP Address** is a unique string of numbers separated by periods. To enter an IP address:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > IP Address.

Use the numeric keypad to enter an IP address. Then keys are used to separate each number in the string. After inputting each number press to set the address.

Subnet Mask

Subnet Mask divides the IP address into network address and host address.

To set Subnet Mask:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > Subnet Mask.

Use the numeric keypad to enter the subnet mask. Then keys are used to separate each number in the string. After inputting each number press to set the address.



Gateway IP

The gateway address is by default the IP address of the network device that connects the instrument. If **IP Mode** is set to DHCP **Gateway IP** does not have to be set.

To set Gateway IP:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > Gateway IP.

Use the numeric keypad to enter an IP address. Then keys are used to separate each number in the string. After inputting each number press to set the address.

Primary DNS

Domain Name Service (DNS) is the system that automatically translates Internet addresses to the numeric machine addresses. The DNS address is the IP address of the system that performs this service.

If IP Mode is set to DHCP DNS will automatically be set.

To set the **Primary DNS**:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > Primary DNS.

Use the numeric keypad to enter an IP address. Then keys are used to separate each number in the string. After inputting each number press to set the address.

Hostname

Each instrument comes with a unique hostname that can be changed. The default hostname has the following format:

BK-<modelnumber>-<Serialnumber>

Figure 7.3 shows the example:

BK-9141-20101



LAN Reset

LAN Reset resets all LAN settings and webpage passwords. The default webpage password is bk.

To reset LAN:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > LAN Reset .

Before resetting a warning will display informing both LAN settings and webpages passwords will be reset.



Figure 7.4 Reset

Select Yes to finalize the reset.



Restore Default

Restore Default will set all LAN settings to their factory defaults.

To restore factory defaults:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Settings > Restore Default .

Before restoring LAN settings to default the following warning will display.




Figure 7.5 Restore Factory Defaults

Select Yes to set to factory default.



LAN Status

LAN Status provides an overview of the LAN settings.

To view the LAN status:

Press the Utility button then use the soft key to select Utilities > I/O Config > LAN Status .




Figure 7.6 LAN Status



7.3 GPIB (optional)

In GPIB the GPIB address can be changed from 01 to 30.

To change the GPIB address:

Press the Utility button then use the soft key to select Utilities > I/O Config > GPIB.



Figure 7.7 GPIB Address

Use the numeric keypad to enter the new address, then press the Enter key.

The rotary knob can also be used to set the address. Enter must be pressed to set the new address.



7.4 Digital I/O

To enter the **Digital I/O** menu:

Press the Utility button then use the soft key to select Utilities > I/O Config > Digital I/O.

Inhibit Mode

Select the function and polarity of pins: 1, 2, and 3.

- **Pin Functions**
 - None Off
 - Digital In Out Latched
 - Trigger In | Out Live
 - Fault Out/Inhibit In
 - Polarity Pos | Neg




Figure 7.8 Digital I/O Menu



7.4.1 Functions

Default: None

To configure a pin:

Press the Utility button then use the soft key to select Utilities > I/O Config > Digital I/O > Pin(#).

None

Set selected pin to have no function.

Digital In | Out

Toggle to select In/Out digital function.

Digital In: Receive a signal from external device. **Digital Out**: Send a signal to external device.



The input voltage range for digital I/O pins is 0 V to 5 V. To prevent damage to the instrument, do not exceed 5 V or supply a negative voltage to the digital I/O pins.

Trigger In | Out

Toggle to select In/Out trigger function.

Trigger In: Receives signal that triggers set event.

Trigger Out: Sent trigger signal when specified. (BOST or EOST)

In **List Mode**, the **Trigger In** function can be used to trigger the next step when **Trigger Source** is set to **Digital IO**.

In **Datalog**, the **Trigger In** function can be used to start/stop data logging when **Trigger Source** is set to **Digital IO**.

Trigger Out is only available for list mode, step BOST and EOST.



Fault Out

Enable a fault condition, which generates a protection fault signal on the digital port.

Different conditions such as over voltage, over current, or over temperature will generate a fault event.

The fault event will "disable" all outputs without turning them off.

The outputs are "disabled" by setting the outputs as low as possible.

7.4.1 Polarity

Default: Positive

Set polarity of selected pin.

Positive

A logic true signal is received as a voltage high.

Negative

A logic true signal is received as a voltage low.

7.4.1 Inhibit Mode

Receive an external input signal that controls the output state of all channels.

Default: Off

To set Inhibit Mode:

- 1. Assign the **inhibit In** function to pin 3 by:
 - Press the Utility button then use the soft key to select Utilities > I/O Config > Digital I/O > Pin 3 > Inhibit In.
- 2. Select Inhibit Mode: Press the Utility button then use the soft key to select Utilities > I/O Config > Digital I/O > Inhibit Mode.
- 3. Select one of the following modes:

Note:

The following modes are only available for pin 3.





The inhibit input is ignored.

Latched

A logic-true transition signal will disable the power supply. The output will remain disabled.

Live

Power supply output follows the state of the inhibit signal. If the inhibit signal is true the output is disabled. When it is false the output is enabled.

7.5 Test/Admin

7.5.1 Self Test

Run a Module test.

Press the Utility button then use the soft key to select Utilities > Test/Admin > Self-Test > Start.



Figure 7.9 Self Test Complete

7.5.2 Security

The **Security Settings** are locked and can be accessed by entering the default code **77416699**.






Figure 7.10 Security Locked

Note:

The default password can be change in the Change Code menu. If the set code is forgotten contact B&K Precision customer support.

Use the password to gain access to the following settings.

- **Change Code**
- **Calibrate**
- **Firmware Update**
- **NISPOM**
- Lock





Change Code

Changes the security code.

Press the Utility button then use the soft key to select Utilities > Test/Admin > Security > Change Code.

Calibrate

Enter calibration mode.

Press the Utility button then use the soft key to select Utilities > Test/Admin > Security > Calibrate . See chapter Calibration Adjustment Procedure to adjust the units calibration.

Firmware Update

Update the firmware and module. Press the Utility button then use the soft key to select Utilities > Test/Admin > Security > Firmware Update .

NISPOM

Select for complete memory wipe. Press the Utility button then use the soft key to select Utilities > Test/Admin > Security > NISPOM .

Lock

Sets security status to Lock. Press the Utility button then use the soft key to select Utilities > Test/Admin > Security > Lock .

If **Done** is selected without locking the security settings, the user will be prompted that the security settings will not be locked.

7.6 Error Log

View up to 50 previously set error codes.

Press the Utility button then use the soft key to select Utilities > Error Log.

Figure 7.11 Error Log

Errors are placed in the order that they were encountered. 1 being the most recent.

The error log displays up to 50 error codes.

After reaching 50 error codes no more codes will be reported in the error log.

To continue filing error codes the error log list must be cleared

The error log can be saved into a USB flash drive connected to the USB port on the front panel.

Save the log by:

Pressing the Utility button then use the soft key to select Utilities > Error Log > Save .

Use the rotary knob and the Enter button to navigate through the file path of the USB. Once the desired location has been found select **Save** by pressing the softkey furthest to the left.

Clear the data log by:

Pressing the Utility button then use the soft key to select Utilities > Error Log > Clear All > Yes.

Code	Description
0x0001	Over Voltage Protection Triggered
0x0002	Over Current Protection Triggered
0x0004	Over Temperature
000004	Protection Triggered
0x0008	Sense not connected

Table 7.1 Status Code



7.7 Help

To enter the Help menu:

Press the Utility button then use the soft key to select Utilities > Help.




Figure 7.12 Help Menu

Use the rotary knob to navigate the help options shown in figure 7.12.

To select the Quick help topic press the Enter key or press the **Select** softkey.

System Info

To view the instrument's general information:

Press the Utility button then use the soft key to select Utilities > Help > System Info.




Figure 7.13 System Info





7.8 On Screen Help

Press and hold any soft key that selects a menu branch for 3 seconds to receive an explanation of what can be found in that branch.

Key Lock

Lock all front panel keys including on and on/off.

Press the Utility button then use press and hold the soft keys **Key Lock** for 3 seconds.




Figure 8.1 Key Lock

If Key Lock Output is enabled, holding Key Lock for 3 seconds locks all front panel keys except and On/Off. See section **7.1.1** to enable/disable Key Lock Output.

To unlock the front panel use the softkey to select Unlock.

Save/Recall

Save/Recall the instruments Output Settings and Power-On Settings.

9.1 Save the Output Settings

Save to Internal Memory

Save the instrument's output settings to the internal memory. A total of 10 (0 to 9) output settings can be saved.

To save the output settings:

Press the Recall button then use the soft keys to select **Save > Save to INT**.

Using the numeric keypad enter a number from 0 to 9 to save the output settings to that address. The settings will be saved after a short delay.




Figure 9.1 Save to Internal Storage

Save to USB

Save the instrument's output settings to a USB flash drive connected to the front panel USB host port.

Press the Recall button then use the soft keys to select **Save > Save to USB**.



Using the rotary knob navigate through the file paths of the USB. Use the Enter button to expand folders. Once the desired location has been found press Save.

The output settings will be saved after a short delay.




Figure 9.2 Save to USB

9.2 Recall the Instrument's Settings

Recall previously saved output settings from the internal memory. A total of 10 (0 to 9) user settings can be saved.

To recall settings:

Press the Recall button then use the soft keys to select Recall > Recall from INT.

Use the numeric keypad to enter a number from 0 to 9 to recall the output settings stored in that address. The settings will be recalled after a short delay.

Recall from USB

Recall the instrument's output settings from a USB drive.

Press the Recall button then use the soft keys to select **Recall** > **Recall from USB**.

Use the rotary knob to navigate through the file paths of the USB. Use the Enter button to expand folders. Once the desired location has been found press Load.

The settings will be recalled after a short delay.








Figure 9.3 Recall from Internal Memory




Figure 9.4 Recall from USB

9.3 Power-On Settings

Load previously saved output parameters on power-on.

Off

To turn off **Power-On Mode**:

Press the soft keys to select **Power-On Settings > Power- On Mode > Off**.

Last

To set the output parameters to the previous parameters before powering-off the instrument: Press the





button then use the soft keys to select **Power-On Settings > Power- On Mode > Last**.

User

To set the output parameters previously saved parameters:

- button then use the soft keys to select Power-On Settings > Power- On Mode > User.
- Press the Recall button then use the soft keys to select **Power-On Settings** > **User Settings**.
- Use the numeric keypad or the rotary knob to assign an address (0 to 9).

To save settings see 9.1.

Default Values and Ranges

Set the instrument's output settings to default.

Press the Recall button then use the soft keys to select **Set to Default**.

9.4 Screenshot

To take a screenshot:

together for 3+seconds until you hear a beep.

A USB must be plugged in for this function.



Devemeter	9140			9141			Heit
Parameter	Default	Max	Min	Default	Max	Min	Unit
VSET	0	32.32	0	0	60.6	0	V
ISET	1	8.08	.015	1	4.04	.015	Α
Vmax	32.32	32.32	0	60.6	60.6	0	V
Vmin	0	32.32	0	0	60.6	0	V
Vslew	1600	3200	0.001	600	3000	0.001	V/s
Islew	500	800	1	100	200	1	A/s
OVP Limit	35.2	35.2	0	66	66	0.000	V
OCP Limit	8.8	8.800	0.015	4.4	4.4	0.015	Α
Timer	0	99:59:59	0	0	99:59:59	0	HH:MM:SS
On Delay	0	3600	0	0	3600	0	Sec
Off Delay	0	3600	0	0	3600	0	Sec
Datalogger Sampling Interval	0.2	300	0.200	0.2	300	0.2	Sec
List Dwell	0.1	9999	0.1	0.1	9999	0.1	Sec
List Voltage	1	96.96	0	1	181.8	0	V
List Current	.015	24.24	.015	.015	12.12	.015	А
List Repeat	0	100000	0	0	100000	0	

Table 9.1 Default Values & Ranges

Calibration Adjustment Procedure

Calibration Interval

The recommended calibration interval for the 9140 series is one year.

To enter the Calibration Menu:

Press the Utility button, then use the soft key to select Utilities > Test/Admin > Security > Calibrate.

In the **Calibration Menu** use the softkeys to select a parameter from the menu to calibrate.

- Voltage
- Current
- **OVP**
- OCP
- **RTC**




Figure 10.1 Calibration Parameters



10.1 Voltage Calibration Adjustment

For the voltage calibration procedure a precise DMM will be needed.

To adjust the voltage calibration:

- 1. Enter the Calibration Menu
 - Press the Utility button, then use the soft key to select Utilities > Test/Admin > Security. Use the numeric keypad to enter security code. See the subsection **Security**. Press the button to enter the security menu.
- 2. Use the softkeys to select **Voltage > CH {1 |2 |3}**.
- 3. Verify the correct channel is chosen.
 - The upper left corner will display the chosen channel. Voltage Calibration will have a frame with the color corresponding to the chosen channel.
 - Yellow = CH 1
 - Blue = CH 2
 - Orange = CH 3
- 4. Connect the DMM's voltage input to the power supply's binding post corresponding to the selected channel.
- 5. Use the softkey to select Start.
- 6. Use the numeric keypad to enter the measured voltage. Press the Enter button to configure the point.
- 7. Repeat step 6 for the remaining calibration points.
 - Upon entering the last calibration point value the display will return to the channel selection screen.
- 8. Repeat steps 2 through 7 to calibrate the remaining channels.



10.2 Current Calibration Adjustment

For the current calibration procedure a precise DMM will be needed.

To adjust the current calibration:

- 1. Enter the Calibration Menu
 - Press the Utility button, then use the soft key to select Utilities > Test/Admin > Security. Use the numeric keypad to enter security code. See the subsection Security. Press the Enter button to enter the security menu.
- 2. Use the softkeys to select Current > CH {1 |2 |3}.
- 3. Verify the correct channel is chosen.
 - The upper left corner will display the chosen channel. Current Calibration will have a frame with the color corresponding to the chosen channel.
 - Yellow = CH 1
 - Blue = CH 2
 - Orange = CH 3
- 4. Connect the DMM current input to the power supply's binding post corresponding to the selected channel.

Note:

Upon entering a calibration point the unit will immediately output the next current point. To avoid blowing the DMM's fuse ensure the correct DMM's input is chosen.

The points' output are as follows:

9140		9141	
1st Point 0).4 A	1st Point	0.2 A
2nd Point	2.8 A	2nd Point	1.4 A
3rd Point 5	5.5 A	3rd Point	2.7 A
4th Point 8	3.0 A	4th Point	4.0 A



- 5. Use the softkey to select **Start**.
- 6. Use the numeric keypad to enter the measured current. Press the Enter button to configure the point.
- 7. Repeat step 6 for the remaining calibration points.
 - Upon entering the last calibration point value the display will return to the channel selection screen.
- 8. Repeat steps 2 through 7 to calibrate the remaining channels.

10.3 OVP Calibration Adjustment

For the over voltage protection calibration the instrument's voltage must be calibrated.

To adjust the OVP calibration:

- 1. Enter the Calibration Menu
 - Press the Utility button, then use the soft key to select Utilities > Test/Admin > Security. Use the numeric keypad to enter security code. See the subsection Security. Press the button to enter the security menu.
- 2. Use the softkeys to select OVP > CH {1 |2 |3}.
- 3. Verify the correct channel is chosen.
 - The upper left corner will display the chosen channel. OVP Calibration will have a frame with the color corresponding to the chosen channel.
 - Yellow = CH 1
 - Blue = CH 2
 - Orange = CH 3
- 4. Connect the DMM's voltage input to the power supply's binding post corresponding to the selected channel.
- 5. Use the softkey to select **Start**.
- 6. Calibration State will show as Busy. After a few seconds the calibration will be adjusted on its own.
- 7. Upon successfully completing the calibration adjustment a different channel can be selected.
- 8. Repeat steps 2 through 6 to calibrate the remaining channels.



10.4 OCP Calibration Adjustment

For the over current protection calibration the instrument's current must be calibrated.

To adjust the OCP calibration:

- 1. Enter the Calibration Menu
 - Press the Utility button, then use the soft key to select Utilities > Test/Admin > Security. Use the numeric keypad to enter security code. See the subsection Security. Press the button to enter the security menu.
- 2. Use the softkeys to select OCP > CH {1 | 2 | 3}.
- 3. Verify the correct channel is chosen.
 - The upper left corner will display the chosen channel. OCP Calibration will have a frame with the color corresponding to the chosen channel.
 - Yellow = CH 1
 - Blue = CH 2
 - Orange = CH 3
- 4. Connect the DMM's 10 A input to the power supply's binding post corresponding to the selected channel.
- 5. Use the softkey to select Start.
- 6. Calibration State will show as Busy. After a few seconds the calibration will be adjusted on its own.
- 7. Upon successfully completing the calibration adjustment a different channel can be selected.
- 8. Repeat steps 2 through 6 to calibrate the remaining channels.



10.5 RTC Calibration Adjustment

To adjust the Real-Time Clock(RTC) calibration:

- 1. Enter the Calibration Menu
 - Press the Utility button, then use the soft key to select Utilities > Test/Admin > Security. Use the numeric keypad to enter security code. See the subsection Security. Press the button to enter the security menu.
- 2. Use the softkeys to select RTC.
- 3. Use the softkey to select Start.
- 4. Calibration State will show as Busy. The calibration will be adjusted on its own in about 4 to 5 mins.
- 5. Calibration State will show as Success once the calibration has finished.

Performance Verification

Performance verification ensures the instrument will meet specifications listed in the datasheet. Load regulation can be tested for both the front and rear outputs.

Note:

All specifications apply to the unit after a temperature stabilization time of 15 minutes over an ambient temperature range of 23 $^{\circ}$ C \pm 5 $^{\circ}$ C. Specifications are valid for single unit operation only.

CV Load Regulation Front Panel Output

- 1. Turn off the power supply before making any connections.
- 2. Connect the: DMM, electronic load, and the rear panel remote sense to the power supply's terminal being tested.

(Remote sense must correspond with the channel being tested.)




Figure 11.1 Front Panel Wiring Diagram



Note:

Keep all cables as short as possible.

- 3. Turn on the power supply.
- 4. Set the power supply settings of the channel being tested to the values given in table 11.1.
- 5. Set the electronic load settings to the stated values in table 11.1.
- 6. Enable remote sense. See section Remote Sense.
- 7. Enable the channel output.
- 8. Enable the electronic load. Monitor the power supply to ensure it remains in CV mode. If the power supply switches to CC slightly lower the current on the electronic load until the power supply return to CV mode.
- 9. Give the power supply some time to settle and record the DMM reading as V load.
- 10. Disable the electronic load and record the DMM reading as V noload.
- 11. Take the difference between V load and V noload (V load V noload) and record the value as the voltage regulation. The difference should be within the **specification limit**.

CV Load Regulation Rear Panel Output

- 1. Turn off the power supply before making any connections.
- 2. Connect the: DMM, electronic load, and the rear panel remote sense to the power supply's rear +/terminal being tested. Use jumpers to connect the +S to + and -S to -. See figure 11.2 (Remote sense must correspond with the channel being tested.)
- 3. Turn on the power supply.
- 4. Set the power supply settings of the channel being tested to the values given in table 11.1.
- 5. Set the electronic load settings to the stated values in table 11.1.
- 6. Enable remote sense. See section Remote Sense.
- 7. Enable the channel output.






Figure 11.2 Rear Panel Wiring Diagram

- 8. Enable the electronic load. Monitor the power supply to ensure it remains in CV mode. If the power supply switches to CC slightly lower the current on the electronic load until the power supply return to CV mode.
- 9. Give the power supply some time to settle and record the DMM reading as V load.
- 10. Disable the electronic load and record the DMM reading as V noload.
- 11. Take the difference between V load and V noload (V load V noload) and record the value as the voltage regulation. The difference should be within the **specification limit**.

Model	Power Supply Settings		Electronic		Load Regulation Limit		
Model	Voltage	Current	Remote	Mode	Current	Lower Limit	Upper Limit
9140	32.000 V	3.069 A	Enabled	CC	3.065 A	- 6.2 mV	+ 6.2 mV
9141	60.000 V	1.666 A	Enabled	CC	1.650 A	- 9 mV	+ 9 mV

Table 11.1

Specifications

Note: All specifications apply to the unit after a temperature stabilization time of I5 minutes over an ambient temperature range of 23 °C \pm 5 °C. Specifications are valid for single unit operation only.

Model		9140	9141	
Output Rating				
Voltage		32 V	60 V	
Current		8 A	4 A	
Maximum Output Power	per Channel	100 W		
Total Output Po	ower	300	W	
Load Regulation (1) ± (%	output + offset	t)		
Voltage		≤ 0.01%	+ 3 mV	
Current		≤ 0.1%	+ 3 mA	
Line Regulation ± (% ou	tput + offset)			
Voltage		≤ 0.01%	+ 3 mV	
Current		≤ 0.1%	+ 3 mA	
Ripple and Noise (20 Hz	z to 20 MHz)			
Normal Mode Volt	age p-p	≤ 5 mV	≤ 10 mV	
Normal Mode Volt	age rms	≤ I mV	≤ 2 mV	
Normal Mode Curr	ent rms	≤ 3	mA	
Programming / Readback	ck Resolution			
Voltage		I n	ıV	
Current		I m	ıA	
Programming / Readback	ck Accuracy ± (% output + offset)		
Voltage		0.03% + 4 mV	0.03% + 8 mV	
Current		0.1% + 5 mA	0.1% + 3 mA	
Series Accuracy (combine				
Voltage		0.03% + 12 mV		
Current		0.1% + 5 mA 0.1% + 3 mA		
Parallel Accuracy (comb	ined mode)			
Voltage		0.03% + 4 mV	0.03% + 8 mV	
Current		0.1% + 15 mA	0.1% + 9 mA	
Temperature Coefficient	t per °C			
Voltage		6.4 mV / °C	I2 mV / °C	
Current		I.6 mA / °C		
Output Response Time	2)			
Rise Time	Full load	10 ms	20 ms	
	No load	10 ms	20 ms	
Fall Time	Full load	IO ms	20 ms	
No load		250 ms 250 ms		
Transient Response (3)				
Time		0.5 ms		
Protection	_			
OVP	Range	35.2 V	66 V	
	Accuracy	320 mV	600 mV	
ОСР	Range	8.8 A	4.4 A	
	Accuracy	80 mA	40 mA	

General			
Remote Sense Compensation		ΙV	
Command Response	Time (4)	10 ms	
Power Factor		0.98 / II5 VAC 0.94 / 230 VAC	
I/O Interfaces		USB (USBTMC-compliant and virtual COM), LAN (I.5 LXI device specification 2016), GPIB (optional)	
AC Line Input		100 VAC to 240 VAC ± 10%, 47 Hz to 63 Hz	
Maximum Rated Inpu	t Power	500 VA	
T Detine	Operation	32 °F to I04 °F (0 °C to 40 °C)	
Temperature Ratings	Storage	14 °F to I58 °F (-10 °C to 70 °C)	
Dimensions (W x F	I x D)	8.4" x 3.5" x 13" (213 x 88 x 330 mm)	
Weight		II lbs (5 kg)	
Warranty		3 Years	
Standard Accessories		Power cord, test report & certificate of calibration	
Optional Accessories		Rack mount kit (RK2US)	

Regulatory Compliance				
Safety	Low Voltage Directive (LVD) 2014/35/EU, EN61010-1:2010, cTUVus certification mark ⁽⁵⁾ fulfills US (UL 61010-1:2012) and Canadian (CAN/CSA-C22.2 NO. 61010-1-12) safety standards			
Electromagnetic Compatibility	EMC Directive 2014/30/EU, EN61326-1:2013			

- (I) With remote sense terminal connected.
- (2) From 10% to 90% or from 90% to 10% of total voltage excursion.
- (3) Time for output voltage to recover within 0.5% of its rated output for a load change 50-100% of full load.
- (4) Typical time required for output to begin to change following receipt of command data.
- (5) Tested and certified by a Nationally Recognized Testing Laboratory (NRTL), accredited by OSHA.

Ordering Information

9140 Series Power Supplies

Model Description 32 V / 8 A, 300 W 9140 9140-GPIB 32 V / 8 A, 300 W with GPIB

60 V / 4 A, 300 W 9141

9141-GPIB 60 V / 4 A, 300 W with GPIB