OPERATING MANUAL

Refrigerated and **Heating Circulators**

air cooled

F25-HE

F32-HE

F34-HE

FP50-HE

water cooled

FPW50-HE





Original Operating Manual

1.951.2460-V7 09/19

16.09.2019

Congratulations!

You have made an excellent choice.

JULABO thanks you for the trust you have placed in us.

This operating manual has been designed to help you gain an understanding of the operation and possible applications of our circulators. For optimal utilization of all functions, we recommend that you thoroughly study this manual prior to beginning operation.

The JULABO Quality Management System



Temperature control devices for research and industry are developed, produced, and distributed according to the requirements of ISO 9001 and ISO 14001. Certificate Registration No. 01 100044846

Unpacking and inspecting

Unpack the circulator and accessories and inspect them for possible transport damage. Damage should be reported to the responsible carrier, railway, or postal authority, and a damage report should be requested. These instructions must be followed fully for us to guarantee our full support of your claim for protecting against loss from concealed damage. The form required for filing such a claim will be provided by the carrier.

Changes without prior notification reserved

Important: keep operating manual for future use

TABLE OF CONTENTS

Opera	ating manual	5
1. Ir	ntended use	5
1.1.	Description	5
2. O	Operator responsibility – Safety recommendations	6
2.1.	Disposal	8
2.2.	Warranty conditions	8
2.3.	EC Conformity	9
2.4.	Technical specifications	14
2.5.	Cooling water connection	19
Opera	ating instructions	20
3. S	Safety notes for the user	20
3.1.	Explanation of safety notes	20
3.2.	Explanation of other notes	20
3.3.	Safety recommendations	21
4. O	Operating controls and functional elements	23
5. P	Preparations	27
5.1.	Installation	27
5.2.	Bath fluids	28
5.3.	Temperature application to external systems	30
5	.3.1.Tubing	31
5.4.	Filling/draining	32
6. O	Pperating procedures	33
6.1.	Power connection	33
6.2.	Switching on/Start - Stop	33
	5.2.1.Switching on the circulator	
6	5.2.2.Switching on the Cooling Machine	34
7.	Setting of temperatures	35
7.1.	Using the pre-settings in the T menu	35
7.2.	Direct setting of temperatures	36
8.	Safety installations, warning functions	37
8.1.	Excess temperature protection	37
8	.1.1.Early warning system, low level protection	38
8.2.	Switch-over from warning to shutdown function	39
8.3.	Over and Sub temperature warning function	40
9.	MENU Menu functions	41
9.1.	MENU PROGRAM – START	42
9.2.	MENU PROGRAM – creation, administration	45

9.3	B. MENU PUMP - Setting of pump pressure	47
9.4	MENU CONFIG - Configuration of unit	48
	9.4.1.Remote control via the serial interface	49
	9.4.2.Keypad control or setpoint setting via the analog input	
	9.4.3.AUTOSTART	
	9.4.4.OFF-MODE	
	9.4.5.ACTVAR - actuating variable	
	9.4.6.Setting of clock and date	
	9.4.7.RESET – Factory settings	
	MENU CONTROL — Control characteristics and parameters	
	9.5.1.CONTROL – Control INTERNAL/EXTERNAL	
	9.5.3.Dynamic internal	
	9.5.4.Control parameters– XP-, TN-, TV- INTERNAL	
	9.5.5.COSPEED - external	
	9.5.6.Control parameters – XPU-, XP-, TN-, TV- EXTERNAL	57
9.6	6. MENU SERIAL - BAUDRATE, HANDSHAKE, PARITY	58
9.7	. MENU ATC - Absolut Temperature Calibration	59
	9.7.1.ATC SENSOR - INTERNAL/EXTERNAL	61
	9.7.2.ATC STATUS - YES/NO	
	9.7.3.CALIBRATION TYPE: 1 -/ 2 -/ 3 POINT	62
	9.7.4.Example: 3-point calibration for internal control	
	B. MENU LIMITS	
	9.8.1.Limits for internal control	
	9.8.2.Limits for external control	
	MENU IN/OUT – Analog inputs/outputs (Option)	
	9.9.1.Outputs of the connector - REG+E-PROG	
	9.9.2.Input of the connector - REG+E-PROG	
	9.9.3.ALARM-output/Stand-by-input	/4
10.	Troubleshooting guide/error messages	76
11.	Electrical connections	79
12.	Remote control	81
12.	1. Setup for remote control	81
12.	2. Communication with a PC or a superordinated data system	81
12.	3. List of commands	82
12.	4. Status messages	85
	5. Error messages	
	Installation of electronic module	
	JULABO Service – Online remote diagnosis	
15.	Cleaning/repairing the unit	88

Operating manual

1. Intended use


JULABO circulators have been designed to control the temperature of specific fluids in a bath tank. The units feature pump connections for temperature control of external systems (loop circuit).



JULABO circulators are not suitable for direct temperature control of foods, semiluxury foods and tobacco, or pharmaceutical and medical products. Direct temperature control means unprotected contact of the object with the bath medium (bath fluid).

1.1. **Description**







☑ Temperature- and time-dependent processes can be stored and executed using the integrated programmer.



☑ The control electronics including "ICC - Intelligent Cascade Control" automatically adjust the heat supply to the thermal requirements of the bath.



☑ The TCF - Temperature Control Features give the user access to all important temperature control parameters. This means full control of the control behavior at all times and the ability to manually adjust or adapt the controls to the specific application.



☑ Absolute Temperature Calibration (ATC3) provides high temperature stability at all points in the bath. With the 3-point calibration, an offset is adjusted at three temperatures to ensure an accurate temperature pattern at the selected spot in the bath over the entire temperature range.



☑ Electrical connections:

RS232

The serial interface, switchable from RS232 to RS485, allows modern process technology without additional interface.

Pt100

Connection for Pt100 external sensor for external temperature measurement and control. Alarm output for external alarm message or control of JULABO refrigerating baths

or solenoid valve (cooling water). The electronic module (option) provides 3 further analog connections (alarm input,

standby input, recorder output, programmer input).



☑ The excess temperature protection conforming to IEC 61010-2-010 is a safety installation independent from the control circuit. This protection can be indicated and set on the VFD COMFORT-DISPLAY.



☑ The early warning system for low level signals that bath fluid needs to be refilled. before the low level protection conforming to IEC 61010-2-010 causes a complete shutdown of the main functional elements.

☑ Intelligent pump system: The pump capacity (electronically adjustable via the motor speed) enables to adapt to varying conditions for internal and external temperature applications.

2. Operator responsibility – Safety recommendations

The products of JULABO ensure safe operation when installed, operated, and maintained according to common safety regulations. This section explains the potential dangers that may arise when operating the circulator and also specifies the most important safety precautions to preclude these dangers as far as possible.

- > The operator is responsible for the qualification of the personnel operating the units.
- The personnel operating the units should be regularly instructed about the dangers involved with their job activities as well as measures to avert these dangers.
- Make sure all persons tasked with operating, installing, and maintaining the unit have read and understand the safety information and operating instructions.
- When using hazardous materials or materials that could become hazardous, the circulator may be operated only by persons who are absolutely familiar with these materials and the circulator. These persons must be fully aware of possible risks.

If you have any questions concerning the operation of your unit or the information in this manual, please contact us!

Contact

Safety instructions for the operator:

- You have received a product designed for industrial use. Nevertheless, avoid strikes to the housing, vibrations, damage to the operating-element panel (keypad, display), and contamination.
- Make sure the product is checked for proper condition regularly (depending on the conditions of use). Regularly check (at least every 2 years) the proper condition of the mandatory, warning, prohibition and safety labels.
- Make sure that the mains power supply has low impedance to avoid any negative effects on instruments being operated on the same mains.
- This unit is designed for operation in a controlled electromagnetic environment. This means that transmitting devices (e.g., cellular phones) should not be used in the immediate vicinity. Magnetic radiation may affect other devices with components sensitive to magnetic fields (e.g., monitors). We recommend maintaining a minimum distance of 1 m.
- Permissible ambient temperature: max. 40 °C, min. 5 °C.
- Permissible relative humidity: 50% (40 °C).
- Do not store the unit in an aggressive atmosphere.
- Protect the unit from contamination.
- Do not expose the unit to sunlight.

Appropriate operation

Only qualified personnel is authorized to perform configuration, installation, maintenance and repairs of the circulator.

Routine operation can also be carried out by untrained personnel who should however be instructed by trained personnel.

Use:

The bath can be filled with flammable materials. Fire hazard!

There might be chemical dangers depending on the bath medium used.

Observe all warnings for the used materials (bath fluids) and the respective instructions (safety data

Insufficient ventilation may result in the formation of explosive mixtures. Only use the unit in well ventilated areas.

Only use recommended materials (bath fluids). Only use non-acid and non corroding materials.

When using hazardous materials or materials that could become hazardous, the operator must affix the enclosed safety labels (1 + 2) to the front of the unit so they are highly visible:

1 Warning label W00: Colors: yellow, black Danger area. Attention! Observe instructions. (operating manual, safety data sheet) 2 Mandatory label M018: Colors: blue, white Carefully read the user information prior to beginning operation. Scope: EU or 2 Semi S1-0701 Table A1-2 #9 Carefully read the user information prior to beginning operation. Scope: USA, NAFTA

Particular care and attention is necessary because of the wide operating range. There are thermal dangers: Burn, scald, hot steam, hot parts and surfaces that can be touched.



Warning label W26: Colors: yellow, black

Hot surface warning.

(The label is put on by JULABO)

Observe the instructions in the manuals for instruments of a different make that you connect to the circulator, particularly the respective safety recommendations. Also observe the pin assignment of plugs and technical specifications of the products.

2.1. Disposal

The circulator contains a back-up battery that supplies voltage to memory chips when the unit is switched off. Do not dispose of the battery with household waste!

Depending on battery regulations in your country, you might be obliged to give back used or defect batteries to gathering places.

The product may be used with oil as bath fluid. These oils fully or partially consist of mineral oil or synthetic oil. For disposal, observe the instructions in the safety data sheets.

These units contains refrigerants – at this time considered not to have any negative effects on the ozone layer. However, during the long operating period of the unit, disposal prescriptions may change. So only qualified personnel should take care of disposal.



Valid in EU countries

See the current official journal of the European Union – WEEE directive. Directive of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE).

This directive requires electrical and electronic equipment marked with a crossedout trash can to be disposed of separately in an environmentally friendly manner. Contact an authorized waste management company in your country.

Disposal with household waste (unsorted waste) or similar collections of municipal waste is not permitted!

2.2. Warranty conditions

JULABO GmbH warrants its products against defects in material or in workmanship, when used under appropriate conditions and in accordance with appropriate operating instructions

for a period of ONE YEAR.

Extension of the warranty period – free of charge



With the '1PLUS warranty' the user receives a free of charge extension to the warranty of up to 24 months, limited to a maximum of 10 000 working hours.

To apply for this extended warranty the user must register the unit on the JULABO web site , indicating the serial no. The extended warranty will apply from the date of JULABO GmbH's original invoice.

JULABO GmbH reserves the right to decide the validity of any warranty claim. In case of faults arising either due to faulty materials or workmanship, parts will be repaired or replaced free of charge, or a new replacement unit will be supplied.

Any other compensation claims are excluded from this guarantee.

2.3. **EC Conformity**

EG-Konformitätserklärung nach EG Maschinenrichtlinie 2006/42/EG, Anhang II A EC-Declaration of Conformity to EC Machinery Directive 2006/42/EC, Annex II A

Hersteller / Manufacturer:

JULABO GmbH Gerhard-Juchheim-Straße 1 77960 Seelbach / Germany Tel: +49(0)7823 / 51 - 0



Hiermit erklären wir , dass das nachfolgend bezeichnete Produkt We hereby declare, that the following product

Produkt / Product: Thermostat / Circulator

HE, HL, SE, SL Typ / Type:

Serien-Nr. / Serial-No.: siehe Typenschild / see type label

aufgrund seiner Konzipierung und Bauart in der von uns in Verkehr gebrachten Ausführung den grundlegenden Sicherheits- und Gesundheitsanforderungen den nachfolgend aufgeführten EG-Richtlinien entspricht. due to the design and construction, as assembled and marketed by our Company - complies with fundamental safety and health requirements according to the following EC-Directives.

Maschinenrichtlinie 2006/42/EG; Machinery Directive 2006/42/EC EMV-Richtlinie 2004/108/EG; EMC-Directive 2004/108/EC (bis zum / until 19. April 2016) EMV-Richtlinie 2014/30/EU; EMC-Directive 2014/30/EU (vom / from 20. April 2016) RoHS-Richtlinie 2011/65/EU; RoHS-Directive 2011/65/EU

Angewandte harmonisierte Normen und techn. Spezifikationen:

The above-named product is in compliance with the following harmonized standards and technical specifications:

EIN 3030 | 2012
Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe
Technickal documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

EN ISO 12100: 2010

Sicherheit von Maschinen - Allgemeine Gestaltungsleitsätze - Risikobeurteilung und Risikominderung (ISO 12100:2010) Safety of machinery - General principles for design - Risk assessment and risk reduction (ISO 12100:2010)

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 1: Allgemeine Anforderungen Safety requirements for electrical equiment for measurement, control, and laboratory use, Part 1: General requiremen

EN 61010-2-010: 2014
Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 2-010: Besondere Anforderungen an Laborgeräte für das Erhitzen von Stoffen Safety requirements for eletrical equipment for measurement, control, and laboratory use, Part 2-010: Particular requirements for laboratory equipment for the heating of

EN 61326-1: 2013

Elektrische Mess-, Steuer-, Regel- und Laborgeräte- EMV-Anforderungen- Teil 1: Allgemeine Anforderungen Electrical equipment for measurement, control, and laboratory use - EMC requirements - Part 1: General requirements

Bevollmächtigter für die Zusammenstellung der techn. Unterlagen: Authorized representative in charge of administering technical documentation: Hr. Torsten Kauschke, im Hause I on the manufacturer's premises as defined above

Die Konformitätserklärung wurde ausgestellt The declaration of conformity was issued and valid of

Seelbach, 22.02.2016

M. Juchheim, Geschäftsführer / Managing Director

2016_008_HE-HL-SE-SL-Thermostat_d_e.docx

JULABO GmbH Hersteller / Manufacturer:

Gerhard-Juchheim-Straße 1 77960 Seelbach / Germany Tel: +49(0)7823 / 51 - 0



Hiermit erklären wir , dass das nachfolgend bezeichnete Produkt

We hereby declare, that the following product

Produkt / Product: Kältegerät / Refrigeration Unit

Typ / Type:

Serien-Nr. / Serial-No.: siehe Typenschild / see type label

aufgrund seiner Konzipierung und Bauart in der von uns in Verkehr gebrachten Ausführung den grundlegenden Sicherheits- und Gesundheitsanforderungen den nachfolgend aufgeführten EG-Richtlinien entspricht. due to the design and construction, as assembled and marketed by our Company - complies with fundamental safety and health requirements according to the following EC-Directives.

Maschinenrichtlinie 2006/42/EG; Machinery Directive 2006/42/EC EMV-Richtlinie 2014/30/EU; EMC-Directive 2014/30/EU RoHS-Richtlinie 2011/65/EU; RoHS-Directive 2011/65/EU

Angewandte harmonisierte Normen und techn. Spezifikationen:

The above-named product is in compliance with the following harmonized standards and technical specifications:

EN 50581: 2012

Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

EN ISO 12100: 2010

Sicherheit von Maschinen - Algemeine Gestaltungsfeitsätze - Risikobeurteilung und Risikominderung (ISO 12100-2010). Safety of machinery - General principles for design - Risik assessment and risik reduction (ISO 12100-2010).

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 1: Allgemeine Anforderungen Safoty requirements for electrical equiment for measurement, control, and laboratory use, Part 1: General requirements

EN 61010-2-010 : 2014

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 2-010: Besondere Anforderungen an Laborgeräte für das Erhitzen von Stoffen Safoty requirements for eletrical equipment for measurement, control, and laboratory use, Part 2-010: Particular requirements for laboratory equipment for the heating of

EN 61326-1:2013

Elektrische Mess-, Steuer-, Regel- und Laborgeräte- EMV-Anforderungen- Teil 1: Allgemeine Anforderungen Electrical equipment for measurement, control, and laboratory use - EMC requirements - Part 1: General requirements

Kälikanlagen und Wärmepumpen – Sicherheitstechnische und umweitrelevante Anforderungen – Teil 1: Grundlegende Anforderungen, Begriffe, Klassifikationen und Auswahlniterien
Auswahlniterien
Befrigerating systems and heat pumps - Safety and erwironmental requirements - Part 1: Basics requirements, definitions, classification and selection criteria

EN 378-2: 2016

Kälteanlagen und Wärmepumpen – Sicherheitstechnische und umweltrelevante Anforderungen – Teil 2: Konstruktion, Herstellung, Prüfung, Kennzeichnung und Dokumentation Dokumentation Refrigerating systems and heat pumps - Safety and environmental requirements - Part 2: Design, construction, testing, marking and documentation

EN 378-3: 2016

Kälteanlagen und Wämsepumpen – Sichemeitstechnische und umweitrelevante Anforderungen – Teil 3. Aufstellungsort und Schutz von Personen Refrigerating systems and heat pumps - Safety and environmental requirements - Part 3. Installation site and personal protection

EN 378-4: 2016

Källearlagen und Wärmepumpen – Sicherheitstechnische und umweitrelevante Anforderungen – Teil 4: Betrieb, Instandhaltung, Instandsetzung und Rückgewinnung Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, repair and recovery

Bevollmächtigter für die Zusammenstellung der techn. Unterlagen:

Authorized representative in charge of administering technical documentation: Hr. Torsten Kauschke, im Hause I on the manufacturer's premises as defined above

Die Konformitätserklärung wurde ausgestellt

The declaration of conformity was issued and valid of

Seelbach, 05.10.2017

M. Juchheim, Geschäftsführer / Managing Director

2017_010_F25-Kältegerät_d_e.docx

JULABO GmbH Hersteller / Manufacturer:

Gerhard-Juchheim-Straße 1 77960 Seelbach / Germany Tel: +49(0)7823 / 51 - 0



Hiermit erklären wir, dass das nachfolgend bezeichnete Produkt

We hereby declare, that the following product

Produkt / Product: Kältegerät / Refrigeration Unit

Typ / Type:

Serien-Nr. / Serial-No.: siehe Typenschild / see type label

aufgrund seiner Konzipierung und Bauart in der von uns in Verkehr gebrachten Ausführung den grundlegenden Sicherheits- und Gesundheitsanforderungen den nachfolgend aufgeführten EG-Richtlinien entspricht.

due to the design and construction, as assembled and marketed by our Company - complies with fundamental safety and health requirements according to the following EC-Directives.

Maschinenrichtlinie 2006/42/EG; Machinery Directive 2006/42/EC EMV-Richtlinie 2014/30/EU; EMC-Directive 2014/30/EU RoHS-Richtlinie 2011/65/EU; RoHS-Directive 2011/65/EU

Angewandte harmonisierte Normen und techn. Spezifikationen:

The above-named product is in compliance with the following harmonized standards and technical specifications:

Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe Technische Dokumentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

EN ISO 12100: 2010

Sicherheit von Maschinen - Allgemeine Gestaltungsleitsätze - Risikobeurteilung und Risikominderung (ISO 12100:2010) Safety of machinery - General principles for design - Risik assessment and risik reduction (ISO 12100:2010)

EN 61010-1:2010

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 1: Allgemeine Anforderungen Safety requirements for electrical equiment for measurement, control, and laboratory use, Part 1: General requireme

EN 61010-2-010: 2014

Sicherheisbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 2-010: Besondere Anforderungen an Laborgeräte für das Erhitzen von Stoffen Safety requirements for eletrical equipment for measurement, control, and laboratory use, Part 2-010: Particular requirements for laboratory equipment for the heating of

EN 61326-1: 2013

Elektrische Mess-, Steuer-, Regel- und Laborgeräte- EMV-Anforderungen- Teil 1: Allgemeine Anforderungen Electrical equipment for measurement, control, and laboratory use - EMC requirements - Part 1: General requirements

EN 378-1: 2016

Kälteanlagen und Wärmepumpen – Sicherheitstechnische und umweltrelevante Anforderungen – Teil 1: Grundlegende Anforderungen, Begriffe, Klassifikationen und Auswahlkriterien
Refrigerating systems and heat pumps - Safety and environmental requirements - Part 1: Basics requirements, definitions, dassification and selection criteria

EN 378-2: 2016

Refrigerating systems and heat pumps - Safety and environmental requirements - Part 2: Design, construction, Herstellung, Prüfung, Kennzeichnung und Dekumentation

Kälteanlagen und Wärmepumpen – Sicherheitstechnische und umweltrelevante Anforderungen – Teil 3: Aufstellungsort und Schutz von Personen Refrigerating systems and heat pumps - Safety and environmental requirements - Part 3: Installation site and personal protection

EN 378-4: 2016

Kälteanlagen und Wärmepumpen – Sicherheitstechnische und umweltrelevente Anforderungen – Teil 4: Betrieb, Instandhaltung, Instandsetzung und Rückgewinnung Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, repair and recovery

Bevollmächtigter für die Zusammenstellung der techn. Unterlagen:

Authorized representative in charge of administering technical documentation:

Hr. Torsten Kauschke, im Hause / on the manufacturer's premises as defined above

Die Konformitätserklärung wurde ausgestellt

The declaration of conformity was issued and valid of

Seelbach, 05.10.2017

M. Juchheim, Geschäftsführer / Managing Director

2017_012_F32-Kältegerät_d_e.docx

Hersteller / Manufacturer:

JULABO GmbH Gerhard-Juchheim-Straße 1 77960 Seelbach / Germany Tel: +49(0)7823 / 51 - 0



Hiermit erklären wir , dass das nachfolgend bezeichnete Produkt

We hereby declare, that the following product

Produkt / Product: Kältegerät / Refrigeration Unit

Typ / Type: F34 Serien-Nr. / Serial-No.: siehe Typenschild / see type label

aufgrund seiner Konzipierung und Bauart in der von uns in Verkehr gebrachten Ausführung den grundlegenden Sicherheits- und Gesundheitsanforderungen den nachfolgend aufgeführten EG-Richtlinien entspricht. due to the design and construction, as assembled and marketed by our Company - complies with fundamental safety and health requirements according to the following EC-Directives.

Maschinenrichtlinie 2006/42/EG; Machinery Directive 2006/42/EC EMV-Richtlinie 2014/30/EU; EMC-Directive 2014/30/EU RoHS-Richtlinie 2011/65/EU; RoHS-Directive 2011/65/EU

Angewandte harmonisierte Normen und techn. Spezifikationen:

The above-named product is in compliance with the following harmonized standards and technical specifications:

EN 50581: 2012

Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe-Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

EN ISO 12100 : 2010

Sicherheit von Maschinen - Allgemeine Gestaltungsleitsätze - Risikobeurteilung und Risikominderung (ISO 12100;2010) Safety of machinery - General principles for design - Risk assessment and risk reduction (ISO 12100;2010)

EN 61010-1:2010

Sicherhaltsbestimmungen für elektrische Mess-, Steuer-, Regel- und Läborgeräte, Teil 1: Allgemeine Anforderungen Safety requirements for electrical equiment for measurement, control, and laboratory use, Part 1: General requirements

EN 61010-2-010: 2014

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Lebergeräte, Teil 2-010: Besondere Anforderungen an Lebergeräte für das Erhitzen von Stoffen Safety requirements for eletrical equipment for measurement, control, and laboratory use, Part 2-010: Particular requirements for laboratory equipment for the heating of

EN 61326-1: 2013

Elektrische Mess-, Steuer-, Regel- und Laborgeräte- EMV-Anforderungen- Teil 1: Allgemeine Anforderungen Electrical equipment for measurement, control, and laboratory use - EMC requirements - Part 1: General requirements

Källearilagen und Wärmepumpen – Sicherheitstechnische und umweltrelevante Anforderungen – Teil 1; Grundlegende Anforderungen, Begriffe, Klassifikationen und Auswahlkriferien
Auswahlkriferien
Befrigeraltring systems and heat pumps - Safety and envirormental requirements - Part 1: Basics requirements, definitions, diassification and selection criteria

EN 378-2: 2016

Kälteanlagen und Wärmepumpen – Sichemeitstechnische und umweltrelevante Anforderungen – Teil 2: Konstruktion, Herstellung, Prüfung, Kennzeichnung und Dokumentation Refrigerating systems and heat pumps - Safaty and environmental requirements - Part 2: Design, construction, testing, marking and documentation

EN 378-3: 2016

Källeanlagen und Wärmepumpen – Sichemeitstechnische und umweltrelevante Anforderungen – Teil 3: Aufstellungsort und Schutz von Personen. Refrigerating systems and heat pumps - Safety and environmental requirements - Part 3: Installation site and personal protection.

EN 378-4: 2016

Källeanlagen und Wärmepumpen – Sicherheitstechnische und umweitrelevante Anforderungen – Teil 4: Betrieb, Instandhaltung, Instandsetzung und Rückgewinnung Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, repair and recovery

Bevollmächtigter für die Zusammenstellung der techn. Unterlagen:

Authorized representative in charge of administering technical documentation: Hr. Torsten Kauschke, im Hause / on the manufacturer's premises as defined above

Die Konformitätserklärung wurde ausgestellt

The declaration of conformity was issued and valid of

Seelbach, 05.10.2017

M. Juchheim, Geschäftsführer / Managing Director

2017_014_F34-Kältegerät_d_e.docx

Hersteller / Manufacturer:

JULABO GmbH

Gerhard-Juchheim-Straße 1 77960 Seelbach / Germany Tel: +49(0)7823 / 51 - 0

Hiermit erklären wir, dass das nachfolgend bezeichnete Produkt

We hereby declare, that the following product

Produkt / Product: Kältegerät / Refrigeration Unit

Typ / Type: FP50, FPW50 Serien-Nr. / Serial-No.: siehe Typenschild / see type label

aufgrund seiner Konzipierung und Bauart in der von uns in Verkehr gebrachten Ausführung den grundlegenden Sicherheits- und Gesundheitsanforderungen den nachfolgend aufgeführten EG-Richtlinien entspricht. due to the design and construction, as assembled and marketed by our Company - complies with fundamental safety and health requirements according to the following EC-Directives.

Maschinenrichtlinie 2006/42/EG; Machinery Directive 2006/42/EC EMV-Richtlinie 2014/30/EU; EMC-Directive 2014/30/EU RoHS-Richtlinie 2011/65/EU; RoHS-Directive 2011/65/EU

Angewandte harmonisierte Normen und techn. Spezifikationen:

The above-named product is in compliance with the following harmonized standards and technical specifications:

EN 50581: 2012

Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

EN ISO 12100 : 2010

Sicherheit von Maschinen - Allgemeine Gestaltungsleitsätze - Risikobeurteilung und Risikominderung (ISO 12100:2010) Safety of machinery - General principles for design - Risk assessment and risk reduction (ISO 12100:2010)

EN 61010-1: 2010

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 1: Allgemeine Anforderungen Safety requirements for electrical equiment for measurement, control, and laboratory use, Part 1: General requirements

EN 61010-2-010: 2014

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte, Teil 2-010: Besondere Anforderungen an Laborgeräte für das Erhitzen von Stoffen Safety requirements for eletrical equipment for measurement, control, and laboratory use, Part 2-010: Particular requirements for laboratory equipment for the heating materials

EN 61326-1: 2013

Elektrische Mess., Steuer, Regel- und Laborgeräte- EMV-Anforderungen- Teil 1: Altgemeine Anforderungen Electrisch equipment for measurement, control, and laboratory use - EMC requirements - Part 1: General requirements

EN 378-1: 2016

Kälteanlagen und Wilmrepumpen – Sichetheitstechnische und umweltrelevante Anforderungen – Teil 1: Grundlegende Anforderungen, Begriffe, Rassifikationen und Auswahlkriterien Refrigeraling systems and heat pumps - Safety and environmental requirements - Part 1: Basics requirements; definitions, classification and selection criteria.

EN 378-2: 2016

Kälteerlagen und Wärmepumpen – Sicherheitstechnische und umweitrelevante Anforderungen – Teil 2: Konstruktion, Herstellung, Prüfung, Kennzeichnung und Dokumentation Befrigerating systems and heat pumps - Safety and environmental requirements - Part 2: Design, construction, testing, marking and documentation

Kälteanlagen und Wärmepumpen – Sicherheitstechnische und umweltretevante Anforderungen – Teil 3: Aufstellungson und Schutz von Personen Refrigerating systems and heat pumps - Safety and environmental requirements - Parl 3: Installation site and personal protection

EN 378-4: 2016

Kälteanlagen und Wärmepumpen – Sicherheitstechnische und umweltrelevante Anforderungen – Teil 4: Betrieb, Instandhaltung, Instandsetzung und Rückgewinnung Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, repair and recovery

Bevollmächtigter für die Zusammenstellung der techn. Unterlagen:

Authorized representative in charge of administering technical documentation: Hr. Torsten Kauschke, im Hause I on the manufacturer's premises as defined above

Die Konformitätserklärung wurde ausgestellt

The declaration of conformity was issued and valid of

Seelbach, 05.10.2017

M. Juchheim, Geschäftsführer / Managing Director

2017 020 FP(W)50-Kältegerät d e.docx

2.4. **Technical specifications**

		-	F25-HE	F32-HE
Working temperature range		°C	-28 200	-35 200
Temperature stability		°C	±0,01	±0,01
Cooling capacity Medium: ethanol		°C kW	<u>+20 0 -20</u> 0.26 0.2 0.06	<u>+20 0 -20 -30</u> 0.45 0.39 0.15 0.06
Refrigerant			R134a	R134a
Overall dimensions	(WxDxH)	cm	23x42x64	31x42x64
Bath opening	(WxL)	cm	12x14	18x12
Bath depth		cm	14	15
Filling volume		liters	3 4,5	5,5 8
Weight		kg	32	38
Mains power connection	Z	V/ Hz	230/50	230/50
Current draw	(at 230 V)	Α	12	12
Current draw CH	(at 230 V)	Α	2	-
Mains power connection		V/ Hz	230/50/60	230/50/60
Current draw	(at 230 V)	Α	12	12
Current draw CH	(at 230 V)	Α	-	2
Mains power connection		V/ Hz	115/60	115/60
Current draw	(at 115 V)	Α	13	14
Mains power connection		V/ Hz	100/50/60	100/50/60
Current draw	(at 100 V)	А	13	14

			FP34-HE
Working temperature range		°C	-30 150
Temperature stability		°C	±0.01
Cooling capacity		°C	<u>+20 0 -20 -30</u>
Medium: ethanol		kW	0.45 0.32 0.14 0.03
Refrigerant			R134a
Overall dimensions	(WxDxH)	cm	38x58x64
Bath opening	(WxL)	cm	24x30
Bath depth		cm	15
Filling volume		liters	14 20
Weight		kg	44
_			
Mains power connection		V/Hz	230/50
Current draw	(at 230 V)	Α	12
Current draw GB, CH			
Mains power connection		V/ Hz	230/60
Current draw	(at 230 V)	Α	13
Mains power connection		V/ Hz	115/60
Current draw	(at 115 V)	А	14

			FP50-HE 50 Hz	FP50-HE 60 Hz
Working temperature range		°C	-50 200	-50 200
Temperature stability		°C	±0.01	±0.01
Cooling capacity Medium: ethanol		°C kW	<u>+20 0 -20 -40</u> 0.9 0.8 0.46 0.14	<u>+20 0 -20 -40</u> 0.9 0.8 0.5 0.16
Refrigerant			R452A	R404A/R507
Overall dimensions	(WxDxH)	cm	42x49x72	42x49x72
Bath opening	(WxL)	cm	18x12	18x12
Bath depth		cm	20	20
Filling volume		liters	5.5 8	5.5 8
Weight		kg	57	57
Maina nawar connection		\//Ы¬	220/50	220/60
Mains power connection Current draw	(at 230 V)	V/Hz A	230/50 14	230/60 14
Current draw CH	(at 230 V)	A	9+4	9+4

		-	-	-
			FPW50-HE	FPW50-HE
			50 Hz	60 Hz
Working temperature range		°C	-50 200	-50 200
Temperature stability		°C	±0.01	±0.01
Cooling capacity		°C	+20 0 -20 -40	+20 0 -20 -40
Medium: ethanol		kW	0.9 0.8 0.49 0.11	0.9 0.8 0.5 0.16
Refrigerant			R452A	R404A/R507
Overall dimensions	(WxDxH)	cm	42x49x72	42x49x72
Bath opening	(WxL)	cm	18x12	18x12
Bath depth		cm	20	20
Filling volume		liters	5.5 8	5.5 8
Weight		kg	57	57
Mains power connection		V/Hz	230/50	230/60
Current draw	(at 230 V)	Α	14	14
Current draw CH	(at 230 V)	А	9+4	9+4

			HE
Temperature selection			digital
via keypad			indication on VFD COMFORT-DISPLAY
remote control via PC			indication on monitor
Temperature indication			VFD COMFORT-DISPLAY
Resolution		°C	0.01
ATC3	INT/EXT	°C	±3/±9
Temperature control	Temperature control		ICC - Intelligent Cascade Control
Heater wattage (at 230 V)		kW	2,0
Heater wattage (at 115 V)		kW	1,0
Electronically adj. pump capacity	stages		1 4
Flow rate at 0 bar		l/min	22 26
Max. pressure at 0 liters		bar	0.7
Max. suction at 0 liters		bar	0.4
Electrical connections:	Electrical connections:		See page 17
Ambient temperature		°C	5 40

All measurements have been carried out at: rated voltage and frequency ambient temperature: 20 °C Technical changes without prior notification reserved.

Electrical connections:

External alarm device 24-0 V DC/max. 25 mA

Computer interface RS232 or RS485

External Pt100 sensor

Optional for HE, SE

(Order No. 8900100 Electronic module with analog connections)

Programmer input -100 °C to 400 °C = 0 - 10 V or 0 - 20 mA or 4 - 20 mA

Input for the signal of a flow meter or external manipulated variable

 $0 - 10 \text{ V} (0 \text{ V} = -100 ^{\circ}\text{C}, 10 \text{ V} = 400 ^{\circ}\text{C})$ Temperature recorder outputs

> $0 - 20 \text{ mA} (0 \text{ mA} = -100 ^{\circ}\text{C}, 20 \text{ mA} = 400 ^{\circ}\text{C})$ $4 - 20 \text{ mA} (4 \text{ mA} = -100 ^{\circ}\text{C}, 20 \text{ mA} = 400 ^{\circ}\text{C})$

Standby input for external emergency switch-off

Alarm output for external alarm signal

Safety installations according to IEC 61010-2-010:

Excess temperature protection adjustable from 0 °C ... 320 °C

Low liquid level protection float switch Classification according to DIN 12876-1 class III

Supplementary safety installations

Early warning system for low level float switch

High temperature warning function optical + audible (in intervals) Low temperature warning function optical + audible (in intervals)

Supervision of working sensor plausibility control

Reciprocal sensor monitoring between

working and safety sensors difference >35 K

Alarm message optical + audible (permanent) Warning message optical + audible (in intervals)

Environmental conditions according to IEC 61 010-1:

Use indoors only.

Altitude up to 2000 m - normal zero.

Ambient temperature: see Technical specifications

Humidity:

Max. relative humidity 80% for temperatures up to +31 °C,

linear decrease down to 50% relative humidity at a temperature of +40 °C

Max. mains voltage fluctuations of ±10% are permissible.

Protection class according to IEC 60 529 IP21 The unit corresponds to Class Ш Overvoltage category Pollution degree 2



Caution:

The unit is not suitable for use in explosive environment

EMC requirements

The device is an ISM device of group 1 per CISPR 11 (uses HF for internal purposes) and is classified in class A (industrial and commercial sector).

Notice:

- Devices of class A are intended for the use in an industrial electromagnetic
- When operating in other electromagnetic environments, their electromagnetic compatibility may be impacted.
- This device is not intended for the use in living areas and cannot guarantee adequate protection of the radio reception in such environments.

Information about the used refrigerants

The Regulation (EU) No. 517/2014 on fluorinated greenhouse gases applies to all systems which contain fluorinated refrigerants and replaces (EC) 842/2006.

The aim of the Regulation is to protect the environment by reducing emissions of fluorinated greenhouse gases.

Among other things it regulates the emission limits, use and recovery of these substances. It also contains requirements for operators of systems which require/contain these substances to function.

Under Regulation 517/2014, the operator of a system of this nature has the following duties:

- The operator must ensure that the equipment is checked at regular intervals for leaks.
- These intervals depend on the CO₂ equivalent of the system. This is calculated from the refrigerant fill volume and type of refrigerant. The CO₂ equivalent of your system is shown on the model plate.
- The operator undertakes to have maintenance, repair, service, recovery and recycling work carried out by certified personnel who have been authorized by JULABO.
- All such work must be documented. The operator must keep records and archive them for at least five years. The records must be submitted to the relevant authority on request.

Refer to the text of the Regulation for further information.

2.5. Cooling water connection

Cooling water pressure (IN/OUT) max. 6 bar

Difference pressure (IN - OUT) 3.5 to 6 bar

<20 °C Cooling water temperature

Recommended quality of cooling water:

pH – value	7,5 to 9,0
Sulfate [SO4 2-]	< 100 ppm
Hydrocarbonate [HCO3-]/Sulphate [SO4 2-]	> 1 ppm
Hardness [Ca2+, Mg2+]/[HCO3-]	> 0,5 dH
Alkalinity	60 ppm < [HCO3-] < 300 ppm
Conductivity	< 500 µs/cm
Chloride (CL-)	< 50 ppm
Phosphate (PO43-)	< 2 ppm
Ammonia (NH3)	< 0,5 ppm
Free Chlorine	< 0,5 ppm
Ferri lons (Fe3+)	< 0,5 ppm
Mangano Ions (Mn2+)	< 0,05 ppm
Carbon dioxide (CO2)	< 10 ppm
Hydrosulfide (H2S)	< 50 ppm
Content of oxygen	< 0,1 ppm
Algae growth	impermissible
Suspended solids	impermissible



Notice:

Danger of corrosion of heat exchanger due to unsuitable quality of cooling

- Due to its high content of lime hart water is not suitable for cooling and causes calcination of the heat exchanger.
- Ferrous water or water containing ferrous particles will cause formation of rust even in heat exchangers made of stainless steel.
- Chlorous water will cause pitting corrosion in heat exchangers made of stainless steel.
- Due to its corrosive characteristics distilled and deionized water is unsuitable and will cause corrosion of the bath. .
- Due to its corrosive characteristics sea water is not suitable.
- Due to its microbiological (bacteria) components which settle in the heat exchanger untreated and unpurified river water and water from cooling towers is unsuitable.
- Avoid particulate matter in cooling water.
- Avoid putrid water.



Cooling water circuit

Risk of oil leaking from the cooling circuit (compressor) of the recirculating cooler into the cooling water in case of a fault in the circuit!

Observe the laws and regulations of the water distribution company valid in the location where the unit is operated.

Operating instructions

3. Safety notes for the user

3.1. Explanation of safety notes



In addition to the safety warnings listed, warnings are posted throughout the operating manual. These warnings are designated by an exclamation mark inside an equilateral triangle. "Warning of a dangerous situation (Attention! Please follow the documentation)."

The danger is classified using a signal word.

Read and follow these important instructions for averting dangers.



Warning:

Describes a **possibly** highly dangerous situation. If these instructions are not followed, serious injury and danger to life could result.



Caution:

Describes a **possibly** dangerous situation. If this is not avoided, slight or minor injuries could result. A warning of possible property damage may also be contained in the text.



Notice:

Describes a **possibly** harmful situation. If this is not avoided, the product or anything in its surroundings can be damaged.

3.2. Explanation of other notes



Note!

Draws attention to something special.



Important!

Indicates usage tips and other useful information.

This icon is used in the operating instructions to indicate flashing values or parameters which have to be set or confirmed.

3.3. Safety recommendations

Follow the safety instructions to avoid personal injury and property damage. Also, the valid safety instructions for workplaces must be followed.



- Only connect the unit to a power socket with an earthing contact (PE protective earth)!
- The power supply plug serves as a safe disconnecting device from the line and must always be easily accessible.
- Place the unit on an even surface on a base made of nonflammable material.
- Do not stay in the area below the unit.
- Make sure you read and understand all instructions and safety precautions listed in this manual before installing or operating your unit.
- Adjust excess-temperature safety device below the flash point of the bath fluid.
- Observe the limited working temperature range when using plastic bath tanks.
- Never operate the unit without bath fluid in the bath.
- Pay attention to the thermal expansion of bath oil during heating to avoid overflowing of the fluid.
- Prevent water from entering the hot bath oil.
- Do not drain the bath fluid while it is hot! Check the temperature of the bath fluid prior to draining (e.g., by switching the unit on for a short moment).
- Use suitable connecting tubing.
- Avoid sharp bends in the tubing, and maintain a sufficient distance from surrounding walls.
- Make sure that the tubing is securely attached.
- Regularly check the tubing for material defects (e.g., for cracks).
- Never operate damaged or leaking units.
- Always turn off the unit and disconnect the mains cable from the power source before performing any service or maintenance procedures, or before moving the
- Always turn off the unit and disconnect the mains cable from the power source before cleaning the unit.
- Always empty the bath before moving the unit.
- Transport the unit with care.
- Sudden jolts or drops may cause damage in the interior of the unit.
- Observe all warning labels.
- Never remove warning labels.
- Never operate units with damaged mains power cables.
- Repairs are to be carried out only by qualified service personnel.



Some parts of the bath tank and the pump connections may become extremely hot during continuous operation. Therefore, exercise particular caution when touching these parts.



Caution:

The temperature controlling i.e. of fluids in a reactor constitutes normal circulator

We do not know which substances are contained within these vessels. Many substances are:

- inflammable, easily ignited or explosive
- hazardous to health
- environmentally unsafe

i.e.: dangerous

The user alone is responsible for the handling of these substances! The following questions shall help to recognize possible dangers and to reduce the risks to a minimum.

- Are all tubes and electrical cables connected and installed? Note:
 - sharp edges, hot surfaces in operation, moving machine parts, etc.
- Do dangerous steams or gases arise when heating? Is an exhaust needed when working?
- What to do when a dangerous substance was spilled on or in the unit? Before starting to work, obtain information concerning the substance and determine the method of decontamination.





Notice: Check the safety installations at least twice a year!

- Excess temperature protection according to IEC 61010-2-010. With a screwdriver turn back the adjustable excess temperature protection until the shut-down point (actual temperature).
- Low level protection according to IEC 61010-2-010. To check the function of the float, it can be manually lowered with a screwdriver for example.

Operating controls and functional elements

Front view





1a 1b



Mains power switch, illuminated for circulator

Mains power switch, illuminated for cooling machine

2



VFD COMFORT-DISPLAY

Header: Control indicators

Line 1: Actual value internal or external

The display is depending on the selected control mode in the

menu > Control < (internal or external).

Line 2: Working temp. setpoint, constantly S xxx.xx

Line 3: Actual value (E = external or I = internal)

Alternating with the display in line 1

Use the keys to indicate further values in line 3

PI Capacity in % - with manipulated variable set to >control<* PS Capacity in % - with manipulated variable set to >serial<* or >eprog<*

Heater capacity in Watts

U Mains voltage Volts

Flow rate in liters/minute (providing EPROG input set to >Flowrate<)

*refer to >MENU/CONFIG< → >CONFIG/ACTVAR>

2.1



Control indicators in the header:

Heating/Cooling/Alarm /

Remote control

2.2



Control indicators in the header:

Temperature indication Internal or External actual value Temperature indication in °C (°F not possible on this unit)

2.3



Display of set pump pressure stage

Four stages, can be set via the key



MENU , under >MENU - PUMP<.

4

Navigation keys

4.1



Start/Stop (pump/heater) 1. Key: >OK<

2. >OK< in the menu Menu item/select submenu for setting Save set value

Save selected parameter

A beep signals the end of setting



After the actions Start, Stop and change from VFD Display to standard display the key **OK** is locked for a short time.

The above graph "front side" shows an example for standard display.

4.2



1. Key: >Return< Stop (pump/heater)

2. >Return< in the menu one menu level down Correction function for parameters or values (prior to OK) immediately back to standard display OK D - D icon for "keep key pressed down". 1. Key: >Up/Down -temperature – increase/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down 1. Key: >Up/Down -temperature – increase/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down 1. Key: start the menu selection of menu items/parameters Menu keys 4.4 Key: start the menu > warning and safety values< 4.5 Key: display of MENU structure 6 Menu Key: display of MENU structure 6 Menu Key: display of MENU structure 7 Socket for external measurement and control sensor or external setpoint programming 8 O CONTROL OF SERIAL 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM 11 Standby input (for external emergency switch-off) STAND-BY 12 Programmer input and temperature recorder output REG+E-PROG	Correction function for parameters or values (prior to OK) OK D immediately back to standard display OK D OK D icon for "keep key pressed down". 1. Key: >Up/Down < temperature – increase/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down Menu keys 4.4 Key: start the menu > warning and safety values< Key: start the menu > temperature setpoints< 4.6 MENU Key: display of MENU structure 6 MENU Key: display of MENU structure 7 Socket for external measurement and control sensor or external setpoint programming 8 OCCUPO SERIAL 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 10 Alarm output (for external alarm signal) ALARM 11 Standby input (for external emergency switch-off) STAND-BY 12 Programmer input and temperature recorder output			
Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Alarm output (for external alarm signal) ALARM 1. Key: JUp/Down ctemperature increases/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. JUp/Down ctemperature setpoin from the menu items/parameters Menu keys Key: start the menu > warning and safety values < 4.5 Key: start the menu > temperature setpoints < 4.6 MENU Key: display of MENU structure Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 ALARM 11 Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	A.3 1. Key: >Up/Down < temperature - increase/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down < in the menu selection of menu items/parameters Menu keys			
1. Key: >Up/Down < temperature — increase/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down < in the menu selection of menu items/parameters Menu keys	1. Key: >Up/Down < temperature - increase/decrease setpoint Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down < in the menu selection of menu items/parameters Menu keys			immediately back to standard display
Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down< in the menu selection of menu items/parameters Menu keys	Push key quickly for single steps, Keep key pressed for fast change. 2. >Up/Down< in the menu selection of menu items/parameters Menu keys			OK (P) - (5) (P) icon for "keep key pressed down".
Menu keys	Menu keys	4.3	•	Push key quickly for single steps, Keep key pressed for fast change.
4.5	4.5 Key: start the menu > warning and safety values< 4.5 Key: start the menu > temperature setpoints < 4.6 MENU Key: display of MENU structure 6 Socket for external measurement and control sensor or external setpoint programming 8 Socket for external measurement and control sensor or external setpoint programming 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 10 Alarm output (for external alarm signal) ALARM 11 Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output			2. >Up/Down< in the menu selection of menu items/parameters
4.5 T Key: start the menu >temperature setpoints< 4.6 MENU Key: display of MENU structure 6 Adjustable excess temperature protection according to IEC 61010-2-010 7 Socket for external measurement and control sensor or external setpoint programming 8 OCHEC OF SERIAL Interface RS232: remote control via personal computer SERIAL 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 10 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY 12 Programmer input and temperature recorder output	4.5 Key: start the menu >temperature setpoints< 4.6 MENU Key: display of MENU structure 6 Adjustable excess temperature protection according to IEC 61010-2-010 7 Socket for external measurement and control sensor or external setpoint programming 8 OCCURRENCE OF SERIAL 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 10 Alarm output (for external alarm signal) ALARM 11 Standby input (for external emergency switch-off) STAND-BY 12 Programmer input and temperature recorder output			Menu keys
4.6 MENU Key: display of MENU structure 6 Adjustable excess temperature protection according to IEC 61010-2-010 7 Socket for external measurement and control sensor or external setpoint programming 8 OSERIAL Interface RS232: remote control via personal computer SERIAL 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 10 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	4.6 MENU Key: display of MENU structure Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Interface RS232: remote control via personal computer SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	4.4		Key: start the menu > warning and safety values<
Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Interface RS232: remote control via personal computer SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Interface RS232: remote control via personal computer SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	4.5		Key: start the menu >temperature setpoints<
Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Interface RS232: remote control via personal computer SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	Adjustable excess temperature protection according to IEC 61010-2-010 Socket for external measurement and control sensor or external setpoint programming Interface RS232: remote control via personal computer SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	4.6	MENU	Key: display of MENU structure
or external setpoint programming Interface RS232: remote control via personal computer SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	or external setpoint programming 8	6	40 \$ 320	Adjustable excess temperature protection according to IEC 61010-2-010
SERIAL Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	SERIAL 9 Socket: control cable of JULABO refrigerated circulator or output for alarm messages Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM 11 Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	7	ext Pt100	
Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	Option: Electronic module Order No. 8 900 100 Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	8		Interface RS232: remote control via personal computer
Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	Alarm output (for external alarm signal) ALARM Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	9	*	
ALARM 11 Standby input (for external emergency switch-off) STAND-BY 12 Programmer input and temperature recorder output	ALARM 11 Standby input (for external emergency switch-off) STAND-BY 12 Programmer input and temperature recorder output	Option	n: Electronic mod	ule Order No. 8 900 100
Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	Standby input (for external emergency switch-off) STAND-BY Programmer input and temperature recorder output	10		Alarm output (for external alarm signal)
12 Programmer input and temperature recorder output	12 Programmer input and temperature recorder output	11		Standby input (for external emergency switch-off)
		12		Programmer input and temperature recorder output



16a

16b

Mains fuses for circulator, T16A

Mains fuses for cooling machine, T10A

Operating controls and functional elements

FPW 24

17a		Mains power cable with plug for circulator	
17b		Mains power cable with plug cooling machine	
40			
18		Built-in mains outlet for connection of circulator	
19	00	Drain screw with drain connection	
	\$ 3		
20		Venting grid, removable	
21		1 4	
22		Pump connectors 🏻 suction pump 🖒 pressure pump	
23	- 1	0.1	
23	Ø- o	Selector dial for cooling machine (only F25, F34) Position "1" for operation with HE circulator.	
		·	
24	81	OUT IN	
27	900000	Å 	
	8 2 0	Φ Φ	
		Cooling water OUTLET and INLET.	

5. **Preparations**

5.1. Installation

Place the unit on an even surface on a pad made of nonflammable material.

F34: The circulator fitted with a stainless steel bridge is placed on on the back of the bath tank leaving the bath open on the front side.

The place of installation should be large enough and provide sufficient air ventilation to ensure the room does not warm up excessively because of the heat the instrument radiates to the environment. (Max. permissible ambient temperature: 40 °C).

With regard to a disturbance in the cooling loop (leakage), the guideline EN 378 prescribes a certain room space to be available for each kg of refrigerant.

The necessary amount of refrigerant is specified on the type plate.

- > For 0.25 kg of refrigerant R134a, a room space of 1 m³ is required.
- > For 0.52 kg of refrigerant R404A, a room space of 1 m³ is required.
- > For 0.49 kg of refrigerant R507, a room space of 1 m³ is required.
- > For 0.423 kg of refrigerant R452A, a room space of 1 m³ is required.

- Set selector dial for cooling machine in position "1" for operation with HE circulator. $\bigcirc -0$ (only F25, F34)
- Keep at least 20 cm of open space on the front and rear venting grid.
- Do not set up the unit in the immediate vicinity of heat sources and do not expose to sun light
- Before operating the unit after transport, wait about one hour after setting it up. This will allow any oil that has accumulated laterally during transport to flow back down thus ensuring maximum cooling performance of the compressor.



Only water cooled models:

Ensure circulation of cooling water by connecting the tubing to cooling water inlet and outlet on the rear of the refrigerated circulator.

- Cooling water connecter G¾"
- Cooling water see page 19

5.2. **Bath fluids**



Caution:

Carefully read the safety data sheet of the bath fluid used, particularly with regard to

If a bath fluid with a fire point of ≤65 °C is used, only supervised operation is possible.

Water: The quality of water depends on local conditions.

- Due to the high concentration of lime, hard water is not suitable for temperature control because it leads to calcification in the bath.
- Ferrous water can cause corrosion even on stainless steel.
- Chloric water can cause pitting corrosion.
- Distilled and deionized water is unsuitable. Their special properties cause corrosion in the bath, even in stainless steel.

Recommended bath fluids:

Bath fluid	Temperature range
soft/decalcified water	5 °C to 80 °C
mixture water/glycol, mixture 1:1	-20°C to 50°C

JULABO bath fluids

JULABO		Thermal	Thermal	Thermal
Description		G	HY	H5
Order Number	10 liters	8 940 124	8 940 104	8 940 106
	5 liters	8 940 125	8 940 105	8 940 107
Temperature range	°C	-30 80	-80 55	-50105
Flash point	°C		78	124
Fire point	°C		80	142
Color		light yellow	clear	clear

JULABO		Thermal	Thermal
Description		H10	H20S
Order Number	10 liters	8 940 114	8 940 108
	5 liters	8 940 115	8 940 109
Temperature range	°C	-20 180	0 220
Flash point	°C	190	230
Fire point	°C	216	274
Color		clear	light brown



See website for list of recommended bath fluids.

ATTENTION: The maximum permissible viscosity is 70 mm²/s·



Caution:

Fire or other dangers when using bath fluids that are not recommended:

Use only nonacidic and noncorrosive bath fluids.

JULABO assumes no liability for damage caused by the selection of an unsuitable bath liquid.

Unsuitable bath fluids are fluids which, e.g.,

- are highly viscous (much higher than recommended at the respective working temperature)
- have a low viscosity and have creep characteristics
- have corrosive characteristics or
- tend to crack.
- No liability for use of other bath fluids!


5.3. Temperature application to external systems



Caution: Securely attach all tubing to prevent slipping.

If the circulator is operated without external system, close the pump connector (22) with the cap nut.


Temperature application to external, closed systems



The circulator is used for temperature application to external, closed systems (loop circuit) with simultaneous temperature application in the circulator bath.

- Unscrew the M16x1 collar nuts on the pump connectors with a 19 mm (3/4") wrench and remove the sealing disks. Using the collar nuts, screw on the tubing connection fittings (for tubing 8 mm or 12 mm in diameter) delivered with the unit and tighten firmly. (Pressure pump: 22, suction pump: 21)
- Push on the tubings, and secure with tube clamps.
- Attach the tubings to the connectors of the external closed system, e.g., an instrument with a pressure-resistant temperature jacket or a temperature coil, and fasten with tube clamps to prevent slipping.

Temperature application to external, open systems



S = Suction pump connection

D = Pressure pump connection

K = Float

H = Height adjustment

The circulator is equipped with both a pressure and suction pump for external temperature application in open systems.

Differing flow rates of the pressure and suction pumps should be compensated. To maintain a constant liquid level, the JULABO "D+S" Level Adapter is recommended for the external bath tank. The flow rate of the pressure pump will be then regulated by a built-in float device. The liquid level may be changed by a height adjustment on the "D+S" Level Adapter.

Accessory: "D+S" Level Adapter Order No. 8 970 410

Important:

- The liquid level should be equal in the internal and external baths (absolute height).
- i) If you take out samples (for example Erlenmeyer flasks) from the external bath, turn the circulator off with the Start/Stop key.

Return flow safety device

If the liquid levels in the circulator bath and the external system are at different heights, overflowing must be prevented after the power has been turned off.



Flood hazard!

For this reason, shut-off valves can be integrated in the loop circuit.

Order No.	Description
8 970 456	Shut-off valve (suitable up to +90 °C)
8 970 457	Shut-off valve (suitable up to +200 °C)

5.3.1. **Tubing**

Recommended tubing:

Order No.	Length			Temperature range
8930008	1 m	CR® tubing	8 mm inner dia.	-20 °C to 120 °C
8930012	1 m	CR® tubing	12 mm inner dia.	-20 °C to 120 °C
8930108	1 m	Viton tubing	8 mm inner dia.	-35 °C to 200 °C
8930112	1 m	Viton tubing	12 mm inner dia.	-35 °C to 200 °C
8930410	1 m	Insulation for tubing	8 mm inner dia.	-50 °C to 100 °C
8930412	1 m	Insulation for tubing	12 mm inner dia.	-50 °C to 100 °C
8 930 209	0.5 m	Metal tubing, triple in	nsulated, M16x1	-100 °C to +350 °C
8 930 210	1.0 m			
8 930 211	1.5 m			
8 930 214	3.0 m			
8 930 220	0.5 m	Metal tubing, insulate	ed, M16x1	-50 °C to +200 °C
8 930 221	1.0 m			
8 930 222	1.5 m			
8 930 223	3.0 m			



Warning: Tubing:

At high working temperatures the tubing used for temperature application and cooling water supply represents a danger source.

A damaged tubing line may cause hot bath fluid to be pumped out within a short time. This may result in:

- Burning of skin
- Difficulties in breathing due to hot atmosphere

Safety recommendations


- Employ suitable connecting tubing.
- Make sure that the tubing is securely attached.
- Avoid sharp bends in the tubing, and maintain a sufficient distance from surrounding walls.
- Regularly check the tubing for material defects (e.g. for cracks).
- Preventive maintenance: Replace the tubing from time to time.

5.4. Filling/draining



Notice:


- Pay attention to the thermal expansion of bath oil during heating to avoid overflowing of the liquid.
- Do not drain the bath fluid while it is hot! Recommendation: Temperature range 5 °C to 40 °C Check the temperature of the bath fluid prior to draining (by switching the unit on for a short moment, for example).
- Store and dispose the used bath fluid according to the laws for environmental protection.



Filling

Take care that no liquid enters the interior of the circulator.

- Recommended maximum filling level with water as bath fluid: 30 mm below the tank rim
- Recommended maximum filling level with bath oils: 40 mm below the tank rim
- (i) After filling, immerse the samples in the bath or place the lid on the bath, in case the opening is not to be used.
- The circulator provides an early warning system for low level that may be triggered when changing samples in the bath.



Draining

- Turn off the circulator and cooling machine.
- Hold the venting grid, pull out and remove.
- Slide a short piece of tube onto the drain port (11) and hold it into a pail.
- Unscrew the drain tap (23) and empty the unit completely.
- Tighten the drain tap.

6. Operating procedures

6.1. Power connection



Caution:

- Only connect the unit to a power socket with earthing contact (PE protective earth)!
- The power supply plug serves as safe disconnecting device from the line and must be always easily accessible.
- Never operate equipment with damaged mains power cables.
- Regularly check the mains power cables for material defects (e.g. for cracks).
- We disclaim all liability for damage caused by incorrect line voltages!

Check to make sure that the line voltage matches the supply voltage specified on the identification plate. Deviations of ±10 % are permissible.

- Connect the circulator with mains power cable (17a) to the mains outlet (18).
- Connect the control cable (9) between the connectors * (9a, 9b).
- Connect the refrigerated circulator with mains power cable (17b) to the mains socket.

6.2. Switching on/Start - Stop

6.2.1. Switching on the circulator



Switching on:

- Turn on the mains power switch (1).
- (i) The unit performs a self-test. Then the software version (example: V 1.xx) appears. The display "OFF" or "R OFF" indicates the unit is ready to operate.
- (i) The circulator enters the operating mode activated before switching the circulator off:

keypad control mode (manual operation)

remote control mode (operation via personal computer).



Start:

Press **OK** key. The actual bath temperature is displayed on the VFD COMFORT-DISPLAY. The circulating pump starts with a slight delay.

Stop:

(i) Press or Keep (1) key pressed. The VFD COMFORT-DISPLAY indicates the message "OFF".



6.2.2. Switching on the Cooling Machine



Switching on:

• Switch on the cooling machine using the switch (1b) .



(i) Control of the cooling machine:

With the mains switch (1b) turned on, the circulator automatically switches the cooling machine off and on.

- It is switched off, if:
 - the actual working temperature is increased by >30 °C (cooling is not required).
 - the heater operates at full power (>800 W) for longer than 5 minutes.
- It is switched on, if:
 - cooling is necessary for maintaining the bath temperature. After switch-off, the cooling machine automatically switches on only after a delay of 5 minutes for protecting the cooling compressor.



To save energy, turn off the cooling machine with the mains switch (1b) whenever cooling is not required.

7. Setting of temperatures

7.1. Using the pre-settings in the

key to call up the menu for temperature selection. 3 different working temperatures can be adjusted. Their values are freely selectable within the operating temperature range.

- The temperatures can be set in start or stop mode.
- (i) Press (iii) key if a value is to be retained

Setting of working temperature in the


1. Press the key T. The value flashes


Werkseinstellungen: SETPNT 1 25 °C 37 °C SETPNT 2 SETPNT 3 70°C

- Select SETPOINT 1 or 2 or 3 using the key or
- 3. Confirm by pressing the **OK** key.
- (i) The circulator uses the new working temperature value for temperature control.

Example: Adjustment/modification of the pre-setting of "SETPOINT 3"

1. Press the \tag{T} key.





4. Adjust value by pressing the key and the key to 85.00 °C and confirm by pressing the **OK** key. The decimal digits flash \\\ and can be adjusted if desired.

Confirm once more by pressing the **OK** key. Example on the left: SETPNT 3/85.00.

(i) If the active setpoint (SETPNT) is changed, the new value is immediately used for the control of the working temperature. The heater control indicator flashes.

(i) If the other two setpoints (not activated for control) are changed the MENU has to be left by pressing the (5) key after the decimal digits have been confirmed



Notice: Refer to SETPOINT MAX/MIN in chapter 9.8. **MENU LIMITS**

SSS

Direct setting of temperatures



The circulator uses the setpoint of SETPNT 1 or 2 or 3 for temperature control


The indicated setpoint temperature can be changed directly any time. Example: change 25.00 °C to 50.00 °C



By pressing the key ____ the circulator switches to the active SETPOINT< example on the left: >SETPNT/1 25.00°C<.

The integer digits flash \\ (example: <25>).

2. By pressing the keys and the value is changed to 50.00 °C and is confirmed by pressing the **OK** key. The decimal digits flash and can be adjusted if desired. Confirm once more by pressing the **OK** key.



The temperatures can be set in start or stop mode.



8.

Safety installations, warning functions



Check the safety installations at least twice a year! Refer to (page 22)

SECVAL (Security Values)

SAFETMP

AL-TYPE

OVERTMP

SUBTEMP

Settings for the excess temperature protection > **SAFETMP**< and for the warning functions for high > OVERTMP< and low > **SUBTEMP**< temperature are made in a menu which is called up by

pressing the key

Menu item > AL-TYPE< allows choosing between a warning and an alarm cut-off for the menu items > OVERTMP< and > SUBTEMP<.

8.1. **Excess temperature protection**



Warning:

Adjust excess-temperature safety device below the flash point of the bath fluid. In case of wrong setting there is a fire hazard! We disclaim all liability for damage caused by wrong settings!



This excess temperature protection is independent of the control circuit. When activated heater and circulating pump are completely shut down. The alarm is indicated by optical and audible signals (continuous tone) and the error message "ALARM-CODE 14" appears on the VFD COMFORT-DISPLAY together with the ticker: > EXCESS TEMPERATURE PROTECTOR ALARM-CHECK ADJUSTMENT <





Setting range: 20 °C ... 320 °C

(i) Rough setting can be effected by using the temperature scale.

Exact setting:

Press the key to display menu >SAFETMP<.









Recommendation:


Set the excess temperature protection at 5 °C to 10 °C above the working temperature setpoint.

8.1.1. Early warning system, low level protection



This low level protection is independent of the control circuit and is divided into two sections:

1. Switch in stage 1 recognizes a defined fluid level 🕒. An audible warning sounds (interval tone) and together with the ticker: > LOW LEVEL WARNING-FILL MEDIUM < a message appears on the VFD COMFORT-DISPLAY:





Refill the bath fluid!

2. Switch in stage 2 recognizes a low fluid level 😊. If stage 2 of the low level protection according to IEC 61010-2-010 is triggered, a complete, all-pole shutdown of heater and circulating pump is effected A continuous alarm sounds and together with the ticker: > LOW

LEVEL ALARM-FILL MEDIUM < a message appears on the VFD COMFORT-DISPLAY:



Turn off the unit with the mains switch, refill bath fluid and turn the unit on again!

- 3. Float
- 4. Circulating pump
- 5. Heater



Warning:

When adding bath fluid, always us the type of fluid which is identical with the fluid in

Bath oils must not contain any water and should be pre-heated approximately to the current bath temperature! Explosion hazard at high temperatures!

8.2. Switch-over from warning to shutdown function

SEEVAL AL - TYPE If a shutdown of functional elements (e.g. heater, circulating pump) is required when the limit values are exceeded or undercut the circulator can be changed over from warning function >WARNING< to shutdown function >ALARM<.

Factory setting: >WARNING<

1. Press the key

2. Select the menu >SECVAL -AL-TYPE< by pressing the key.

RL-TYPE WARNING XX 3. Press the **OK** key and the set parameter will flash (Example: WARNING)

AL - TYPE RLARM

4. Change the parameter by pressing the key and confirm by pressing the **OK** key. press the key if the parameter is to retained.

i Setting >WARNING<

A mere warning function with optical and audible warning signal (interval tone) A message appears on the VFD COMFORT-DISPLAY:

CODE OB or **OVERTMP**



Setting >ALARM<

Temperature limit with shutdown of heater and circulating pump. An audible alarm sounds (continuous tone) and a message appears on the VFD COMFORT-DISPLAY:






8.3. Over and Sub temperature warning function

Over temperature OVERIMP 200.00

Sub temperature SUBTEMP -- 99.00

If the observance of a working temperature value >SETP< has to be supervised for a sensitive temperature application, then set over and sub temperature warning values. In the example below the SETPOINT 85 °C is surrounded by the values OVERTMP 87 °C and SUBTEMP 83 °C. The electronics immediately register if the actual temperature breaches one of the set limit values. The resulting reaction is defined in a further menu item. (See chapter 8.2.



- 1. Press the key
- or key select the menu >OVERTMP< or 2. By pressing the >SUBTEMP<.
- 1. Press the OK key. The integer digits flash
- 2. Change the values to 87. °C and/or 83. °C by pressing the and key and confirm with the **OK** key.

The decimal digits flash and can be adjusted if desired.

Confirm once more by pressing the **OK** key. See above examples.

The warning functions are only activated if the actual bath temperature remains within the set limit values for 3 seconds after switch-on.



Recommendation:

Set the over temperature warning value >OVERTMP< 5 °C to 10 °C above the working temperature setpoint.

Set the sub temperature warning value >SUBTMP< 5 °C to 10 °C below the working temperature setpoint.

MENU Menu functions 9.

- 1. Open the menu by pressing the MENU key.
- 2. Use the keys to scroll in menu level 1.
- 3. Press the **OK** key to change to menu level 2. Press the key if settings are to be retained.

MENU 4	The term "Menu functions" refers to settings such as	
Menu level 1		
MENU P-START OK >	Start program P-SIARI SIEP	Page 42
MENU PROGRAM	Administration and creation of programs	Page 45
MENU PUMP	Electronically adjustable pump capacity	Page 47
MENU EONFIG	Configuration of the unit REMOTE – on/off (remote control via RS232) AUTOST – AUTOSTART on/off OFF-MODE – pump on/off TIME/DATE – setting time and date RESET – factory settings	Page 48
MENU EONTROL	Control characteristics and parameters C-TYPE – Internal or external control DYNAMICS - internal Control parameter - XP-, TN-, TV- INTERNAL Control parameter - XP-, TN-, TV- XPU-, EXTERNAL	Page 52
MENU SERIAL	Adjustable interface parameters BAUD RATE, PARITY, HANDSHAKE	Page 58
MENU RIE	ATC - Absolute Temperature Calibration, Sensor calibration INTERNAL SENSOR, Sensor calibration EXTERNAL SENSOR 3-point calibration	Page 59
MENU LIMITS	Limitations of temperature and capacity SETPOINT MAX/MIN - Maximum and minimum setpoint HEAT MAX – Set maximum heating COOLING MAX – Set maximum cooling INTERN MAX/MIN – Limitation of the temperature range BAND HIGH/LOW – Band limit	Page 65

Menu level 1

MENU IN/OUT Analog inputs/outputs

ALARM - output

Recorder output – CHANNEL 1, 2, 3 EPROG – External programmer input EX-STBY - STAND-BY input Page 68

9.1. MENU PROGRAM - START

This menu will start a previously set program.

Start-Menu

(i) Requirements:

- 1. Create a program. (refer to next chapter)
- 2. Return to the Start-MENU and confirm the desired setting of each MENU item with the key OK
- 3. Set a start time (>TIME< >DATE< >YEAR<) if the program is to be started by the internal timer.

> STEP< Program start at section 1 ... 10
> RUNS < Number of repetitions 1 ... 99

> END< Status at end of program (STDBY/SETPNT)

Standby or last setpoint

> GO < Time of start (NOW/TIMER)

Menu level 1

MENU
P-5TART


OK

Press the key if a parameter is to be retained.

Correction function for parameters or values (prior to OK)

Level 2	Parameter level	
P-START STEP OK	STEP /X	• Set program step with and example: STEP 1
P-SIARI RUNS OK →	RUNS /X	Set number of runs with and ok example: 1 run

Level 2	Parameter level	
P-SIRRI		a Cat daying disparent in 199
/ h / T/	ENII STIBY XX	Set desired parameters with
E N II OK		and ok .
	or F N TI	(STDBY/SETPNT) Parameter ST an DBY : the circulator switches to –
	ENII SETPNT	OFF
	JE 11 141	Parameter SETP oi NT: the circulator constantly keeps the temperature at the value of the last step.
P-START	5 <i>0</i>	Confirm >NOW< with the OK key and the program
БП ок →	NON XX	will start immediately
7	oer	start at the set time under parameter (TIMER).
	= 50	Set time in the example below:
4	TIMER	09. August 2009, 11:15 hrs
5 <i>0</i>		
TIMER		i) set the time for the start of the program in the
ок 🗸		submenu >TIMER<.
Submenu TIMER		
T T 1.4 / T / T	Parameter level	TIME - become /primartes /bbaress) - act beth values are
TIMER TIME OK	TIME	>TIME< hours/minutes (hh:mm), set both values one after the other and confirm
→	\/\	hours flash, set by pressing
		_ + OK
		minutes flash, set by pressing
		_ + OK
TIMER IRTE OK	IRTE 09.08 \\	>DATE< day/months (TT/MM), set both values one after the other and confirm.
→	/10	 day flashes, set by pressing
		month flashes, set by pressing
		+ ok
TIMER	YEAR	>YEAR< year
YEAR OK	2009 XX	Set the year with
*		and ok .
TIMER	START	
START OK	□K XX	① The program starts at the set time.
→	ОК	
- [[FF-	i Display of time	until start:
		ce >TIMER< and the set values for "TIME" and
S 25.00 TIMER		re alternately indicated
TITLE	(see MENU CON	ct setting of the internal real time clock if required IFIG)



The started program

After the start the program will indicate the currently calculated setpoint in line

S XX.XX. The value increases within the time period >TSLICE< until the target temperature >SETPNT< of the section is reached.

If the time period in a section is set to "0", the next section will not begin until the target temperature has been reached.

Use the edit keys to scroll to line 3. The display changes approximately every 4 seconds between the current section (STEP XX) and the


- Α remaining time of the section
- remaining time of the program
- current bath temperature I xxx.xx - internal actual value or E xxx.xx - external actual value
- RUN the program has started or

PAUSE - the progress of the program has been interrupted by pressing the key. While the time is stopped the temperature will constantly remain at the last calculated setpoint

Continue with the key.



Termination/Interruption of a program






- (i) In case of power failure the program is interrupted. The circulator switches to -OFF-.
- (i) If the AUTOSTART-function is activated the programmer starts again at the point in time approx. 5 minutes prior to the interruption. However, an uncontrolled change of the bath temperature has occurred.

9.2. **MENU PROGRAM – creation, administration**

Menu level 1 MENLI PROGRAM

1 program 10 sections The integrated programmer permits fast and easy programming of setpoint temperature sequences. This temperature sequence is called program. A program is composed of individual sections (STEP). The sections are defined by duration (TSLICE) and target temperature. The target temperature is the setpoint (SETPNT), which is achieved at the end of a section. The programmer calculates the temperature ramp from the difference in time and temperature.



(i) Sections without set value and time are skipped. They can be defined retroactively and the integrated into the program.

Menu level 1 MENU PROGRAM OK	>EDIT< > DELETE< Press	Create, administer program > STEP< Program step (1 10) >SETPNT < Temperature setpoint of step >TSLICE< Duration of step delete program step (01 10, ALL) a parameter is to be retained.
	Correction function	for parameters or values (prior to OK)
Level 2	Level 3	Parameter level
PROGRAM E II I OK >	EIII STEP OK >	51EP / ;; (STEP 1 10)
	EDIT DI STEP	 Set program step with and ok ← (Example: EDIT STEP 01) i) For STEP 01 the values for SETPOINT 01 and TSLICE 01 are set one after the other
	EDIT DI SETPNI OK >	SETPNT 1□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
		 Decimal digits flash, set by pressing + ok
	E II I II I I I I I I I I I I I I I I I	TSLIEE ☐☐. I☐ > (• Set duration by pressing and oк)
PROGRAM DELETE OK	JELETE STEP XX	 Delete program Program steps can be deleted individually or entirely. (STEP 01, 02, 10, ALL). Set parameters by pressing and ok

9.3. **MENU PUMP - Setting of pump pressure**

Ist



Examples:

Soll

The pressure of the circulating pump is adjustable in four stages. After setting, the VFD COMFORT-DISPLAY indicates the corresponding value.

Adjustable pump capacity stage 1 ... 4

Illuminated display: For pump pressure

(i) Adjusted: Display for the adjusted pump pressure stage in the -OFFmode.

(i) Effective: Display for the effective pump pressure stage (rotation speed) after start.

For protecting the pump motor, the rotation speed (i.e. the pump pressure stage) changes with the load applied.

Example: The viscosity of the bath fluid (i.e. the load applied to the pump motor) changes with the working temperature in the bath.

Flow rate:	22 26	i l/min			
Pump capacity stage		1	2	3	4
Pump pressure	[bar]	0.4	0.5	0.6	0.7
Suction pump	[bar]	0.2	0.26	0.33	0.4
Total capacity in a loop circuit	[bar]	0.6	0.76	0.93	1.1



Factory setting: stage 1

> PUMP LEVEL

- 1. Press the MENU kev.
- 2. Select the menu >PUMP< pressing the key and confirm by pressing the **OK** key The set parameter flashes (example: >LEVEL 2<)
- 3. Change the parameter by pressing and confirm by pressing the ok key. or

Press the key if the parameter is to be retained.

9.4. **MENU CONFIG - Configuration of unit**

Menu level 1 MENU CINFIG OK		ffected only in the >OFF< mode. RESET r by pressing the OK key and call up the menu
Level 2	Parameter level	Press the key if a parameter is to be retained. Correction function for parameters and values (prior to OK).
EUNFIG REMUTE OK >	REMOTE OFF XX OR REMOTE ON	 Switch on and off remote control by pressing and ok Control display in the topline for Remote For remote control refer to 81 Occurrence of the control of the contro
EUNFIG SP EXT OK >	SP EXT OFF XX or SP EXT PT 100 or SP EXT EPROG	 Switch over setpoint setting by pressing
EUNFIG AUTUST OK >	PUTUST OFF XX or PUTUST ON	Switch on and off autostart by pressing and ok AUTOSTART on = on AUTOSTART off = off See WARNING page 50
EONFIG OFFMOJE ok →	OFFMOJE PMP ON XX or OFFMOJE PMP OFF	Switch on and off OFFMODE by pressing and ok PUMP ON continuous operation of circulating pump PUMP OFF circulating pump is linked to Start/Stop
EONFIG REIVAR OK >	AEIVAR EONTROL ;;; or AEIVAR SERIAL or AEIVAR EPROS	Switch over the input variable by pressing and ok Programming of variables for the parameters > SERIAL < or > EPROG < is only accepted, if the unit is in Start mode Parameter level
LUVUIZ	LCACI 2	i aramoter iever

E□NFIG TIME/IT ok →	TIME/IIT TIME OK >	 I IME /// // // // // // // // // // // // //
	IIME/II IRIE OK >	 □RTE □B□9 /1/ Day flashes, set by pressing
	IIME/III YEAR OK→	YEAR 19 \\ • Year flashes, set by pressing • • • • • • • • • • • • • • • • • •
EONFIG RESET OK >	- [] F F - RESET OK); - [] F F - RESET - RUN -	 Return to factory settings by pressing OK RESET returns all set values to the factory setting except for date and time. A RESET can be effected only in the –OFF- mode. During the message –RUN- all parameters are reset to factory settings.

9.4.1. Remote control via the serial interface

Factory setting: OFF

The control electronics offer two ways of adjusting a setpoint.

- 1. Adjustment of setpoint using the keypad or the integrated programmer.
- 2. Adjustment of setpoint via the serial interface RS232 using a PC or a superordinated process control system.
- The topline of the VFD-DISPLAY shows a bright "R" for remote control; - remote control discontinued.

o o	IMPORTANT: additional measures for remote control		
RS232	(i) Connect the circulator to the PC using an interface cable.		
	(circulator and PC)		
	and make sure they match.		
	(refer to 12.1. Setup for remote controll page 81)		

9.4.2. Keypad control or setpoint setting via the analog input

Factory setting:: OFF

EDNF 15 SP EXT

In addition to the serial interface via remote control the circulator offers the possibility to adjust the setpoint via analog interface >ext. Pt100< or >REG+E-PROG<.

The selected mode is indicated on the VFD COMFORT-DISPLAY

XXXX OFF $I \times \times \times \times \times$ 51 XXXX PT100 $I \times \times \times \times \times$ SP XXXX EPROG $I \times X \times X \times X$

OFF - Setpoint setting with the navigation keys or the integrated programmer.

PT100 - Setpoint setting via the analog socket "ext. Pt100" using an external temperature sensor or an appropriate voltage/current source.


EPROG - Can only be adjusted when an electronic module with analog connections is used (option).

Setpoint setting via the analog interface REG+E-PROG connection with an external voltage or current source or a programmer.

Important:

Connect the external voltage or current source or a programmer to the circulator via the socket REG+E-PROG (see page 72). In the menu >MENU IN/OUT< set the parameter >EPROG-INPUT< and the input variables >EPROG-SIGNAL< (see page 72).

The E-Prog input can only be used either under menu item >SP EXT < or under menu item >ACTVAR< (see page 51).



9.4.3. **AUTOSTART**



Warning

For supervised or unsupervised operation with the "AUTOSTART" function avoid any hazardous situation to persons or property

Take care to fully observe the safety and warning functions of the circulator.

Factory settings: OFF

Notice:

The circulator has been configured and delivered by JULABO in accordance with the NAMUR recommendations. This means for the start mode that the unit must enter a safe operating status after a power failure. This safe operating status is indicated by the message "OFF" or "R OFF" on the VFD COMFORT-DISPLAY.

A complete, all-pole shutdown of the main functional elements such as heater and pump motor is effected.

The values set on the circulator remain saved and the unit is restarted by pressing the start/stop key in manual control.

In remote control mode the values need to be resent by the PC via the interface.

If such a safety standard is not required, the NAMUR recommendations can be bypassed with the AUTOSTART function thus allowing a direct start of the circulator by pressing the mains switch or using a timer.

9.4.4. OFF-MODE

Factory setting: PMP OFF Usually the circulating pump is controlled with the key **OK** or the start/stop command. If the circulating pump is to work in the -OFFmode, the adjustment can be set in a sub-menu.

(i) The pump motor will be shutdown in case of alarm anyhow.

9.4.5. **ACTVAR** - actuating variable

Factory setting: CONTROL The variable (ACTuating VARiable) corresponds to the extent to which the heater or cooling unit of the circulator is controlled. Heat or cold is applied to the bath according to this variable. If this happens with the control electronics of the circulator, called > CONTROL < in this particular case, the bath temperature is exactly heated and maintained constant at the adjusted setpoint.

(i) Programming of variables for the parameters > SERIAL < or > EPROG < is only accepted, if the unit is in Start mode.

RETVAR EONTROL RETVAR SERIAL RETV RR

EPRO5

Possible parameters:

CONTROL – The internal control electronics of the circulator controls the heater und the connected cooling unit. Self-tuning is possible.

SERIAL – The heater or the connected cooling unit receives the control signal via the serial interface. Self-tuning is not possible.

EPROG - The heater or the connected cooling unit receives the control signal via the E-Prog input. Self-tuning is not possible.

Important:

MENLI EPROG U Under IN/BUT set the input variable >EPROG U/I< INPUT to INPUT RETVAR (refer to page 72).

EONF I G SP EXT SP EXT EPR05 EDNF 15 RETURR EPR05 RETVAR

Note:

The E-Prog input can only be used either under menu item >SP EXT< (refer to page 50) or under menu item > ACTVAR <.



Warning:

The working temperature range of the circulator is determined during configuration. If set to >CONTROL<, this range cannot be exceeded.

If set to > SERIAL < and > EPROG <, heat or cold is applied to the bath without control. The permissible maximum temperature can be exceeded. The user has to take adequate precautions for temperature control.

Materials, such as gaskets or insulations for example, may be damaged or destroyed, if the permissible maximum temperature is exceeded.

The safety and warning functions > < of the instrument must always be used to</pre> their fullest capacity.

9.4.6. Setting of clock and date



TIME 11.15 The internal real time clock allows starting a program any time. The clock is set to the local mean time (MEZ) at the factory.

- (i) If the unit is operated in a different time zone, the clock can be adjusted in this menu.
- (i) Change summer/winter time in this menu

9.4.7. **RESET – Factory settings**



A Reset will return all values to factory setting except for date and time.

A RESET can be effected in the >OFF< mode only.</p> Switch off the circulator by pressing the key **OK** and call up the menu CONFIGURATION.

9.5. **MENU CONTROL – Control characteristics and parameters**

Menu level 1 MENLI *FANTRAL*

OK V

The circulator is qualified for internal and external temperature control The switchover is carried out in the menu >C-TYPE< .(INT or EXT).

- (i) For external temperature control and measurement connect a Pt100 external sensor to the socket at the rear of the circulator.
- key if a parameter is to be retained. Correction function for parameters or values (prior to OK)
- **(i)**

Level 2	Parameter level	
EONTROL E-TYPE OK →	E-TYPE INT XX	The parameter flashes, switch by pressing and ok
	or <i>E - T Y P E</i> <i>E X T</i>	 The control type can be adjusted in the -OFF-mode only. Depending on the adjustment only the active parameters are displayed.
EDNTROL SELFTUN OK >	SELFTUN OFF XX	The parameter flashes, switch by pressing and ok
	SELFTUN UNCE or SELFTUN ALWAYS	 OFF - no selftuning. ONCE - single selftuning (factory setting) ALWAYS - continual selftuning.

	<u> </u>	
Level 2	Parameter level	
C-TYPE INTERNAL		
EONTROL IYNAMIE (ok →	IYNAMIE APER X	The parameter flashes, switch by pressing and ok
	or IYNAMIE NORM	in case of internal control.
EDNIROL XP INI OK >	*F INI !5 ;; 0.1 99.9	The parameter flashes, set by pressing ok ok
EONTROL IN INT OK →	IN INI IDD ;;(3 9999	• The parameter flashes, set by pressing + ok
EONTROL IV INT OK →	<i>IV INI</i> 5 \\ 0 999	• The parameter flashes, set by pressing + ok
C-TYPE EXTERNAL		
EUNTRUL XP EXT OK >	XP EXI	• The parameter flashes, set by pressing + ok
EDNTROL IN EXT OK >	IN E × I 720 \\\ 3 9999	The parameter flashes, set by pressing OK OK
EUNTRUL IV EXT OK >	TV EXT 55 ;; 0999	• The parameter flashes, set by pressing + OK
EONTROL ×PU ok →	<i>XPU</i> ∃□ \ \\ 0.1 99.9	The parameter flashes, set by pressing ok ok

9.5.1. CONTROL - Control INTERNAL/EXTERNAL



Switchover can only be effected if a Pt100 external sensor is connected.

Factory setting: INT

IMPORTANT: Additional measures for external temperature control

- (i) Suggested settings for external temperature control: BAND HIGH/LOW and INTERN MAX/MIN see chapter >MENU LIMITS<.
- (i) Sensor calibration of the Pt100 external sensor is carried out in the menu >ADJUST<, submenu >ATC SENOR EXT<; set ATC STATUS< to >OFF< (See page 59).



Attention:

Place the external sensor into the temperature-controlled medium and securely fix the sensor.



Accessory: Pt100 external sensor

Order No.	Description	Material	Cable
8981003	200x6 mm Ø,	stainless steel	1.5 m
8981005	200x6 mm Ø,	glass	1.5 m
8981006	20x2 mm Ø,	stainless steel	1.5 m
8981010	300x6 mm Ø,	stainless steel	1.5 m
8981015	300x6 mm Ø,	stainless steel/PTFE coated	3 m
8981013	600x6 mm Ø,	stainless steel/PTFE coated	3 m
8981016	900x6 mm Ø,	stainless steel/PTFE coated	3 m
8981014	1200x6 mm Ø,	stainless steel/PTFE coated	3 m
8981103	Extension cable for Pt100 sensor 3.5 m		3.5 m
8981020	M+R in-line Pt100 sensor		

The M+R in-line Pt100 sensor is a flow sensor and can be installed loop circuit

9.5.2. SELFTUNING



Selftuning:

When performing a selftuning for the controlled system (temperature application system), the control parameters Xp, Tn and Tv are automatically determined and stored.

Possible parameters:

OFF - no selftuning

The control parameters ascertained during the last identification are used for control purposes.

ONCE - <u>single</u> selftuning (factory setting)


The instrument performs a single selftuning of the controlled system after each start with the ok key or after receiving a start command via the interface.

ALWAYS - continual selftuning

The instrument performs a selftuning of the controlled system whenever a new setpoint is to be reached.

Use this setting only when the temperature application system changes permanently.

9.5.3. Dynamic internal



This parameter affects the temperature sequence only in case of internal control.

Factory setting: APER (aperiodic)

Possible parameters:

NORM Allows for reaching the setpoint faster – with setpoint change or ramp function – but overshooting of up to 5 % is possible.

APER Ramp function: the increase of temperature occurs temporally offset and achieves the target temperature without overshooting. Setpoint change: The temperature increases at the same rate, the target temperature is achieved without overshooting.

(i) With both settings constant temperature is achieved after approximately the same time.

9.5.4. Control parameters- XP-, TN-, TV- INTERNAL

In most cases the control parameters preset in the factory are adequate for achieving an optimum temperature sequence.

The control parameters allow adjustment to special control processes..

XP INT

Setting range: 0.1 ... 99.9

Proportional range >Xp<

The proportional range is the range below the setpoint in which the control circuit reduces the heating capacity from 100% to 0 %

IN INI

Setting range: 3 ...9999

Reset time >Tn< (Integral component)

Compensation of the remaining control deviation due to proportional regulation. An insufficient reset time may cause instabilities. Excessive reset times will result in unnecessary prolongation of compensation of the control difference.

Setting range: 0 ... 999


Lead time >Tv< (Differential component)

The differential component reduces the transient time. An insufficient lead time will prolong the time required for compensation of disturbance effects and cause high overshooting during run-up. An excessive lead time could cause instabilities (oscillations)

Optimization instructions for the PID control parameters


Optimum setting


Control parameters XP-, TN-, TV- INTERNAL as well as -EXTERNAL



The heat-up curve reveals possible faulty settings of the control parameter.

Inappropriate settings may produce the following heat-up curves:






9.5.5. COSPEED - external



This parameter affects the temperature pattern only in case of **external** control.

Possible parameters: 0.0 ... 5.0

During selftuning, the control parameters Xp, Tn and Tv of a controlled system are automatically determined and stored. Depending on the controlled system, time for tuning can be unequally longer. This controller layout allows protection of sensitive objects requiring temperature application.



As soon as a co-speed factor is set, it is considered for calculating the control parameters. As shown in the diagram, tuning times become shorter the higher the co-speed factor is, but overshooting can happen in the internal system.

9.5.6. Control parameters – XPU-, XP-, TN-, TV- EXTERNAL

XP EXT D.7

Setting range: 0.1 ...99.9

IN EXT 720

Setting range: 3 ...9999

IV EXT 55

Setting range: 0 ... 999

XPU 30 Setting range: 0.1 ... 99.9 In most cases the control parameters preset in the factors are adequate for achieving an optimum temperature sequence.

The control parameters allow adjustment to special control processes.

Proportional range >Xpu<

The proportional range Xpu of the cascaded controller is only needed for external control.

9.6. MENU SERIAL - BAUDRATE, HANDSHAKE, PARITY

PARITY

PRRITY

NΠ

SOFT

Menu level 1 MENU SERIAL OK	For communication between circulator and a PC or a superordinated process control system the interface parameters of both units must be identical. (i) For remote control refer to page 81 Factory settings: 4800 Baud even hardware handshake	
Level 2	Parameter level	① Press the
SERIAL OK >	######################################	• The parameter flashes, switch by pressing and ok
SERIAL PARITY OK >	PARITY EVEN X	The parameter flashes, switch by pressing and ok and

• The parameter flashes, switch by pressing

Data bits = 7; Stop bits = 1

Data bits = 7; Stop bits = 1

Data bits = 8; Stop bits = 1

and ok

even:

odd:

no:

Xon/Xoff-protocol Protocol RTS/CTS (Software handshake) (Hardware handshake)


9.7. **MENU ATC - Absolut Temperature Calibration**

MENLI RIL

ATC serves to compensate a temperature difference that might occur between circulator and a defined measuring point in the bath tank because of physical properties.

Example:

1-point calibration °C T₇1



 $T_T 1 = Original curve$

Principle:


M

°C

For ATC calibration, in steady state the bath temperature at the location of the temperature sensor (CT) is determined at the respective adjusted working temperature. This value is then set on the circulator in the menu >ATCalibration< under menu item > CTEMP X <.

B (INT)

This can be a 1-point, 2-point or 3-point calibration.



M = Temperature measuring instrument with temperature sensor

B = Bath tank (INTernal or EXTernal)

T = circulator

CT = Temperature on measuring point

TT = Temperature on circulator

Menu level 1		
MENLI		
ATE		
ок ↓		
Level 2	Parameter level	Press the key if parameter is to be retained. Correction function for parameters or values (prior to OK).
RIC SENSOR OK >	SENSOR INTERNX	 The parameter flashes, switch by pressing and
	or SENSOR EXTERN	① On level 2 a (I) is indicated for internal or an (E) for external.
		Example: RIE (I) RIE (E)
AIE (I) SIAIUS OK >	STATUS YE5米	The parameter flashes, switch by pressing and ok and
	or STRTUS ND	NOCarry out an ATC calibrationYESreturn to standard operation after calibration.
AIE (I) IYPE OK >	IYPE I-POINT XX	The parameter flashes, switch by pressing and ok
	IYPE 2-POINT	(i) A >1-point<, >2-point< or >3-point< calibration can be carried out.
	TYPE 3-POINT	The selected calibration is indicated on level 2 by 1 or 2 or 3.
RIE (I)	IMPVALI	The value >TMPVAL< is only indicated
IMPI'ALI OK →	80.00 (5)	In addition the measured temperature value >CALVAL X< is saved during the next step.
RIE (I) ERLI/ALI OK >	EALVALI 79.70 ::	 Integer digits flash, set by pressing ok
		 Decimal digits flash, set by pressing + οκ
	indicated anymore	ibration is carried out, the following menu items are not
Level 2	Parameter level	
AIE (I) IMPVALZ OK >	TMPVAL 2 120.00 (5)	The value is only indicated

Level 2	Parameter level	
ATE (I) EALVAL2 OK >	ERLVAL2 1 1950 X	■ Integer digits flash, set by pressing → → → oκ
		Decimal digits flash, set by pressing
	indicated anymore	ibration is carried out, the following menu items are not
HIE (I) TMPVAL3 OK >	TMPVAL 3 160.00 5	The value is only indicated
RIE (I) ERLVAL3 OK	ERLVAL 3 15930);(Integer digits flash, set by pressing
		 Decimal digits flash, set by pressing + ok

9.7.1. ATC SENSOR - INTERNAL/EXTERNAL

RIE SENSOR SENSOR INTERN SENSOR EXTERN

In the first submenu the ATC function is set for the >INTERN< internal or the >EXTERN< external temperature sensor.

Calibration can be carried out for the internal temperature sensor and for the external temperature sensor connected to the socket "ext. Pt100".

The circulator is able to save both parameter sets. However only the one which has been set under menu item >ATC SENSOR < is displayed.

9.7.2. ATC STATUS - YES/NO

 $AIE \langle I \rangle$ STRTUS STRTUS Y E S STRTUS NΠ In the second submenu the ATC function for the temperature sensor selected above is activated >YES< or deactivated >NO<.

>YES< (factory setting) The controller of the circulator uses the original curve of the temperature sensor or the new curve measured during the ATC calibration.

Important: Set to **>NO<** during the calibration process

>NO< An ATC calibration is to be carried out.

Important: Set to **>YES<** after calibration.

(i) In the > ATC STATUS < >YES< the ATC calibration always affects the current working temperature; also the one set via interface.

9.7.3. CALIBRATION TYPE: 1 -/ 2 -/ 3 POINT

RTE (I) TYPE

IYPE I-POINT

TYPE 2-POINT

TYPE 3-POINT A >1-point<, >2-point< or >3-point< calibration can be carried out.

values indicated on the LCD DIALOG-DISPLAY.

First geometrically define the location for calibration (measuring point CT), then determine the temperature values of the calibration points.

The type of calibrations also determines the number of the following pairs of

Pairs of values:

TMPVAL X: Circulator temperature 1 or 2 or 3 (actual value TT)

The actual temperature of the bath is simultaneously saved with the "calibration value" >CALVAL< and can be indicated for control purposes (value does not flash).

CALVAL X: Calibration temperature 1 or 2 or 3 (actual value CT)

The "calibration value" is determined with a temperature measuring device and saved under menu item >CALVAL<.

(value flashes /1)

9.7.4. Example: 3-point calibration for internal control

In the temperature range from 80 °C to 160 °C the calibration curve of the temperature sensor (TT) is to be adjusted to the actual temperatures at measuring point (CT).

1. Set circulator to internal control: **MENU CONTROL page 52**

Menu level 1 MENLI

[[NTR[]L OK]

The type of control can be set only in the -OFF- mode.








2. Set working temperature setpoint - SETPNT:

Refer to "Direct temperature setting "page 36

- By pressing the key the circulator switches to the active >SETPOINT< see example on the left: >SETPNT/1 25.00°C<. The integer digits flash /ix (Example: <25>).
- Change the value to 80.00 °C by pressing the keys and and confirm by pressing the key The decimal digits flash.

Confirm once more by pressing the key **OK**.

The bath is heated up. Wait for approx. 5 minutes until the temperature is constant.



80.00°C

120.00 °C

160.00 °C

3. Reading of temperature measuring device

Read the value of measuring point CT on the device and enter under menu item >CALVAL X< by using the keypad.

> >CALVAL 1< (79.70 °C) >CALVAL 2< (119.50 °C) >CALVAL 3< (159.30 °C)

	4. Calibration		
Menu level 1 MENU RIC OK	 Press the		
Level 2	Parameter level		
RIC SENSOR OK →	SENSOR INTERNX	Set SENSOR INTERN: The parameter flashes, switch by pressing and ok.	
HIE (I) SIHIUS OK →	STRTUS NO XX	An ATC calibration is to be carried out. Set to >NO< The parameter flashes, switch by pressing and ok.	

Meria functions			
RIE (I) IYPE OK >	TYPE 3-POINT %	The parameter flashes, switch by pressing and ok .	
	③	A >3-point< calibration is carried out.	
HIE (I) IMPVALI OK →	TMPVAL I 80.00 (5)	The value >TMPVAL< is only indicated In addition the measured value >CALVAL X< is saved during the following step	
AIE (I) EALVALI OK →	ERLVALI 79.70 %	• Integer digits flash, set by pressing (79) + OK	
		Decimal digits flash, set by pressing (70) + OK	
		The first of 3 points is calibrated.	
	Return to 2. Set working	g temperature value SETPNT: 120.00 °C	
ATE (I) IMPVALZ OK >	TMPVAL 2 0.0051	The value is only indicated	
FIL (I)	ERLVAL2 1 1950 ;;	Integer digits flash, set by pressing (119) + OK	
		Decimal digits flash, set by pressing (50) + ok	
		The second of 3 points is calibrated.	
	Return to 2. set working	g temperature value SETPNT: 160.00 °C	
AIE (I) IMPVAL3 OK >	TMPVRL 3 160.00 (5)	The value is only indicated.	
AIE (I) EALVAL∃ OK →	ERLVAL 3 159.30 ; ;	Integer digits flash, set by pressing (159) + OK	
		Decimal digits flash, set by pressing (30) + ok	
		The 3-point calibration is completed	
	5. Return to standard operation		
RIE (I) SIRIUS OK >	STATUS YES:XX	Set >YES< after calibration. (Standard operation)	
		I and the second	

9.8. **MENU LIMITS**

Menu level 1	
MENLI	
LIMITS	
ок ↓	
Level 2	

ок 👃				
Level 2	Parameter level	Press the beautiful key if parameter is to be retained. Correction function for parameters or values (prior to OK).		
LIMITS SETMAX OK >	SETMAX 300.00 ; ;	Integer digits flash, set by pressing + ok		
		 Decimal digits flash, set by pressing + οκ 		
LIMITS SEIMIN OK >	SEIMIN -94.99	 Integer digits flash, set by pressing + ok 		
		Decimal digits flash, set by pressing + OK		
LIMITS HERTMRX OK >	HERIMAX IDD ;; 0 100 %	 The value flashes, set by pressing + οκ 		
LIMITS EDOLMAX OK >	EDDLMAX D);(0 100 %	The value flashes, set by pressing mit		
	In case of external cont	trol these menu items are additionally indicated.		
LIMIIS INIMAX OK >	INIMAX 300.00 ; ;	 Integer digits flash, set by pressing + ok 		
		Decimal digits flash, set by pressing + ok		
LIMIIS INIMIN OK >	INIMIN -9499;;;	 Integer digits flash, set by pressing + ok 		
		Decimal digits flash, set by pressing		
LIMITS BAND-H OK	IRNI-H 200%	• The value flashes, set by pressing		
LIMIIS BAND-L OK	IRNI-L 200%	 The value flashes, set by pressing + οκ 		

9.8.1. Limits for internal control

E-TYPE INT

SETMAX

SEIMIN

300.00

-- 94.99

SETPOINT MAX/MIN – Maximum and minimum setpoint

Restriction of the adjustable temperature range.

The limitation of the operating temperature range effects the temperature

setting in the menu with the key

Only setting of working temperatures which lie within the determined limits is possible

Existing settings for SETPNT 1, -2, -3, as well as those for >OVERTMP< and > SUBTMP < (refer to page 37), are automatically deferred into the limit range.

Setting range: -94,90 °C ... +300,0 °C

SET MAX > SET MIN
Interchange of values is not possible.

Set maximum heating/cooling

The heating and cooling capacity of the unit are adjustable. 100 % corresponds to the technical specification of the equipment.

Setting range:

HEAT MAX – 0 to 100 % in 1 % steps **COOLING MAX** – 0 to 100 % in 1 % steps

HERTMAX 100 COOLMAX O

9.8.2. Limits for external control

INTERN MAX/MIN

Restriction for the temperature range of the internal bath.

INTMRX 300.00 INTMIN -9499

Setting range: -94,9 °C ... +300,0 °C

The limits INT MAX and INT MIN are only active in external control. INT MAX and INT MIN determine fixed limits for the temperature within the internal bath. The temperature controller cannot exceed these limits even if it would be necessary for achieving the temperature in an external system. Therefore it is possible that the external setpoint cannot be achieved.



Sense of limit setting:


- ☑ Protects the bath fluid from overheating.
- ✓ Prevents an undesired alarm shutdown by the excess temperature protection >ALARM CODE 14<.</p>
 Set the value of > INT MAX at least 5 °C below the value of >SAFETMP<.</p>
- Protects the pump motor from high viscosity of the bath fluid at low temperatures.
- ☑ For refrigerated circulators. Freezing protection when using water as bath fluid.



BAND HIGH/LOW - Band limitation

The band limitation is active during external control. Varied, practiceoriented setting are feasible for heat-up and cool-down phases. Setting range: 0 °C ... 200 °C


BAND HIGH and BAND LOW allow for the limitation of the difference between the temperatures in the internal bath and the external system to any maximum value for the heat-up and cool-down phase. During the heat-up phase this difference value is always added to the actual external temperature. During the cool-down phase the difference value is subtracted.



Sense of a band limitation:

- ☑ Protection of objects and samples by gentle temperature control
- ✓ Protection of e.g. glass reactors from thermal shock.

MENU IN/OUT – Analog inputs/outputs (Option) 9.9.



in order to use the analog inputs and outputs, the circulator must be equipped with the electronic module available as option. Order No. 8 900 100 Electronic module

This submenu enables setting of the input and output values for the programmer input and the temperature recorder outputs of socket REG+E-PROG.

The >STAND-BY< input and the >ALARM< output are configurable.




(i) Press the (b) key if parameter is to be retained. Correction function for parameters or values (prior to OK).

	T	1	
Level 2	Level 3	Parameter level	
IN/OUT EHI OK	EHI □UTPUT OK →	OUTPUT RETINT XX OUTPUT RETEXT OUTPUT POWER OUTPUT SETPNT	The parameter flashes, switch by pressing and ok ACTINT [°C] internal actual temperature value (bath temperature) ACTEXT [°C] external actual temperature value (external sensor) S-POINT [°C] active setpoint temperature POWER [%]
	ΕΗ Ι□ Ι'Οκ	01/ °C -99.90)	Integer digits flash, set by pressing
	EH □ /	10V °C 400.00 } (Decimal digits flash, set by pressing
IN/□□I EH2 OK →	[H2 □UTPUT OK →	OUTPUT RETEXT XX OUTPUT RETINT OUTPUT POWER OUTPUT SETPNT	The parameter flashes, switch by pressing and ok and

		T	
Level 2	Level 3	Parameter level	
	[H2] []/ οκ	01/ °C -99.90) (Integer digits flash, set by pressing → → → οκ
			Decimal digits flash, set by pressing
	EH2 □ / οκ →	101′ °C 400.00) (+ ок
IN/OUT EH3 OK	EH3 GUTPUT OK	OUTPUT SETPNT XX OUTPUT RETINT OUTPUT POWER OUTPUT RETEXT	The parameter flashes, switch by pressing and ok
	EH∃ □MR ok →	OMA °C -99.90 ; ;(Integer digits flash, set by pressing OK Decimal digits flash, set by
			pressing
	EH3 20MR ok →	20MR °C 400.00) K	+ OK
	EH∃ RANGE OK →	RANGE 4-20MA X RANGE 0-20MA	The parameter flashes, switch by pressing and ok
IN/OUT EPROG OK	EPROG U INPUI OK	INPUT SEIPNT XX INPUT REIVAR INPUT FLOURAT	The parameter flashes, switch by pressing and ok
	EPROG SIGNAL OK	SIGNAL VOLTAGE XX or SIGNAL EURRENT	 The parameter flashes, switch by pressing and ok Define the indication of EPROS U EPROS I INPUT OR INPUT VOLTAGE CURRENT

Level 2	Level 3	Parameter level	
	EPROG LVAL VAL EPROG UVAL	LVAL "E -99.90 Lower VALue LIVAL "E 400.00 Upper VALue	 Integer digits flash, set by pressing
IN/□□I Ex-SI∄Y OK →	EX-SIBY INACIIV ;; or EX-SIBY ACIIV		The parameter flashes, switch by pressing and ok and
IN/□UT AL-□UT OK →	AL-OUT FUNET	FUNET STANIBY XX FUNET AL-STBY FUNET ALARM	The parameter flashes, switch by pressing and ok
	AL-OUT TYPE	TYPE NORMAL XX TYPE INVERSE	The parameter flashes, switch by pressing and ok and


9.9.1. Outputs of the connector - REG+E-PROG





REG+E-PROG:

- 1. Select CHANNEL 1, 2 or 3
- 2. First define the desired output value for CHANNELs 1 to 3:



(SETPoint 1, 2, 3,/ integr. programmer /external programmer)







3. Then select the display size for CHANNELs 1 to 3:

Voltage outputs CHANNELs 1 and 2


Assign the voltage values of 0 V to the lowest and 10 V to the highest necessary temperature (°C) or power rating (%) required as an output value.

CHANNEL 3: Output for temperature value (°C)/power (%) The current output (channel 3) offers 2 ranges for selection:

0 mA to 20 mA or 4 mA to 20 mA

Assign the current values 0 mA or 4 mA to the lowest and 20 mA to the highest temperature (°C) or power rating (%) required as an output value.

RANGE	EH3	EH3	or
0-20MA	OMR	20MR	
RANGE	EH3	CH3	
4-20MA	YMA	20MR	



Example 1: DUTPUT RETINT

③ lowest temperature value: 10 °C


③ highest temperature value 210 °C Fig. shows 200 °C scaled to paper width rise: 50 mV/°C

Example 2:

197 °C lowest temperature value: highest temperature value: 202 °C Fig. shows 5 °C scaled to paper width

rise: 2000 mV/°C

9.9.2. Input of the connector - REG+E-PROG



Setting needs to be carried out, if

- setpoint programming is to be made via an external voltage or current source or programmer.
 For this, in the menu > MENU/CONFIG < first set the menu item > SETP < to >EPROG<.
 MENU EDNFIE SP EXI EPROE
- 2. the heater variable should be controlled via an external control pulse. For this, in the menu > MENU/CONFIG < set the menu item >ACTVAR< to >EPROG<.

 MENU EDNFIG RETVAR

 EDNFIG > RETVAR > EPROG (refer to page 51).
- **3.** the signal of an external flow meter should be registered. >FLOWRAT< see below.

>FLOWRAT< Indication on display



(i) FLOWRAT

The E-Prog input can only be used either under menu item >CONFIG -SP EXT< < or under menu item >CONFIG ACTVAR<
If the input is neither occupied by > SP EXT < or > ACTVAR <, the signal of a flow meter can be connected.

i First set >MENU CONFIG<



Settings on input - E-PROG

1. Connect the external voltage or current source or programmer to socket REG+E-PROG of the circulator.

2. Selecting the signal:

The programmer (E-PROG) input of the circulator can be matched to the output signal of the external voltage or current source.

```
SIGNAL
VOLTAGE

voltage input = \mathbf{U} \rightarrow INPUT

SIGNAL
EPROGI
EPROGI
EURRENT

current input = \mathbf{I} \rightarrow INPUT
```

3. Define the input variable:

INPUT
SETPHT
Setpoint programmed by external voltage or current
INPUT
RETVER
Manipulated (ACTuated) variable for the heater
with an external control pulse

INPUT
FLOWRET
Signal of an external flow sensor

EPROG U Beispiel: INPUT

EPROG

SIBNA

Examples:




IIV'AI °C 300.00

EPR05 4 LVAL

- Setting the LOW value: (See below →)

First adjust and set the lowest voltage or current on the external voltage or current source (e.g. 0 V or 0 mA).

Then after approx. 30 secs enter the corresponding temperature value (e.g. 20.00 °C).on the circulator by pressing




EPRO5

5. UVAL - Setting the HIGH value: (See below →)

First adjust and set the highest voltage or current on the external voltage or current source (e.g. 10 V or 20 mA).

Then after approx. 30 secs enter the corresponding temperature value (e.g. 300 °C) on the circulator by pressing





Example:

Set the external voltage or current source output for the equivalent of 50 °C temperature setpoint.

) (1) - to standard display. Press

The temperature value adjusted and set on the external voltage or current source is displayed in line 2 of the VFD COMFORT-DISPLAY for control purposes. (Example: SP 50.00 °C).




This EPROG input enables the use of different voltage and current values as program parameters.



- Setting the LOW value: (See below 2)



- 1. Adjust and set the lowest desired value on the voltage or current source resp. (Example A: 1 V). Wait appr. 30 seconds.
- 2. Assign a lower temperature threshold value to this adjusted voltage/current value by pressing the appropriate buttons on the keypad of the instrument (Example A: 20 °C) and set by pressing OK



EPRO5 LIVAL

- Setting the Upper value: (See below →)

- 1. Adjust and set the highest desired value on the voltage or current source resp. (Example A: 10 V). Wait appr. 30 seconds.
- 2. Assign an upper temperature threshold value to this adjusted voltage/current value by pressing the appropriate buttons on the keypad of the instrument (Example A: 200°C) and set by pressing OK

i Example B in the diagram serves to illustrate that the end point values are freely selectable (Ex: 8 mA and 16 mA).



Example out of diagram A:

• Adjusting the voltage source for an output of 7.6 V!

The instrument calculates this value from the rise angle of the two predecided end points (in example A: 7.6 V correspond to an external setpoint temperature of 152.0 °C).

After returning the VFD display to standard display, this value is displayed in line 2 (Example: SP 152.00 °C).



Notice:


If this adjustment is not correctly performed at two different points, the setpoint setting will be incorrect.



Important:

The usable temperature range between > LVAL < and > UVAL < is limited to the configured working temperature range of the circulator resp. of the unit combination (working temperature range see technical specifications)

9.9.3. ALARM-output/Stand-by-input



Alarm output (10)

(for external alarm signal)

Possible parameters:

AL - OUT FUNET

(STANDBY or ALARM or AL-STBY)

FUNET STANIBY FLINET AL-5111Y FLINET ALARM This socket is a potential-free change-over contact. With the adjustments in the menu item > AL-OUT Function< all operating conditions can be

signaled without having to change the pin assignments. Signification of the terms under menu item >Function<:

The circulator is in condition >STANDBY< or >ALARM< or >AL-STBY< both conditions are signaled.

TYPENDRMRLTYPF INVERSE

Alarm-TYPE

Possible parameters:


AL - DUT TYPE

(NORMAL or INVERS)

For >TYPE- NORMAL< pins 2 and 3 are connected in any case according to the selected > AL-OUT Function<

For >TYPE- INVERS < pins 2 and 1 are connected in any case according to the selected > AL-OUT Function<


Switching capacity 30 W/40 VA max. Switching voltage max. 125 V~/-Switching current max. 1 A



EX-518Y INACTIV EX-518Y ALITY



(for external switch-off)



INACTIV - standby input is ignored

ACTIV - standby input is active

Activate the standby input:

- 1. Under menu item > EXT-STBY <, set the parameter to >ACTIV<.
- 2. Connect an external contact ,AK' (e.g. for switch-off) or an alarm contact of the superordinated system.

In case the connection between Pin 2 and Pin 3 is interrupted by opening the contact ,AK', a complete shutdown of the circulating pump and heater is effected, and the unit enters the condition "E OFF".

If the contact is reclosed, the instrument returns to the standby state and

"E OFF" is displayed. Press OK to start.



The standby function can be used in conjunction with the AUTOSTART feature


- 1. If the Autostart function is NOT turned ON, the standby input is used as described above.
- 2. If the Autostart function is enabled, the instrument will revert back to the original method of entering the setpoint (i.e. keypad, RS232, Analog input, etc.).

Entering the setpoint with the keypad. e.g. As described above, a bipolar shutdown is accompanied by displaying the "E OFF" state. The circulator starts again when the contact is reclosed. The temperature of the bath fluid changed during the "E OFF" state.

Entering the setpoint with the programmer.

The display **E OFF** appears. The setpoint value and the time are both held at the current value. The temperature of the bath fluid will be held constant at this temperature. The programmer continues once the contact is reclosed.

Notice: This is not an actual shutoff feature.







Troubleshooting guide/error messages



Alarm with complete shutdown:

If one of the following failures occur a complete, all-pole shutdown of the heater and circulating pump is effected.



"La" lights up and a continuous signal sounds.

The code for the cause of alarm is indicated on the VFD COMFORT-DISPLAY.





Alarm without shutdown:

The code for the cause of alarm is indicated on the VFD COMFORT-DISPLAY. The warning signal sounds in regular intervals. The messages appear every 10 seconds.



Press the key **OK** to stop the signal

ALARM COJE O I	Error message with ticker: >LOW LEVEL ALARM-FILL MEDIUM < Low level alarm		
	The circulator is operated without or insufficient bath fluid. Switch the unit off with the mains switch, refill bath fluid and switch on!		
	Tube breakage has occurred (insufficient filling level of bath fluid caused by pumping-out) Replace the tubing and refill bath liquid.		
	The float is defect (e.g. transport damage). Repair by authorized JULABO service personnel.		
ALARM COJE OZ	Error message with ticker: > REFRIGERATOR ALARM-CHECK CONNECTION < During the self-test after switch-on a short –circuit is detected between pin 2 and pin 4 of the control line or the control line was disconnected during operation. Reconnect the control line or repair short-circuit.		
WARNING COJE 03 ALARM	Error message with ticker: > EXCESS TEMPERATURE WARNING-CHECK LIMITS < Excess temperature warning		
	or Excess temperature alarm Type of warning: set to >warning< or >alarm< (refer to page 39)		
WARNING COJE OY ALARM COJE OY	Error message with ticker: > LOW TEMPERATURE WARNING-CHECK LIMITS < Low temperature warning or Low temperature alarm. Typ of warning: set to >warning< or >alarm< (refer to page 39)		

Error message with ticker:

RLRRM

EDIE DS

> WORKING SENSOR ALARM-CALL SERVICE <

Cable of working temperature sensor is disconnected or short-circuited.

	HE_
ALARM COJE OS	Error message with ticker: >SENSOR DIFFERENCE ALARM-CHECK VISCOSITY AND PUMP STAGE< Defect of working or excess temperature protector. Working temperature sensor and excess temperature protector report a temperature difference of more than 35 K.
ALARM COJE OT	Error message with ticker: > INTERNAL HARDWARE ERROR-CALL SERVICE < Other errors
ALARM EDJE 12	Error in A/D converter
ALARM EDJE 14	Error message with ticker: > EXCESS TEMPERATURE PROTECTOR ALARM-CHECK ADJUSTMENT < Excess temperature protector defect. The protection temperature is below the set working temperature setpoint. Set the protection temperature to a higher value.
ALARM EDJE 15	Error message with ticker: > EXTERNAL SENSOR ALARM-CHECK EXTERNAL SENSOR < External control was set but the Pt100 external senor was not connected or is defect.
WARNING COJE 20	Error message with ticker: > CLEAN CONDENSER OR CHECK COOLING WATER < Insufficient cooling of condenser. Clean the air-cooled condenser. Check the flow and the temperature of the cooling water of a water-cooled condenser.
WARNING EDJE 21	Error message with ticker: > COMPRESSOR FAILURE-CHECK REFRIGERATOR < Stage 1 of the compressors does not work. Automatic restart after short cool-down, message E 21 goes off.
WARNING EDJE 22	Stage 2 of the compressor does not work. Cooling machine – overload protection The driving motor of the cooling compressor is equipped with an overload protection which is triggered by increased internal_temperatures or excessive current consumption. Shutdown can be caused by insufficient ventilation, insufficient wall distance, soiled condenser, high room temperature switching off and on in short sequence
WARNING COJE 23	Excess temperature in stage 1 of the compressor.
HARNING COJE 24	Excess temperature in stage 2 of the compressor.
HARNING COJE 25	Short circuit of control line to cooling machine during self-test.

ALARM COJE 33	Error message with ticker: > SAFETY SENSOR ALARM-CALL SERVICE <
	The cable of the excess temperature protector has been disconnected or short-circuited
ALARM COJE 38	Ext. Pt100 sensor input without signal, but setpoint programming set to external Pt100.
WARNING EDIE 40	Error message with ticker: > LOW LEVEL WARNING-FILL MEDIUM < The early warning system for low level reports a critical fluid level. Refill bath fluid.



By quickly switching off and restarting the unit the alarm is cancelled. If the error occurs once more after the restart, a remote diagnosis is required.



Error message with ticker:

> CONFIGURATION ERROR-PRESS OK<

The configuration of the circulator does not correspond with its current application.

Press the **OK** key for a non-recurring, automatic change of the configuration.

In this case please call the JULABO Technical Service or an authorized dealer.

Disturbances that are not indicated.

The electronic pump motor is overload-protected by an electronic current limiter. If viscosity of the bath fluid is or becomes too high, the motor stops running.



Warning:

Before exchanging the fuses, turn off the mains power switch and disconnect the power plug from the mains socket!

Only use fine fuses with a nominal value as specified.



The mains fuses on the rear of the unit may easily be exchanged as shown on the left.

Circulator: Fine fuses T 16 A, dia.5 x 20 mm Cooling machine: Fuse T 10.0 A, dia.5 x 20 mm

Example:

Manufacturer	Supplier	Туре	Order No.
Schurter	Schurter	G-fuse insert SPT	No. 0001.2516
		T16A 5x20mm	
Wickmann	Wickmann	G- fuse insert	No. 19195
		T10,0A 5x20 mm	

Electrical connections



Notice:

Use shielded cables only.


The shield of the connecting cable is electrically connected to the plug housing. The unit ensures safe operation if connecting cables with a maximum length of 3 m are used. The use of longer cables does not affect proper performance of the unit, however external interferences may have a negative impact on safe operation (e.g. cellular phones).



Socket for external Pt100 sensor

Pin assignment:


Pin	Signal
1	l+
2	U+
3	U-
4	I-



The shield of the connecting cable is electrically connected to the plug housing and the sensor tube.

RS232 serial interface

This port can be used to connect a computer with an RS232 cable for remote control of the circulator.



Pin assignments RS232:

Pin 2	RxD	Receive Data
Pin 3	TxD	Transmit Data
Pin 5	0 V	Signal GND
Pin 7	RTS	Request to send
Pin 8	CTS	Clear to send

Pin 1; 4; 6, 9 Reserved - do not use!

RS232 interface cable

Circulator (9-pol)		PC (9-pol)
Pin 2 RxD	\Leftrightarrow	Pin 3 TxD
Pin 3 TxD	\Leftrightarrow	Pin 2 RxD
Pin 5 GND	\Leftrightarrow	Pin 5 GND
Pin 7 RTS	\Leftrightarrow	Pin 8 CTS
Pin 8 CTS	\Leftrightarrow	Pin 7 RTS


USB interface adapter cable

Accessories:	Order No.	Description
	8 980 073	RS232 interface cable 9-pol./9-pol., 2,5 m

8 900 110

常/Control output

The connector may only be used for control of a JULABO refrigerated circulator or JULABO MVS Solenoid valve controller for cooling water.



Pin assignment:

Pin Signal (only with attached JULABO equipment)


+24 V (I max. current 25 mA) 1

2 0 V

3 Alarm relay

4 Reserved - do not use!

5 Cooling pulse




Alarm output

(for external alarm signal)

This potential-free change-over contact is activated in case of an alarm when pins 2 and 3 are connected.

Switching capacity max. 30 W/40 VA Switching voltage max. 125 V~/-Switching current max. 1 A Functional description see page 74




STAND-BY input

(for external emergency switch-off)

Pin assignment:	<u>Pin</u>	Signal
	1	not connected
	2	5 V/DC
	3	0 V

Functional description see page 6



Programmer input/temperature recorder output

Pin		Signal	
1	Voltage output	Channel 1	0 10 V
2	Voltage output	Channel 2	0 10 V
3	GND for outputs		0 V
4	Programmer input	EPROG	0 to 10 V/0 to 20 mA
5	Current output	Channel 3	0 to 20 mA/4 to 20 mA
6	GND for Progammer		0 V

Functional description see page 71

12. Remote control

12.1. Setup for remote control



 Check the interface parameters for both interfaces (on circulator and PC) and make sure they match.

(Serial interface refer to page 58)

2. In the menu > MENU CONFIG < set

3. Connect both units with an interface cable...



Like all parameters which can be entered through the keypad, interface parameters are stored in memory even after the circulator is turned off.

12.2. Communication with a PC or a superordinated data system

If the circulator is put into remote control mode via the configuration level, the VFD COMFORT-DISPLAY will read "R -OFF-" = REMOTE STOP. The circulator is now operated via the computer.

In general, the computer (master) sends commands to the circulator (slave). The circulator sends data (including error messages) only when the computer sends a query.



In remote control mode, the start command and all values to be set must be resent by the PC via the interface in case of a power interruption. AUTOSTART is not possible.

A transfer sequence consists of:

- command
- space (⇔; Hex: 20)
- parameter (decimal separation with a period)
- end of file (∠; Hex: 0D)

The commands are divided into in and out commands.

in commands: retrieve parameters out commands: set parameters

Important times for a command transmission:



To ensure a safe data transfer, the time gap between two commands should be at least 250 ms.

The circulator automatically responds to an **in** command with a data string followed by a LF (Line Feed). The next command should only be sent after 10 ms.

The out commands are valid only in remote control mode.



Command to set the working temperature > SETPNT 1< to 55.5 $^{\circ}\text{C}$

OUT_SP_00 ⇔ 55.5. □

Command to retrieve the working temperature > SETPNT 1< $IN_SP_00 \rightarrow Response$ from the circulator: 55.5 \rightarrow



12.3. List of commands

OUT commands: Setting temperature values or parameters.

Command	Parameter	Response of circulator	
OUT_MODE_01	0	Use working temperature > SETPNT 1<	
OUT_MODE_01	1	Use working temperature > SETPNT 2<	
OUT_MODE_01	2	Use working temperature > SETPNT 3<	
OUT_MODE_02	0	Selftuning "off". Temperature control by using the stored parameters.	
OUT_MODE_02	1	Selftuning "once" Single selftuning of controlled system after the next start.	
OUT_MODE_02	2	Selftuning "always" Continual selftuning of controlled system whenever a new setpoint is to be reached.	
OUT_MODE_03	0	Set external programmer input to voltage. Voltage 0 V 10 V	
OUT_MODE_03	1	Set external programmer input to current. Current 0 mA 20 mA	
OUT_MODE_04	0	Temperature control of internal bath.	
OUT_MODE_04	1	External control with Pt100 sensor.	
OUT_MODE_05	0	Stop the unit = R –OFF	
OUT_MODE_05	1	Start the unit.	
OUT_MODE_08	0	Set the control dynamics - aperiodic	
OUT_MODE_08	1	Set the control dynamics - standard	
OUT_SP_00	XXX.XX	Set working temperature. "SETPNT 1"	
OUT_SP_01	xxx.xx	Set working temperature. "SETPNT 2"	
OUT_SP_02	xxx.xx	Set working temperature. "SETPNT 3"	
OUT_SP_03	xxx.xx	Set high temperature warning limit "OverTemp"	
OUT_SP_04	xxx.xx	Set low temperature warning limit "SubTemp"	
OUT_SP_06	xxx.xx	Set manipulated variable for the heater via serial interface -99.99 +100 [%]	
OUT_SP_07	х	Set the pump pressure stage. (1 4)	
OUT_PAR_04	x.x	CoSpeed for external control 0 5.0	
OUT_PAR_06	xxx	Xp control parameter of the internal controller. 0.1 99.9	
OUT_PAR_07	xxx	Tn control parameter of the internal controller. 3 9999	
OUT_PAR_08	xxx	Tv control parameter of the internal controller. 0 999	
OUT_PAR_09	xxx	Xp control parameter of the cascade controller. 0.1 99.9	
OUT_PAR_10	xxx	Proportional portion of the cascade controller. 1 99.9	
OUT_PAR_11	xxx	Tn control parameter of the cascade controller. 3 9999	

Command	Parameter	Response of circulator	
OUT_PAR_12	xxx	Tv control parameter of the cascade controller. 0 999	
OUT_PAR_13	xxx	Maximum internal temperature of the cascade controller.	
OUT_PAR_14	xxx	Minimum internal temperature of the cascade controller.	
OUT_PAR_15	xxx	Band limit (upper) 0 200 °C	
OUT_PAR_16	xxx	Band limit (lower) 0 200 °C	
OUT_HIL_00	-xxx	Set the desired maximum cooling power (0 % to 100 %). Note: Enter the value with a preceding negative sign! This adjustment only makes sense if FP refrigerating units are used.	
OUT_HIL_01	xxx	Set the desired maximum heating power (10 % to 100 %).	

IN commands: Asking for parameters or temperature values to be displayed.

Command	Parameter	Response of circulator
VERSION	none	Number of software version (V X.xx)
STATUS	none	Status message, error message (see page 85)
IN_PV_00	none	Actual bath temperature.
IN_PV_01	none	Heating power being used (%).
IN_PV_02	none	Temperature value registered by the external Pt100 sensor.
IN_PV_03	none	Temperature value registered by the safety sensor.
IN_PV_04	none	Setpoint temperature of the excess temperature protection
IN_SP_00	none	Working temperature "SETP 1"
IN_SP_01	none	Working temperature "SETP 2"
IN_SP_02	none	Working temperature "SETP 3"
IN_SP_03	none	High temperature warning limit "OverTemp"
IN_SP_04	none	Low temperature warning limit "SubTemp"
IN_SP_05	none	Setpoint temperature of the external programmer (REG+E-PROG) .
IN_SP_07	none	 Adjusted pump stage in the -OFF- condition. Pump stage corresponding to the effective rotation speed after start.
IN_SP_08	none	Value of a flowrate sensor connected to the E-Prog input
IN_PAR_00	none	Temperature difference between working sensor and safety sensor
IN_PAR_01	none	Te - Time constant of the external bath.
IN_PAR_02	none	Si - Internal slope
IN_PAR_03	none	Ti - Time constant of the internal bath.

Command	Parameter	Response of circulator
IN_PAR_04	none	CoSpeed - Band limit (max. difference between the temperatures in the internal bath and external system).
IN_PAR_05	none	Factor pk/ph0: Ratio of max. cooling capacity versus max. heating capacity
IN_PAR_06	none	Xp control parameter of the internal controller.
IN_PAR_07	none	Tn control parameter of the internal controller.
IN_PAR_08	none	Tv control parameter of the internal controller.
IN_PAR_09	none	Xp control parameter of the cascade controller.
IN_PAR_10	none	Proportional portion of the cascade controller.
IN_PAR_11	none	Tn control parameter of the cascade controller.
IN_PAR_12	none	Tv control parameter of the cascade controller.
IN_PAR_13	none	Adjusted maximum internal temperature of the cascade controller.
IN_PAR_14	none	Adjusted minimum internal temperature of the cascade controller.
IN_PAR_15	none	Band limit (upper)
IN_PAR_16	none	Band limit (lower)
IN_MODE_01	none	Selected setpoint: 0 = SETP 1 1 = SETP 2 2 = SETP 3 3 = Last setpoint setting was carried out through an external programmer
IN_MODE_02	none	Selftuning type: 0 = Selftuning "off" 1 = Selftuning "once" 2 = Selftuning "alwayS"
IN_MODE_03	none	Type of the external programmer input: 0 = Voltage 0 V to 10 V 1 = Current 0 mA to 20 mA
IN_MODE_04	none	Internal/external temperature control: 0 = Temperature control with internal sensor. 1 = Temperature control with external Pt100 sensor.
IN_MODE_05	none	Circulator in Stop/Start condition: 0 = Stop 1 = Start
IN_MODE_08	none	Adjusted control dynamics 0 = aperiodic 1 = standard
IN_HIL_00	none	Max. cooling power (%).
IN_HIL_01	none	Max. heating power (%).

12.4. Status messages

Status messages	Description
00 MANUAL STOP	Circulator in "OFF" state.
01 MANUAL START	Circulator in keypad control mode.
02 REMOTE STOP	Circulator in "r OFF" state.
03 REMOTE START	Circulator in remote control mode.

12.5. Error messages

12.0. Error messages	
Error messages	Description
-01 LOW LEVEL ALARM	Low liquid level alarm.
-02 REFRIGERATOR ALARM	Control cable of the refrigerated circulator or MVS solenoid valve controller short-circuited or interrupted.
-03 EXCESS TEMPERATURE WARNING	High temperature warning.
-04 LOW TEMPERATURE WARNING	Low temperature warning.
-05 WORKING SENSOR ALARM	Working temperature sensor short-circuited or interrupted.
-06 SENSOR DIFFERENCE ALARM	Sensor difference alarm. Working temperature and safety sensors report a temperature difference of more than 35 K.
-07 I ² C-BUS ERROR	Internal error when reading or writing the I ² C bus.
-08 INVALID COMMAND	Invalid command.
-09 COMMAND NOT ALLOWED IN CURRENT OPERATING MODE	Invalid command in current operating mode.
-10 VALUE TOO SMALL	Entered value too small.
-11 VALUE TOO LARGE	Entered value too large.
-12 TEMPERATURE MEASUREMENT ALARM	Error in A/D converter.
-13 WARNING : VALUE EXCEEDS TEMPERATURE LIMITS	Value lies outside the adjusted range for the high and low temperature warning limits. But value is stored.
-14 EXCESS TEMPERATURE PROTECTOR ALARM	Excess temperature protector alarm
-15 EXTERNAL SENSOR ALARM	External control selected, but external Pt100 sensor not connected.
-20 WARNING: CLEAN CONDENSOR OR CHECK COOLING WATER CIRCUIT OF REFRIGERATOR	Cooling of the condenser is affected. Clean air-cooled condenser. Check the flow rate and cooling water temperature on water-cooled condenser.
-21 WARNING: COMPRESSOR STAGE 1 DOES NOT WORK	Compressor stage 1 does not work.
-22 WARNING: COMPRESSOR STAGE 2 DOES NOT WORK	Compressor stage 2 does not work.
-23 WARNING: HIGH TEMPERATURE ON COMPRESSOR STAGE 1	Excess temperature on compressor stage 1.


Error messages	Description
-24 WARNING: HIGH TEMPERATURE ON COMPRESSOR STAGE 2	Excess temperature on compressor stage 2.
-25 REFRIGERATOR WARNING	Error in the cooling machine.
-26 WARNING: STAND-BY PLUG IS MISSING	External standby contact is open. (see page 74 and 80)
-30 CONFIGURATION ERROR: CONFIRM BY PRESSING <ok> ON CIRCULATOR</ok>	The configuration of the circulator does not conform to its present use. Press >OK< to automatically perform a single modification of the configuration.
-33 SAFETY SENSOR ALARM	Excess temperature sensor short-circuited or interrupted.
-38 EXTERNAL SENSOR SETPOINT PROGRAMMING ALARM	Ext. Pt100 sensor input without signal and setpoint programming set to external Pt100.
-40 NIVEAU LEVEL WARNUNG	Low liquid level warning in the internal reservoir.

Installation of electronic module 13.



Caution:

Always turn off the unit and disconnect the mains cable from the power source before performing any service or maintenance procedures, or before moving the unit. Configuration, installation, maintenance and repairs on the circulator may only be carried out by qualified personnel.



- Turn off the unit with the mains switch and disconnect the power plug.
- Open the screws (A) and remove the dummy plate.
- Carefully insert the upper edge (B) into the rear panel from below, align the electronic module at top and bottom and applying light pressure connect the 15-pole connector.
- Attach the electronic module using the screws (A).
- The circulator is ready for use. It automatically recognizes the installed electronic module.

14. JULABO Service – Online remote diagnosis

JULABO circulators of the HighTech series are equipped with a black box. This box is implemented in the controller and records all significant data for the last 30 minutes.


In case of a failure, this data can be read out from the unit by using special software. This software is available as a free download from \ EasyBlackBox.

- Installation is easy and is performed step by step. Please observe the instructions.
- Data read-out is possible in the conditions "OFF". "R OFF" or "ALARM".
- Connect the circulator to the computer using an interface cable.
- Start the EasyBlackBox program. The program asks for the port used (COM1,) and the baud rate of the unit.

You do not have this information on hand? Simply try it out! The program continues to send the request until the correct settings are made.



- Data is read out and shown on the monitor divided into the sections
 - >Einstellungen/Settings<,
 - >Alarmspeicher/Alarms stored<,
 - >Blackbox<
 - see example
- After pressing >Speichern/Save<, a text file is created. The program suggests a filename ->C:\model description and barcode no.<. Modifications are possible.




Cleaning/repairing the unit



Caution:

- Always turn off the unit and disconnect the mains cable from the power source before cleaning the unit.
- Prevent humidity from entering into the circulator.
- Electrical connections and any other work must be performed by qualified personnel only.



To maintain the full cooling performance, clean the condenser from time to

- Switch off the unit, disconnect mains power cable.
- Hold the venting grid, pull out and remove.
- Clean the ribbed condenser with a vacuum cleaner.
- Replace the venting grid.
- Switch on the unit.

Cleaning:

For cleaning the bath tank and the immersed parts of the circulator, use low surface tension water (e.g., soap suds).

Clean the outside of the unit using a wet cloth and low surface tension water.

The circulator is designed for continuous operation under normal conditions. Periodic maintenance is not required.

The tank should be filled only with a bath fluid recommended by JULABO. To avoid contamination, it is essential to change the bath fluid from time to time.

Repairs

Before asking for a service technician or returning a JULABO instrument for repair, please contact an authorized JULABO service station.

When returning the unit:

- Clean the unit in order to avoid any harm to the service personnel.
- Attach a short fault description.
- During transport the unit has to stand upright. Mark the packing correspondingly.
- When returning a unit, take care of careful and adequate packing.
- JULABO is not responsible for damages that might occur from insufficient packing.



JULABO reserves the right to carry out technical modifications with repairs for providing improved performance of a unit.