


INSTRUCTION MANUAL

ENGLISH



FEATURES

- 3 ¾ digit, 4000 count LCD display
- Auto-ranging with manual ranging capability
- MIN/MAX (Peak Hold). All ranges except capacitance & frequency.
- Frequency, duty cycle, data hold
- Auto power off
- Dual display
- Built-in test lead storage
- Backlit display + Worklight (DL379B & DL389)
- Detachable current clamp head (DL379B & DL389)
- Temperature (DL379B & DL389)
- Magnetic mount (DL379B & DL389)
- True RMS measurement (DL389 only)

SAFETY NOTES

Warning

Refer to user guide regarding potential hazard and proper instructions. Before using this meter, read all safety information carefully. In this manual the word “WARNING” is used to indicate conditions or actions that may pose physical hazards to the user. The word “CAUTION” is used to indicate conditions or actions that may damage this instrument.

Warning

- Before each use, verify meter operation by measuring a known voltage or current.
- Never use the meter on a circuit with voltages that exceed the category based rating of this meter.
- Do not use this meter during electrical storms or in wet weather.
- Do not use the meter or test leads if they appear damaged.
- Keep your fingers away from the test lead’s metal probe contacts when making measurements.

- Ensure meter leads are fully seated and keep fingers away from metal probe contact when making measurements. Always grip the leads behind the finger guards molded into the probe.
- Do not open the meter to replace batteries while the probes are connected.
- Use caution when working with voltages above 60V DC or 25V AC RMS. Such voltages pose shock hazards.
- To avoid false readings that can lead to electrical shock, replace batteries if a low battery indicator appears.
- Unless measuring voltage or current, shut off and lock out power before measuring resistance or capacitance.
- Always adhere to national and local safety codes. Use proper personal safety equipment (PPE) to prevent shock and arc blast injury where hazardous live conductors are exposed.
- Always turn off power to a circuit or assembly under test before cutting, unsoldering or breaking the current path. Even small amounts of current can be dangerous.
- Always disconnect the live test leads before disconnecting the common test lead from the circuit.
- In the event of electrical shock, ALWAYS bring the victim to the emergency room for evaluation, regardless of victim’s apparent recovery. Electrical shock can cause unstable heart rhythms that may need medical attention.
- If any of the following occur during testing, turn off the power source to the circuit being tested: arching, flame, smoke, extreme heat, smell of burning materials or discoloration or melting of components.

Warning

Higher voltages and currents require greater awareness of physical safety hazards. Before connecting the test leads; turn off power to the circuit under test; set meter to the desired function and range; connect the test leads to the meter first, then connect to the circuit under test. Reapply power. If an erroneous reading is observed, disconnect power immediately and recheck all settings and connections.

Warning

This meter is designed for trade professionals who are familiar with the hazards of their trade. Observe all recommended safety procedures that include proper lock-out utilization and the user of personal protective equipment that includes safety glasses, gloves and flame resistant clothing.


Symbol Definitions

	Equipment is safe for connection and disconnection to Live conductors		Ground
	AC Alternating Current		Warning or Caution
	DC Direct Current		Double Insulation (Protection Class II)
	Not Applicable to Identified Model		Battery

Category Definitions

Measurement Category	Short-Circuit (typical) kA ^a	Location in the building installation
II	< 10	Circuits connected to mains socket outlets and similar points in the MAINS installation
III	< 50	Mains distributions parts of the building
IV	> 50	Source of the mains installation in the building

CONTROLS AND INDICATORS



1. Clamp jaw: Measure inductive AC current. Jaw opens to 1.25” (32mm).
2. Wire Separation Tab/NCV Sensor: Used to isolate an individual wire from a bundle for testing. NCV sensor helps detect live voltage.
3. Conductor Alignment Marks: Used to aid in the visual alignment of a conductor when measuring inductive amperage. Greatest accuracy is achieved when the conductor, inside the clamp, is centered at the intersection of these marks.
4. Test Lead Holder: Used for hands-free use of one of the test probes.
5. Hand Guard: Used as a point of reference for the operator’s safety.

Warning

Always keep your hands and fingers behind the hand guards when measuring current on exposed conductors. Contact may result in serious injury.

6. Clamp Lever: Opens and closes current clamp jaw.
NOTE: The clamp uses a high-tension spring to close the jaw. Do not allow fingers or objects to become pinched in the hinge as jaws close.
7. NCV (Non-Contact Voltage) Button: Activates non-contact voltage function. Dual level indication on DL379B only.
8. Range Button: Used to select range for upper and lower display readings.
9. Hold/Backlight Button: Freezes readings or activates backlight and worklight. (Worklight available on DL379B and DL389)
10. Min/Max Button: Activates MIN/MAX capture function, cycles through minimum and maximum values. Press and hold for 2 seconds to return to live readings.
11. Rotary Function Switch: Turns meter on and is used to select the range or function.
12. Upper Display: Used to display current when measuring with the clamp head, or UEi’s optional current hook adapter. Displays output from other accessories when connected to UEi’s meter base.
13. Lower Display: Used to display input to test lead jacks. Includes AC/DC volts, frequency, resistance, diode, capacitance and AC/DC microamps (µA).
14. Select Button: Used to choose a measurement mode from selections with multiple options such as AC or DC volts; AC or DC microamps; resistance, diode, capacitance or continuity; Fahrenheit or Celsius.
15. Temperature Input Jack: Input jack for K-type thermocouple probe (available on DL379B and DL389).
16. Temperature Input Jack Lock: Move switch down to measure temperature.
NOTE: Test leads must be removed from input jacks prior to operating the temperature function.
17. Hz/Duty Cycle Button: Used to toggle between frequency and duty cycle when in AC voltage measurement mode.
18. Common Terminal: The black test lead is plugged into this input jack to supply ground or “low” reference for all measurements.
19. Maximum Category Indicator: Indicates maximum voltage for the rated working category.

Warning


DO NOT exceed 1000V DC or AC RMS at either the common or

20. Multifunction Input Jack: Used for measuring AC/DC volts, frequency, duty cycle, resistance, diode, continuity, and capacitance.

Warning

Use CAT III listed test leads or higher. DO NOT attempt to measure more than 1000V DC, 750V AC or 2000µA DC.

Displays and Indicators



Location of function icons on display may vary by model number.

	AC indicator
	DC indicator
	Indicates a negative value (DC negative voltage)
	Maximum value displayed
	Minimum value displayed
	Displaying Amps from clamp jaw or adapter
	Displaying value from adapter
	Low battery indication
	Hold function
	Diode function
	Continuity function
	Capacitance function (nanofarads or microfarads)
	Microamps function (1µA is 0.000001 Amp)
	Frequency function
	Duty cycle function
	Millivolts function (1 mV is 0.001 Volt)
	Auto power off is active
	Auto Range mode is active
	Displayed if input value exceeds selected range
	Resistance function
	Degrees Fahrenheit
	Degrees Celsius



OPERATING INSTRUCTIONS

Auto Power Off

After powering off, the meter will turn on again when you change ranges, rotate the selector dial or press a button.

NOTE: The APO is disabled during MIN/MAX mode.

Backlight/Worklight (DL379B and DL389 only)

Press and hold the HOLD button for 2 seconds to activate. Lights automatically turn off in 2 minutes to save battery life.

NOTE: After activating the lights, quick press to activate the hold mode.

Automatic / Manual Range

The meter defaults to auto range mode and AT is indicated on the display while active. Press the RANGE button to cycle through available ranges. Selecting a specific range will put the meter in manual range mode and AT will no longer be displayed on screen. Press and hold the RANGE button to return to auto ranging mode.

NOTE: Manual ranging will provide a faster input response over auto range.


MIN/MAX

When using the MIN/MAX capture mode for amps, it is recommended that you first select the range of the expected maximum value. If this is not done it will lock in the lowest range for the initial measurement. If the maximum value exceeds this range the meter will capture O.L. as the maximum value.

Data Hold


Press the HOLD button to activate. This will freeze the reading and range in the display for review.

Measuring AC Amps




- Press SELECT to change between AC/DC
- Press RANGE to select range prior to using MAX/MIN.

NOTE: Max capture is useful for motor inrush current.




Measuring AC/DC Volts



- Press SELECT to change between AC/DC


Measuring Frequency or Duty Cycle



- Must be AC Volt or AC μ A mode
- Press HZ/DUTY to select and change between frequency or duty cycle

NOTE: Frequency greater than 1MHz will display 0.000

Measuring Resistance and Capacitance



Warning



DO NOT measure resistance on a live circuit.

Warning

Safely discharge capacitor before measurement.

NOTE: Leave meter connected to the capacitor for 10 seconds allowing the reading to settle. Larger capacitors could take up to 60 seconds.

Measuring Continuity and Diode




Press SELECT to change between continuity and diode

NOTE: Continuity tone sounds at approximately <50 Ω .

NOTE: Shows voltage drop if forward biased and O.L. if reversed biased.

Measuring Temperature (DL379B and DL389 only)




Warning

Disconnect test lead probes from voltage source and meter.

- Slide temperature input jack lock switch down prior to connecting temperature probe.

- Press SELECT to change between Fahrenheit or Celsius.

Temperature Calibration



- Connect temperature probe as directed above.

- Remove battery cover. Place temperature probe in a known standard temperature. Stirred crush ice in distilled water can be used for 32°F.

- Adjustments are made by accessing the potentiometer through the lower right access port in the battery compartment.

- Using a fine tip standard screwdriver, adjust the potentiometer to 32°F (0°C).

Measuring Non-Contact Voltage

- Press and hold the NCV button and move the sensor tip on the clamp head near the voltage source. Both a visual and audible alert will indicate voltage.

- The DL379B Hi/Lo NCV indicates LOW voltage at <120V and HIGH voltage at >120V.

- NOTE: The worklight will be disabled during NCV tests.

Attaching / Detaching Clamp Heads

- To detach the clamp head first unplug all test leads and probes. Firmly grab clamp head and base and pull apart. When attaching a clamp head or attachment, align heads and push together ensuring the heads lock together securely.

NOTE: Leaving clamp head or attachment plugged in will drain battery.

PERIODIC SERVICE

Warning

Repair and service of this instrument is to be performed by qualified personnel only. Improper repair or service could result in physical degradation of the meter, altering the protection from electrical shock and personal injury this meter provides to the operator. Perform only the maintenance task you are qualified to do.

Cleaning

Periodically clean your meter's case using a damp cloth. DO NOT use abrasive, flammable liquids, cleaning solvents or strong detergents as they may damage the finish, impair safety or affect the reliability of the structural components.

Battery Replacement

Remove screws from battery compartment cover on back of meter and remove cover. Replace batteries with fresh batteries paying attention to polarity position. Replace cover and screws.

SPECIFICATIONS

DC Volts

Range	Resolution	Accuracy	Overload Protection
400mV	0.1mV	$\pm(0.5\% + 4 \text{ dgts})$	1000V RMS
4V	1mV		
40V	10mV		
400V	100mV		
1000V	1V	$\pm(0.8\% + 10 \text{ dgts})$	

AC Volts (45Hz to 400Hz)

Range	Resolution	Accuracy	Overload Protection
400mV	0.1mV	$\pm(2.0\% + 5 \text{ dgts})$	750V RMS
4V	1mV		
40V	10mV		
400V	100mV		
750V	1V		

AC Amps Measurement - Jaw Input (45~400Hz)

Range	Resolution	Accuracy	Overload Protection
40A	0.01A	$\pm(2.9\% + 15 \text{ dgts})$	400A
400A	0.1A	$\pm(1.9\% + 8 \text{ dgts})$	

DL369: 400A range only

DL389: 45Hz to 400Hz True RMS (Crest factor<3:1)

DC Low Amps Measurement (Test Lead Input)

Range	Resolution	Accuracy	Overload Protection
400 μ A	0.01 μ A	$\pm(1.2\% + 3 \text{ dgts})$	2000 μ A/600V RMS
2000 μ A	0.1 μ A		

AC Low Amps Measurement (Test Lead Input 45Hz to 400Hz)

Range	Resolution	Accuracy	Overload Protection
400 μ A	0.01 μ A	$\pm(2.0\% + 5 \text{ dgts})$	2000 μ A/600V RMS
2000 μ A	0.1 μ A	$\pm(1.5\% + 5 \text{ dgts})$	

DL389: 45Hz to 400Hz True RMS (Crest factor<3:1)

Resistance

Range	Resolution	Accuracy	Overload Protection
400 Ω	100m Ω	$\pm(1.0\% + 4 \text{ dgts})$	600V RMS
4k Ω	1 Ω		
40k Ω	10 Ω		
400k Ω	100 Ω		
4M Ω	1k Ω	$\pm(2.0\% + 4 \text{ dgts})$	
40M Ω	10k Ω		

Capacitance Measurement

Range	Resolution	Accuracy	Overload Protection
40nF	0.01nF	$\pm(3.5\% + 6 \text{ dgts})$	600V RMS
400nF	0.1nF		
4 μ F	0.001 μ F		
40 μ F	0.01 μ F		
400 μ F	0.1 μ F		
4000 μ F	1 μ F		

DL379B: Capacitance range to 2000 μ F

Diode Test

Range	Open Circuit V	Test Current	Overload
2.0V	<1.6V DC	0.25mA	600V RMS

Frequency Measurement

Range	Resolution	Accuracy	Overload Protection
9.999Hz	0.001Hz	$\pm(0.1\% + 4 \text{ dgts})$	600V RMS
99.99Hz	0.01Hz		
999.9Hz	0.1Hz		
9.999kHz	1Hz		
99.99kHz	10Hz		
199.9kHz	100Hz		

Minimum Frequency: 0.5Hz, DC V offset should be zero

Sensitivity: >10% of each AC Volt range except 4V (>20%) range only

Temperature Measurement

Range	Resolution	Accuracy	Overload Protection
-22° ~ 14°F	0.1°F	$\pm(1.0\% + 5.4^\circ\text{F})$	30V RMS
15° ~ 752°F		$\pm(1.0\% + 3.6^\circ\text{F})$	
(-30° ~ -10°C)	(0.1°C)	$\pm(1.0\% + 3.0^\circ\text{C})$	
(-9° ~ 400°C)		$\pm(1.0\% + 2.0^\circ\text{C})$	

Duty (%) Cycle Measurement

Range	Accuracy	Overload Protection
01. to 99.9%	$\pm(0.2\% \text{ per kHz} + 0.1\%) + 5 \text{ counts}$	600V RMS

0.5Hz to 100kHz (pulse width >2 μ sec)

Continuity Measurement

1.888.610.7664



www.calcert.com

sales@calcert.com