


Quick Start

Leica DISTO™ X1



- 1 Display
- 2 ON/Measure
- 3 Add
- 4 Clear/OFF
- 5 Measuring Reference
- 6 Functions/Settings
- 7 Subtract

- when it has to be right

Leica
Geosystems

FUNC

2 sec.

Settings

FUNC


2 sec.

1.1

UNIT


0.000 m
0.0000 m
0.000 in


0.00 ft
0'00" 1/32
0 in 1/32


FUNC / 

→ 2.1

BLUETOOTH





→ 


FUNC / 

→ 3.1

NFC





→ 

FUNC / 

→ 4.1

BEEP



→ 


+


-


Change settings in submenu / turn function ON/OFF

FUNC




2 sec.









User Manual:



→ ON



→ OFF

2 sec.

