


Tubing and Plastic Pipe Cutters

Tubing: Nos. 151, 152, 153, 154 and 156

Plastic Tubing and Plastic Pipe: Nos. 151-P, 152-P, 154-P and 156-P Capacity: 1/4" through 6 5/8" O.D.



Ref. No.	Description	151 1 _{/4"-1} 5/8"O.	152 D. ¹ /4"-2 ⁵ /8"O.D.	153 1/4"-3 ¹ /2"O.D.	154 1 ⁷ /8"-4 ^{1/} 2"O.D.	156 4"-6 ⁵ /8"O.D.
1	. Roller (Large)	. 32097 (2) 34670	(2) 34670 (2)	32102 (2)	32102 (2)	
		. 32107 (2) 32112	. ,			
3	. Frame	32017 3202	2 32962 .	32027	32032	
		33122 3215				
		32067 32072				
	, ,	34190 3419				
7	. Latch Pin	32122 3212	7 32127 .	32132	32132	
	` ''' '	33185 3318				
		32142 3214				
	- 1	74740 7474				
		32037 3204				
		32087 3208				
	3	32077 3208				
		32162 3216				
15	Feed Screw Assy	32052 3205	57 32057 .	32062 .	32062	
	. (Incl. Ref. #14)					
	` '	34665	` '			
17	Reamer Blade Kit	32172 3217	72			
	Reversible Knob . (Incl. Ref. #19)	33177 3318	32 33182			
19	Washer Screw	34750 3475	50 34750			
		151-P	152-P	153-P	154-P	156-P
	Description	1/4"-1" O.D.	1/4"-2" O.D.	1/4"-3-1/2"O.D.	1-7/8"-4" O.D.	4"-6" O.D.
	Cutter Wheel (Plastic	:) 74720 747	20 74720	74730	74735	

NOTE: 1. All parts for the P-Series Cutters are the same as the Quick-Acting except for those parts listed.

2. 151-P and 152-P can cut thin wall PVC and flexible plastic when using the 33200 Cutter Wheel.





Quick-Acting Tubing Cutter Operating Instructions

- This Cutter is designed to make clean, accurate cuts of copper, brass, alu-minum, steel tubing and plastic pipe (see chart below for correct wheel application).
- Open Cutter by depressing Release Nut. Place pipe or tube on Rolls. Advance Wheel by pushing Feed Knob toward tube or pipe. Turn Feed Knob clockwise until firm contact is made.
- Copper, Other Metallic Tube. Revolve Cutter around tube and at the end of each revolution turn Feed Knob slightly clockwise (about 1/16 of a turn). Repeat until cut is complete
- PE, PB, PP (Soft) Plastic Pipe. Advance Cutter Wheel into material 1/2 rotation of Feed Knob. Rotate Cutter two full rotations around pipe. Continue cut as with copper.

PVC, ABS (Hard) Plastic Pipe.

Advance Cutter Wheel into pipe 1/4 rotation of Feed Knob. Rotate Cutter two full rotation around pipe. Continue cut as with copper.






Cutter Wheels Application Chart For Quick-Acting Cutters

Material	151-(P)	152-(P)	153-(P)	154-(P)	156-(P)
Copper, Brass &	33185	33185	33185	33170	33170
Aluminum Tubing	E-3469†	E-3469†	E-3469†	E-2558†	E-2558†
Steel, SS,	33190	33190	33190	33175	33175
Tubing	E-4546	E-4546	E-4546	E-2191	E-2191
PE, PP, PB (Soft)	74720	74720	74720	74730	74735
Plastic Pipe	E-2155*	E-2155*	E-2155*	E-2156*	E-2157*
PVC, ABS (Hard)	33195	33195	33195	33180	33180
Plastic Pipe	E-5272	E-5272	E-5272	E-5299	E-5299
Aluminum Pipe	34695	34695	34695	33170	33170
	E-3495	E-3495	E-3495	E-2558	E-2558†

Std. Wheel * Std. Wheel (-P) Models See Ridge Tool Catalog for Additional Wheel Options



KNOB ENDVIEWS

NOTE: 151, 151-P, 152, 152-P, 153, 153-P Quick Acting Cutters have a reversible knob. Knob is designed to stop cutter wheel short of the rolls. Orient "PE/PVC" outward for plastic or "CU" outward for copper.

Printed in U.S.A. 999-998-723