

ICON Lite Kit



Transmitter Configuration Kit with USB Communication



The ICON Lite Kit is for communication to the latest series of INOR transmitters - Models C/R 202, MINIPAQ-HLP/L, C/R 330, C/R 520 and C/R 530. The kit contains the INOR USB Interface, PC to USB Interface cable, USB Interface to Transmitter cable, and storage bag.


Communication with the connected transmitter is established automatically, without any problems to match the PC communication port to the software.

- USB communication
- Automatic matching of communication ports
- Automatic transmitter identification for quick start up
- Diagnostic LED's on the USB Interface show the communication status
- Simple installation of configuration software and drivers for the USB Interface
- User Instructions and Installation Guide included (on USB memory stick)
- Free download of configuration software, Consoft, and USB Interface software from our website

Specifications:

Input (PC to USB Interface)	USB cable
Output (USB Interface to transmitter)	Changeable transmitter cables
Power Supply	From USB port
Ambient temperature	
Operation	0 to 50 °C / 32 to 122 °F
Storage	-20 to 70 °C / -4 to 140 °F
Humidity	0 to 90 % RH
Galvanic isolation	1500 VAC
USB compliance	USB v.1.1 and USB v.2.0
System requirements	
Windows	
Display resolution	Min. 800 x 600
Hard drive space	50 MB

Connection cables



PC to USB
Interface

Part No:
70KAB49817



USB Interface to
IPAQ C/R 201
MinIPAQ-HLP/-L
IPAQ C/R 330
IPAQ C/R 520 & C/R 530 HART

USB Interface




Diagram of a USB port with a 26/1 dimension line and a mm/inch switch.

Ordering information

ICON Complete Configuration Kit 70CFGUS101
Separate parts See above