


**Measurements:**

The **AccuMASTER Digital Fraction 6" Caliper** can perform four different measurements.

- ❶ External
- ❷ Internal
- ❸ Step
- ❹ Depth

**Functions:**

- **Frac/Inch/mm** - Sets caliper's display for fractions, decimal inches or millimeters.
- **0** - Sets display to zero at any selected position of the caliper.
- **On** - Turns on power. The caliper defaults to a setting of 0.00.
- **Off** - Turns off power. The auto shut-off will automatically turn off power after 5 to 7 minutes of inactivity.

**Battery Replacement:**

Turn **Off** caliper. Remove locking screw and battery door on the top of the unit. Replace CR2032 (or equivalent) battery, positive side down in clip. Replace battery door and locking screw.

**IP54 Certified:**

- Splashing water, oil and dust-resistant

**CALCULATED INDUSTRIES**

UG7408E-A