



DIGITAL EARTH TESTER KEW 4105DL / KEW 4105DL-H



KEW 4105DL / 4105DL-H Specifications

Ea	th resistance measurement	20Ω	200Ω	2000Ω
	Measuring range	0.00 - 2000 Ω		
	Display range	0.00 - 20.99 Ω	0.0 - 209.9 Ω	0 - 2099 Ω
	Accuracy*1	±1.5%rdg±0.08 Ω*2	±1.5%rdg±4dgt	
	Auxiliary earth resistance*3	<10 kΩ	<50 kΩ	<100 kΩ
	Comparator reference value	10 Ω	100 Ω	500 Ω
Earth voltage measurement				
	Measuring range	0.0 - 300.0 V AC (45 - 65Hz) / ±0.0 - ±300.0 V DC		
	Display range	0.0 - 314.9 V		
	Accuracy ±1%rdg±4dgt			
Ap	plicable Standards	IEC 61010-1 CAT IV 100 V / CAT II 150 V / CAT II 300 V Pollution degree 3		
		IEC 61010-2-030, IEC 61010-031, IEC 61557-1, -5		
		IEC 60529 IP67, IEC 61326-1, -2-2 (EMC), EN50581 (RoHS)		
Power source		LR6 (AA)(1.5V)×6		
Dimensions		121(L)×188(W)×59(H) mm (including case lid)		
W	eight	Approx. 690g (including batteries and case lid)		
	cessories for 4105DL	7267 (Cable reel for Earth resistance tester (red))		
(C	able Reel Set Model)	7268 (Cable reel for Earth resistance tester (yellow))		
		7271 (Earth resistance test leads)		
		7127B (Simplified measurement probe)		
		8041 (Auxiliary earth spikes[2 spikes / 1set]), 9121 (Shoulder strap)		
		9190 (Carrying case), LR6 (AA)×6, Instruction manual		
Ac	cessories for 4105DL-H	7266 (Earth resistance test leads [red-20m, yellow-10m, green-5m / 1set])		
(H	ard Case Model)	7127B (Simplified measurement probe)		
		8041 (Auxiliary earth spikes[2 spikes / 1set]), 9121 (Shoulder strap)		
		9191 (Hard case), LR6 (AA)×6, Instruction manual		
Op	otional	7272 (Precision measurement Cord set)		
		8259 (Adapter for mea	surement terminal)	

- *1 For precision measurement, auxiliary earth resistance should be 100 Ω ±5% or less.
- $^{*2}\,\text{At}$ simplified measurement add $\pm 0.10~\Omega$ to the specified accuracy.
- *3 Accuracy within the auxiliary earth resistance: ±5%rdg±10dgt.

4105DL Included Accessories



4105DL-H Included Accessories



Strong noise rejection!



Noise rejection up to 25V rms allows accurate testing in noisy environments.

Earth voltage warning

A red LED comes on if an external voltage is detected.



[LED light comes on if:]

Frequency	Voltage	
0 – 10Hz	> 10 V	
10 – 100Hz	> 25 V	
100 – 400Hz	> 5 V	

Robust steel made earth spikes



Earth measurements are possible up to 100kΩ* of auxiliary earth spikes resistance.

Auxiliary earth resistance check

4105DL checks if the auxiliary earth resistance is:

Too high at S(P) terminal



Too high at H(C) terminal



Within allowable range (Green LED OK)



Optional Accessories








7268







Adapters for measurement terminals



8259



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

For inquires or orders :

1.888.610.7664



www.calcert.com

sales@calcert.com

[%] 20 Ω range 10 k Ω , 200 Ω range 50 k Ω , 2000 Ω range 100 k Ω .