





PDA2901/2904 ASSEMBLY INSTRUCTIONS

WARNING

Verify that all ratings and approvals of provided components meet installation requirements.

CAUTION

Installation and service should be performed only by trained service personnel. Observe all applicable national and local codes.

Step	Description	A	B		
1.	A. Install snap-in switch through small rectangular cutout in front of panel. B. Install fuse holder base through anti-rotation hole in front of panel and secure with hex nut in back of panel.				
2.	A. Insert fuse into carrier. B. Insert carrier with fuse into fuse holder base and lock into position. Note: Fuse provided is 5 A, 250 V, slow-blow as recommended in ConsoliDator Instruction Manual.				
Installation Tips	<ul style="list-style-type: none">• Mounting hardware is provided. Follow ConsoliDator Instruction Manual for wiring and mounting.• Before mounting ConsoliDator to panel, make connections to removable connector plugs.• 18-22 AWG is recommended wherever electrically suitable, for ease of use.• Insulated quick connect terminals are optional. Solder connections are suggested.• Terminals packaged with fuse holder will not fit switch tabs. Do not mix terminals.				
Electrical Ratings And Approvals		Enclosure	Fuse Holder	Fuse	Switch
	UL Rating	Type 1, 2, 3, 3R, 3S, 4, 4X, 6, 6P	250 V, 20 A	5 A, 250 V	10 A @ 125 VAC, 6 A @ 250 VAC
	UL File	E229365	E14853	E10480	E121922
	CSA Rating	N/A	250 V, 16 A	5 A, 250 V	N/A
	CSA File	N/A	47235	29862	N/A
Parts List	Qty	Description			
	1	Switch			
	2	Quick-Connect Terminal 0.187 X 0.020 for Fuse Tabs			
	2	Quick-Connect Terminal 0.187 X 0.032 for Switch Tabs			
	1	Fuse Holder (Base, Carrier, Gasket, Nut)			
	1	Fuse 5 A, 250 V			
	4	#8-32 SS Screw			
	4	¼"-20 SS Screw			
	4	#8 SS Lock washer			
	4	#8-32 SS Hex Nut			
	4	Plastic Mounting Feet			

PRECISION DIGITAL CORPORATION



LIM2901_C.doc
06/09

1.888.610.7664



www.calcert.com

sales@calcert.com