



Magnets on back of product can attach to metal products



Press down the battery cover and slide to open



GENERAL®

**DIGITAL FOUR CHANNEL
TIMER/CLOCK**

User's Guide



No. TI388