


LogTag®

HUMIDITY & TEMPERATURE RECORDER

HAXO-8 QUICK SETUP GUIDE



WHAT HARDWARE DO YOU NEED?

- LogTag® HAXO-8 Humidity and Temperature recorder.
- LogTag® LTI/USB Interface Cradle.
- PC running Windows XP or later version.

WHAT ABOUT SOFTWARE?

Before using a LogTag® recorder you will need to download the LogTag® Analyzer software from

the latest version, which supports multiple languages, including those with special characters such as Chinese or Russian. After completion a new icon will appear on your desktop.

INSTALLING THE INTERFACE CRADLE

- Plug the Interface Cradle into a USB port.
- USB drivers will install automatically. Your operating system will inform you when installation is complete.

CONFIGURING THE HAXO-8

The HAXO-8 must be configured before you can take readings.

- Start the LogTag Analyzer software.
- Insert the HAXO-8 into the Interface Cradle with the blue label to the front. You will here a click as the contacts engage.
- The screen will show 'A new LogTag has been detected..... Please wait.....'.
- If a Recorder has been used previously, a chart will appear.
- Select 'LogTag' - 'Wizard' to bring up the configuration wizard. The 'Welcome and general instructions' will be displayed.
- Click on 'Next'; LogTag Analyzer will scan for a Recorder, once found the configuration options will be displayed.



LogTag Configure

User ID: HAXO test unit

Date/Time start: 8/ 9/2014 1:30:00 PM

Begin recording at: 8/ 9/2014 1:30:00 PM

Record readings continuously, overwrite oldest when memory full

Record readings go that:

Readings recorded will span at least: 83 days

Number of readings to record: 8,000 (maximum is 8003)

Record a reading every: 15 Minutes

Begin recording after a delay of: 0 Minutes

Enable the OK (Green) indicator

Humidity | Temperature

Enable the Alert (Red) indicator, when:

Readings below: 25 or above: 70 %RH.

After: 2 consecutive alert readings (30 Minutes)

After: 0 alert readings have occurred (None)


Leave alert indicator enabled even if readings return within alert range

Clear and reset alert when START MARK button pressed

Configure requires a password: *****

Download requires a password

< Back Next > Close Help



GETTING HELP

If after studying the 'HAXO Quick setup guide' you still need further information, please visit the support section of the LogTag Recorders

CONFIGURATION OPTIONS

- User ID - user can enter details about each recorder.
 - Select Push button start or Date/Time start depending on requirements.
 - Enter the start date and time if selected.
 - If you selected Push button start, you can also tick Enable pre-start logging. This function ensures readings are taken in case the user forgets to press the START button.
 - Select recording mode - Continuously (overwrites old readings when memory is full) or reading for a specific duration (note that changing the recording interval automatically re-calculates the recording time).
 - Enter a start delay if required (allows the recorder to stabilise before recording starts).
 - Tick the Enable the OK (Green) indicator (this shows that the LogTag® is recording).
 - Click on the Humidity tab and select or enter humidity alert parameters.
 - Click on the Temperature tab and select or enter temperature alert parameters.
 - If you wish to control future access to this recorder, tick Configure requires a password or Download requires a password and enter a password. On some HAXO-8 units you need to perform an upgrade step to access this functionality. NOTE: Passwords are case sensitive.
 - When the configuration is complete, remove the LogTag® from the interface cradle.
 - If you wish to configure more HAXO-8 units with the same configuration profile, insert the next recorder into the interface cradle and click Again.
- NOTE: It is recommended that all HAXO-8 units be either hung or mounted vertically from the lug to minimise the possibility of water pooling over the sensor (especially in high humidity environments).

DOWNLOADING DATA

- Start LogTag Analyzer software.
- Insert the HAXO-8 into the interface cradle.
- The screen will show 'A new LogTag has been detected..... Please wait.....'.
- After a few seconds, a chart will appear (see image).
- Data can be displayed in Report, Chart, Table or Summary formats by clicking the tabs at the bottom of the window.
- Data can also be saved in a number of formats including TXT, PDF, HTML and CSV for import into a spreadsheet program.