

MGS+4NR

Gas Detection Controller

for Commercial & Industrial Applications



Refrigerant Leak Detection

P/N: 1100-2292 | February 2019 Revision 0

Quick Start Guide

1. Introduction

MGS-408 Gas Detection Controller comprehensive information about the status of all connected gas detectors. A maximum of eight (8) gas sensors can be connected to the MGS-408 via Modbus RTU. Compatible Bacharach gas detectors are the MGS-410, MGS-450, MGS-460, MGS-250 and MGS-550.

2. Safety Instructions



DANGER: The MGS-408 is NOT certified or approved for operation in oxygen-enriched atmospheres. Failure to comply may result in EXPLOSION.



WARNING: NEVER operate the MGS-408 without connection to a protective ground. Failure to comply may result in a potential shock hazard and is a violation of electrical safety standards.

2. Safety Instructions (Continued)



WARNING: Extreme care should be exercised when accessing the product's interior. Only qualified electrical maintenance personnel should perform connections and adjustments. Always remove AC power before working inside the MGS-408's enclosure.



WARNING: Use a <u>DRY CLOTH</u> to clean the outside of this product. **DO NOT** use soap and water or other detergents. Failure to comply may result in a potential shock hazard.



CAUTION: The protection provided by this product may become impaired if it is used in a manner not specified by the manufacturer. Modifications to this instrument, not expressly approved, will void the warranty.



CAUTION: Use ONLY the provided cable glands for electrical and communication wiring. Drilling into the box will void the warranty.

A certified AC power disconnect or circuit breaker should be mounted near the controller and installed following applicable local and national codes. If a switch is used instead of a circuit breaker, a properly rated **CERTIFIED** fuse or current limiter is required to be installed as per local or national codes. Markings for positions of the switch or breaker should state (I) for on and (O) for off.



CAUTION: In case of malfunction, DO NOT continue to use this equipment if there are any symptoms of malfunction or failure. In the case of such occurrence, de-energize the power supply and contact a qualified repair technician or the nearest Bacharach Service Center.

CODE COMPLIANCE: Comply with all local and national laws, rules and regulations associated with this equipment. Operators should be aware of the regulations and standards in their industry / locality for the operation of the MGS-408.

TECHNICIAN USE ONLY: The MGS-408 must be installed by a suitably qualified technician who will install this unit in accordance with these instructions and the standards in their

particular industry / country. This document is only intended as a guide and the manufacturer bears no responsibility for the installation or operation of this unit.

Failure to install and operate the unit in accordance with these instructions and with industry guidelines may cause serious injury or death and the manufacturer will not be held responsible in this regard.



4. Key Specifications

Size (H×W×D):	11.0" × 8.5" × 3.9" (280 × 215 × 100 mm)
Weight:	2.76 lbs (1250 g)
Indicators:	Multi-color Status LED Internal Alarm Buzzer: 72dB @ 3.9" <i>(10 cm)</i>
Alarm Delay:	Configurable (0 to 15 minutes)
Inputs:	Tactile Switches (×2), Magnetic Switches (×2)
Outputs:	Analog Output: 4 to 20 mA, 0 to 5V, 0 to 10V, 1 to 5V (<i>default</i>) or 2 to 10V
Bluetooth®	Bluetooth® Low Energy, BLE 4.2
Modbus:	Connection: RS-485 terminal block Baud Rate: 9,600 (default) or 19,200 Data Bits: 8 Parity: None (default), odd or even Stop Bits: 1 (default) or 2 Retry Time: 500 ms (minimum)

Power Supply:	100 - 240 VAC, 50 / 60 HZ, 80W (maximum)
Wiring (Power):	2-core cable, 16 to 28 AWG
Wiring (Relays):	2-core cable, 16 to 28 AWG
Wiring (Modbus):	Recommended: Belden 3106A (or equivalent) 3-core, 2 twisted pair + ground, shielded cable with 120 Ω characteristic impedance, 16 to 28 AWG
Enclosure:	NA / LARG
Lifelogui C.	Material: ABS Protection: IP66
Temperature:	
	Protection: IP66
Temperature:	Protection: IP66 32 to 113°F (0 to 45°C)

5. Mounting Template