

IPAQ R460

4-wire transmitter for resistance thermometers and thermocouples configurable via software or DIP switches

IPAQ R460 is a programmable 4-wire (separately powered) transmitter. It converts Pt, Ni, KTY and TC sensor signals as well as potentiometer, resistor and mV signals to isolated standard signals.

Due to the simple switching of the calibrated measuring ranges per DIP switch, it can be used flexibly. With the USB programming kit INOR-Set the transmitter IPAQ R460 can be configured via PC and the data records can be stored and documented. An additional power supply is not necessary during PC configuration.

The commissioning function, which can be switched on at the front, generates a reference signal at the output with which the subsequent signal path can be tested and adjusted.



Specifications:

Input

| Sensor | Type | Span min. | Measuring error |
|------------------------------------|---|-------------------------------|-----------------------|
| Pt | Pt100, Pt200, Pt500, Pt1000 | 10 K | < 0,1 K + 0,05 % f.s. |
| Ni | Ni100, Ni200, Ni500, Ni1000 | 10 K | < 0,2 K + 0,05 % f.s. |
| KTY | KTY, 29 Types | 25 K | < 0,3 K + 0,05 % f.s. |
| Resistor | 0 ... 5000 Ω | 100 Ω | < 0,1 Ω + 0,02 % f.s. |
| Sensor current / Sensor connection | 0.2 mA / 4-wire, 3-wire, 2-wire | | |
| Maximum sensor wire resistance | < 100 Ω per conductor, manual compensation programmable for 2-wire connection | | |
| Thermocouples | E, J, K, L, N, R, S, T, U / B, C, D | 50 K / 100 K | < 0,3 K + 0,08 % f.s. |
| Cold junction compensation | internal, external, uncompensated, manual | Error of CJC internal < 1.5 K | |
| mV input | ±100 mV ±1000 mV | 5 mV, 50 mV | < 50 μV + 0,02 % f.s. |
| Potentiometer | 100 Ω ... 50 kΩ | 10 % | < 0,05 % |

Output

| | Current | Voltage |
|------------------|---|---------------------------------|
| Output signal | 0/2 ... 10 mA 0/4 ... 20 mA | 0/1 ... 5 V 0/2 ... 10 V |
| Load | ≤ 12 V (600 Ω and 20 mA) | ≤ 5 mA (2 kΩ and 10 V) |
| Residual ripple | < 10 mV _{rms} | |
| Output limits | 0 ... 102,5 %, (3,8 ... 20.5 mA for output 4 ... 20 mA) | Characteristic rising / falling |
| Error monitoring | Sensor/wire break, Programmable signalling | |

General data

| | |
|--|--|
| Transmission error | < 0.1 % full scale |
| Temperature coefficient ²⁾ | < 100 ppm/K |
| Measuring rate / response time T99 | 4/s / 250 ms |
| Test voltage | 3 kV AC, 50 Hz, 1 min. Input against output against supply |
| Working voltage ³⁾ (basic insulation) | 600 V AC/DC at overvoltage category II and contamination class 2 acc. to DIN EN 61010-1 |
| Protection against dangerous body currents ³⁾ | Protective Separation by reinforced insulation acc. to EN 61010-1 up to 300 V AC/DC for overvoltage category II and contamination class 2 between input and output and power supply. |
| Ambient temperature | Operations: -25 °C to +70 °C (-13 to +158 °F) Transport and storage: -40 °C to +85 °C (-40 to +185 °F) |
| Power supply | 24 V DC Voltage range 9.6 V ... 31.2 V DC, approx. 0.8 W |
| EMC ⁴⁾ | EN 61326-1 |
| Design | 6.2 mm (0.244") housing protection class IP 20, mounting on 35 mm top-hat rail acc. to EN 60715 |
| Weight | approx. 70 g |
| Ordering information | IPAQ R460 70R4600010 |

- 1) Factory setting: Input: Pt100, 0...100°C, 4-wire-sensor connection, Output: 0...20 mA, Characteristic rising, error signal 22 mA
- 2) Average TC in specified operating temperature range
- 3) As far as relevant the standards and rules mentioned above are considered by development and production of our devices. In addition relevant assembly rules are to be considered by installation of our devices in other equipment's. For applications with high working voltages, take measures to prevent accidental contact and make sure that there is sufficient distance or insulation between adjacent situated devices.
- 4) Minor deviations possible during interference

INOR Process AB, PO Box 9125, SE-200 39 Malmö, Sweden, Phone: +46-40-31 25 60, E-mail: support@inor.se

INOR Transmitter OY, Tuupakantie 3, 01740 Vantaa, Finland, Phone: +358-10-421 7900, E-mail: myynti@inor.fi

INOR Transmitter GmbH, Am See 24, 47279 Duisburg, Germany, Phone: +49-203-7382 7620, E-mail: info@inor-gmbh.de

KROHNE Temperature Division INOR, 55 Cherry Hill Drive, Beverly, MA 01915, USA, Phone: +1-978-826 6900, Email: inor-info@krohne.com