



CLAMP POWER METERS

KEW 2060BT/2062/2062BT



KEW 2060BT/2062/2062BT Specifications

	2060BT	2062/2062BT					
Wiring connections	1P2W, 1P3W, 3P3W, 3P4W						
Measurements and parameters	Voltage, Current, Frequency, Active power, Reactive power, Apparent power, Power factor (cos angle, Harmonics (THD-R/THD-F), Phase rotation						
ACV							
Range	1000V						
Accuracy	±0.7%rdg±3dgt(40.0 - 70.0Hz) ±3.0%rdg±5dgt(70.1 - 1kHz)						
Crest factor	1.7 or less						
A <u>CA</u>							
Range	40.00/400.0/1000A (3 range auto)						
Accuracy	±1.0%rdg±3dgt(40.0 - 70.0Hz)						
Crest factor	3 or less on 40.00A/400.0A range, 3 or less 1500A peak on 1000A range						
Frequency							
Display Range	40.0 - 999.9Hz						
Accuracy	±0.3%rdg±3dgt						
Active power							
Range	40.00/400.0/1000kW						
Accuracy	±1.7%rdg±5dgt (PF1, sine wave, 45 - 65Hz)						
Apparent power							
Range	40.00/400.0/1000kVA						
Accuracy	±1dgt against each calculated value, Sum: add errors of each channel, 3P3W: ±2dgt, 3P4W: ±3dgt)						
Reactive power							
Range	40.00/400.0/1000kVar						
Accuracy	±1dgt against each calculated value, Sum: add errors of each channel, 3P3W: ±2dgt, 3P4W: ±3dgt)						
Power factor		<u> </u>					
Display Range	-1,000 - 0,000 -+1,000						
Accuracy	±1dgt against each calculated value, Sum: add errors of each channel, 3P3W: ±2dgt, 3P4W: ±3dgt)						
Phase angle(1P2W only)	Trage against saon saledated value, saint add shore	or each original, or evv. ±2agt, or 4vv. ±eagt,					
Display Range	-180.0 - 0.0 - +179.9						
Accuracy	±3.0°						
Harmonics RMS(Content ra							
Analysis order	1st - 30th order						
Accuracy	±5.0%rdg±10dgt (1 - 10th)						
Total harmonics THD-R/THI		20th) = 22070rdg=10dgt (21 = 30th)					
Display Range							
Accuracy	0.0% - 100.0% ±1dgt against the calculated results of each measured value						
Phase rotation							
Other functions	ACV 80 - 1100V(45 - 65Hz) MAX/MIN/AVG/PEAK, Data hold, Bluetooth® (KEW 2060BT and KEW 2062BT only), Back light, Auto power of						
	MAXIMIN/AVG/PEAK, Data floid, Bluetootri® (KEW 200	OBT and KEW 2062BT only), Back light, Auto power o					
General	District ME O Assistant O assess 100 40 0	- (VEN COORT VEN COORT					
Communication interface							
Power source	LR6(AAA)(1.5V)×2						
Continuous measuring time	11						
Conductor size	Φ75mm max. (busbar of 80mm×30mm)	Φ55mm max.					
Dimensions / Weight	Dimensions / Weight 283(L) × 143(W) × 49(D) mm / Approx. 590g (including batteries) 247(L) × 105(W) × 49(D) mm / approx. 490g (including						
Applicable standards	IEC 61010-1, IEC 61010-2-032, IEC 61326-1, -2-2(EMC), IEC 60529(IP40)						
	CAT IV 600V / CAT III 1000V Pollution degree 2 CAT IV 300V / CAT III 600V / CAT II 1000V Pollution degree 2						
Accessories	7290 (Voltage test lead set) 9198 (Carrying case) LI	R6(AAA)×2, Instruction Manual					

Selection Guide of Power Meters

		Clamp Power Meters			Power Meter	Power Quality Analyzer
		2060BT	2062	2062BT	6305	6315
Appearance						
Voltage[V]		✓	✓	✓	✓	✓
Current[A]		✓	✓	✓	✓	✓
Power[W]		✓	✓	✓	✓	✓
Frequency [Hz]		✓	✓	✓	✓	✓
Energy [Wh]		-	-	-	✓	✓
Harmonics		✓	✓	✓	_	✓
Power Quality	Swell	_	_	_	_	✓
	Dip	_	_	_	_	✓
	Interruption	_	_	_	_	✓
	Transients	_	_	_	_	✓
	Inrush Current	-	_	_	_	✓
Conductor size		Ф75mm	Ф55тт	Ф55mm	Differs depending on the optional clamp sensors used.	Differs depending on the optional clamp sensors used.
Memory		-	-	-	SD card	SD card
Number of Input Channel		4ch(V3,A1)	4ch(V3,A1)	4ch(V3,A1)	6ch(V3,A3)	7ch(V3,A4)
Communication interface		Bluetooth®	_	Bluetooth®	USB,Bluetooth®	USB,Bluetooth®


Accessories



Measurement categories (CAT)

The figure shows an example of measurement category.

Measuring instruments designed for CAT IV environments can be used at the environments of CAT III, CAT II and CAT O.



Caution

The voltage value which follows after the category means the limit of the phase to earth voltage. It is not the limit of the phase to phase voltage. Therefore, in the case of a measuring instrument which complies with CAT IV 300V, it can be used at the electrical circuit up to 520V phase to phase at the 3-phase line connected by star connection.

Some countries regulate the compliance with their Radio Law of the products equipped with Bluetooth $\!^{\! *}\!.$ Please confirm it with your distributor before purchasing our products equipped with Bluetooth®.



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely Safety Warnings: for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

For inquires or orders:



KEW 2060BT/2062/2062BT

Various measurement functions

- Measurements of current, voltage, power, harmonics and phase detection are possible.
- True RMS: Indicates a correct value at the distorted waveform.
- Functions of PEAK, MAX, MIN, AVG are available.
 Easy to check the temporal change in the power source.
- CD can display simultaneously the values of voltage and frequency or power and power factor.



AC Current, Frequency



AC Voltage, Frequency



Power



DATA HOLD



Harmonics



Phase detection



SET UP



Input terminals can be used up to 3. Set the test leads according to the wiring configuration.



Power measurement





Various parameters such as active/reactive/apparent power, power factor, phase differences(1P2W only) which are required for the power measurement can be measured.



Total 3-phase power can be measured in simple steps.



By setting the CT and VT ratio and measuring the secondary side of the transformation, the primary side value can be obtained.

Harmonics measurement

Harmonics of the voltage and current, which cause various failures at the field, can be measured.

It is possible to measure and show each voltage and current harmonics up to 30th.

Total harmonics distortion factor is in two types of THD-R and THD-F.


Each degree of harmonics can be shown on the LCD of the tester.

Both the current value (or voltage value) and the content ratio can be displayed on the same screen.









1.888.610.7664

Jaw shape with emphasis on the safety and the usability

Line-up of two types of jaw to meet the test environment

- KEW 2060BT has a newly designed special jaw shape for using at a large busbar. Extremely large jaw with tear drop shape can clampalarge busbar with safe. (Conductor size 75mm, Busbar 80 x 30mm MAX)
- KEW 2062 and KEW 2062 BT have a tear drop shape jaw, and the size is convenient to use at a small-sized office and factory. (Conductor size 55mm)






Tear drop shape jaw can keep the operator free from the danger of touching the busbar.

Phase detection

Positive phase and negative phase can be confirmed by the buzzer sound and the display without changing the

connection of the leads.









KEW Power*











Please search "KEW Power*

Communication charge may download application.



iOS App

Free iOS software "KEW Power*" is available on "APP Store



Bluetooth® (KEW 2060BT and KEW 2062BT only)

- Obedicated Application "KEW Power*" supports both Android™ and iOS.
- LCD display can be checked at the smart devices.
- OMeasured values and graphs can be stored with a press of a button.
- Voltage and current can be shown in the waveform display. Existence of the harmonics can be found easy.

