

MEMORY HICORDER MR8740T






Perfect for multi-point measurements on high-performance boards 108 Channels of Simultaneous Testing

• Delivering triple-digit multichannel measurement

 $\underset{\text{Max.}}{\text{Analog}} \ 108 ch$

Analog + Logic 144ch






Compact, measures up to 108 channels

Multi-channel, reduced footprint

The MR8740T achieves testing of up to 108 channels, double that of conventional models, while maintaining the same unit size. Test high-performance ECU boards, with their ever-increasing number of test points, with a single measurement system. Make the most of your limited space for testing systems.



Isolated design for fault prevention

All channels isolated

Isolation of all channels prevents noise from connected devices, with no negative effect due to different ground potential. Eliminate faults and other trouble caused by mistaken wirings and over-voltages / over-currents due to shorted boards.



Between input channels

Between main unit and input channel

1.888.610.7664

www.calcert.com



MEMORY HICORDER MR8740T

Analog Max. 108ch Test data transfer time

As artificial intelligence advances in automobiles and other advanced industries the need for technology to simultaneously process large volumes of data, as well as safety and security, has arrived. The MR8740T supports your testing needs with simultaneously sampled measurements across multiple channels.







Simultaneous sampling on all channels




*1: When using 8966 *2: When using MR8990, U8991

Transfer time for test data reduced to almost zero

Minimize dead time while testing


Previously, calculations and saving/transferring data after measurements were slow processes, and much of the testing time was taken up by dead time while waiting to perform the next test. The MR8740T dramatically reduces the time both for calculations and saving data, almost completely eliminating dead time while performing tests.



Save recorded data 100 times faster

Minimize the time required to save on devices and media

The MR8740T features a brand new interface and faster internal processing, reducing the time required to save measurement data to media. For example, saving that required 10 minutes previously can now be completed in as little as 6 seconds. This saves you the trouble of waiting for data to be saved and improves work efficiency.



Save data in real time NEW

Save data while measurement is ongoing


The MR8740T saves data in real-time to recording media while measurement is ongoing thanks to a combination of high-speed data transfer performance and high-speed data saving performance. For example, if saving data to the internal SSD, the instrument can save 64 channels of data in real time at a sampling rate of 1 MS/s.



www.calcert.com

1.888.610.7664

Applications



Control simulation

Generating and measuring signals with a single device eliminates the need to prepare separate measurement and generator devices. Simulated output of various sensor signals and control pulse signals allows you to simulate the test waveforms (DC output, sine wave output) of engine controls for automobiles, high speed trains, and airplanes, and control boards for airbags, brake systems, power steering, and active suspension.







Airbag control test

Brake system control test

Engine control test

Tests using distortion measurements

Input the analog signal from a strain gauge or extensometer and the analog signal from a stress sensor. Use the scaling function to convert those values to tensile strain, and to convert the stress sensor value to tensile stress. Measure analog and logic at the same time, to simultaneously record a variety of signals with a single test.









ECU Testing

ECUs are connected to a large number and wide variety of sensors. Add a signal generation unit to simulate these sensors. By measuring the simulation results with a measurement unit at the same time, you can perform all steps from signal generation to measurement with a single MR8740T.

The U8794 also offers resistance output to enable thermistor circuit testing.



Replace multiple DMMs with a single unit

Replace multiple desktop DMM units with a single MEMORY HiCORDER for measuring multi-channel sensors. Select from the MR8990 2-channel unit with a wide range, or the U8991 4-channel unit to measure multiple channels. In addition to reducing the number of units required, system simplification makes maintenance and management easier.

Expandable to a maximum of 108 channels using multiple 4-channel

108 Benchtop DMMs

Replaced with 1 Unit



Comparison of DIGITAL VOLTMETER UNIT MR8990 and U8991

External appearance		* O.O.O.O.	
Model No.	MR8990	U8991	
Measurement functions	No. of channels: 2, for DC voltage measurement	No. of channels: 4, for DC voltage measurement	
Input terminals	Banana input terminal Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	isolated from the unit, the maximum voltage that can	
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges	1, 10, 100 V f.s., 3 ranges	
Measurement resolution	1/1,000,000 of measurement range (using 24-bit $\Delta\Sigma$ modulation A/D)		
Integration time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)		
Basic measurement	±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)	±0.02% rdg. ±0.0025% f.s.	

Specifications for DC voltage measurements

Measure minute fluctuations in sensor output for automobiles or voltage fluctuations in batteries with high precision and at high resolution. The maximum voltage input is 500 V DC for the MR8990 and 100 V DC for the U8991. Both units also feature high input resistance.


1.888.610.7664



Real-time Save

Save data while measurement is ongoing, even with extended recording, high-speed sampling, and numerous channels

The MR8740T offers real-time save functionality that saves data to recording media while measurement is ongoing. Hioki recommends using the instrument's large internal SSD unit when you need to record data for extended periods of time. If you wish to save data after measurement has completed, you can specify a USB drive as the save destination. Additionally, you can use the real-time save function to control how long the instrument can continue measuring without being dependent on the amount of built-in storage memory. Files are saved as 512 MB segments when using the real-time save function.



Real-time save capabilities when measuring 108 channels

Save destination	Number of channels	Sampling speed	Supported measurement time	Maximum sampling speed at which real-time saving is supported*1
Internal SSD (480 GB)	108 ch	500 kS/s	About 1 hr.	5 MS/s (12 channels)
USB Drive Z4006 (16 GB)	108 ch	100 kS/s	About 10 min.	1 MS/S (12 channels)*2
PC	108 ch	20 kS/s	Depends on PC capacity	200 kS/s (12 ch)

^{*1:} For 2 channels (no settings for channel 1) *2 When connected via a USB 3.0 connector only.

Maximum sampling speeds at which real-time saving is supported

Save destination	Number of channels used					
Save desimation	Up to 12	12 to 32	33 to 64	65 or more		
Internal SSD	5 MS/s	2 MS/s	1 MS/s	500 kS/s		
USB Drive Z4006	1 MS/s *2	500 kS/s *2	200 kS/s *2	100 kS/s *2		
PC	200 kS/s	100 kS/s	50 kS/s	20 kS/s		

^{*1:} Double channel counts if U8991 is installed. *2: When connected via a USB 3.0 connector only.


Amount of time for which data can be saved in real time to internal SSD (reference values)

d: Days h: Hours min: Minutes s: Seconds

	•	,				
Compling and		Number of channels used				
Sampling speed	Up to 12	13 to 32	33 to 64	65 or more		
5 MS/s	50 min	-	-	-		
2 MS/s	2 h 05 min	1 h 02 min 30 s	-	-		
1 MS/s	4 h 10 min	2 h 05 min	1 h 02 min 30 s	-		
500 kS/s	8 h 20 min	4 h 10 min	2 h 05 min	1 h 02 min 30 s		
200 kS/s	20 h 50 min	10 h 25 min	5 h 12 min 30 s	2 h 36 min 15 s		
100 kS/s	1 d 17 h 40 min	20 h 50 min	10 h 25 min	5 h 12 min 30 s		
50 kS/s	3 d 11 h 20 min	1 d 17 h 40 min	20 h 50 min	10 h 25 min		
20 kS/s	8 d 16 h 20 min	4 d 08 h 10 min	2 d 04 h 05 min	1 d 2 h 02 min 30 s		
10 kS/s	17 d 08 h 40 min	8 d 16 h 20 min	4 d 08 h 10 min	2 d 04 h 05 min		
5 kS/s	34 d 17 h 20 min	17 d 08 h 40 min	8 d 16 h 20 min	4 d 08 h 10 min		
2 kS/s	86 d 19 h 20 min	43 d 09 h 40 min	21 d 16 h 50 min	10 d 20 h 25 min		
1 kS/s	173 d 14 h 40 min	86 d 19 h 20 min	43 d 09 h 40 min	21 d 16 h 50 min		
500 S/s	347 d 05 h 20 min	173 d 14 h 40 min	86 d 19 h 20 min	43 d 09 h 40 min		

Saving data directly to your PC


Transfer measurement data directly to your PC by using the FTP sending function together with the real-time save function. This makes it easier to observe data after the measuring process.



Long-term measurements for more efficient testing

The real-time save function boasts high-speed sampling and multi-channel measurements.

Perform an approximately 1-hour measurement at 5 MS/s in 2 channels or 1 MS/s in 64 channels.



www.calcert.com

Complete Product Lineup



Install up to 27 modules

Build Your Ideal Inspection System

Choose from a diverse array of modules to build your perfect test system.

To test a ECU that requires multi-point, high-precision measurements, combine the U8975 and U8991 4-channel units to build a measurement system that delivers a maximum of 108 channels. In addition, create an integrated testing system that can simulate engine behaviors and sensors by utilizing the waveform generators, pulse generators, and VIR generators available on select units.

Use ANALOG UNIT 8966 and DIGITAL VOLTMETER UNIT MR8990 to supplement waveforms of high-speed and high-voltage signals, such as for inverter boards, in the same way as when measuring with a DMM. Combine high-precision units that perform simultaneous sampling for safe and reliable operation in a variety of measurement scenarios.

Unit interchangeability

Use any of the 18 types listed in the unit selection guide below.

The MR8740T is compatible with the same units used for the HIOKI MEMORY HiCORDER MR8740, MR8741, MR6000, MR8827, and MR8847A.

Unit selection guide (18 types available)

	Measured signal	Model No.	Description	No. of channels	Fastest sampling	Bandwidth	A/D resolution	DC accuracy	Max. input voltage	Min. resolution (*1)	Max. sensitivity range	Isolated/ Non- isolated	Notes
	Voltage	8966	ANALOG UNIT	2 ch	20 MS/s	DC to 5 MHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	n/a
	Voltage (multi-channel)	U8975	4ch ANALOG UNIT	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.1% f.s.	200 V DC	0.125 mV	4 V f.s.	Yes	n/a
NEW	Voltage (multi-channel, high resolution)	U8978	4CH ANALOG UNIT	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	40 V DC	3.125 uV	100 mV f.s.	Yes	n/a
	Voltage (high resolution)	8968	HIGH RESOLUTION UNIT	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.3% f.s.	400 V DC	3.125 uV	100 mV f.s.	Yes	with AAF
	Voltage (DC, RMS)	8972	DC/RMS UNIT	2 ch	1 MS/s	DC to 400 kHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	with RMS
	Voltage (high voltage)	U8974	HIGH VOLTAGE UNIT	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.25% f.s.	1000 V DC 700 V AC	0.125 mV	4 V f.s.	Yes	Maximum rated voltage to ground 600 V AC/DC CAT IV
	Voltage (high resolution)	MR8990	DIGITAL VOLTMETER UNIT	2 ch	2 ms	n/a	24 bits	±0.01% rdg. ±0.0025% f.s.	500 V DC	0.1 uV	100 mV f.s.	Yes	Maximum rated voltage to ground 300 V AC/DC CAT II
	Voltage (high resolution)	U8991	DIGITAL VOLTMETER UNIT	4 ch	20 ms	n/a	24 bits	±0.02% rdg. ±0.0025% f.s.	100 V DC	1 uV	1 V f.s.	Yes	Maximum rated voltage to ground 100 V AC/DC
	Current	8971	CURRENT UNIT	2 ch	1 MS/s	DC to 100 kHz	12 bits	±0.65% f.s.	Current sensor only		on current nsor	No	with RMS Max. 4 units
NEW	Current	U8977	3CH CURRENT UNIT	3 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	Current sensor only		on current nsor	No	Max. 3 units
	Temperature	8967	TEMPERATURE UNIT	2 ch	1.2 ms	DC	16 bits	Detailed reference	Thermocouples only	0.01°C	200°C (392°F) f.s.	Yes	n/a
	Strain	U8969	STRAIN UNIT	2 ch	200 kS/s	DC to 20 kHz	16 bits	±0.5% f.s. ±4 με	Strain only	0.016 με	400 μ ε f.s.	Yes	n/a
	Frequency	8970	FREQ UNIT	2 ch	200 kS/s	DC to 100 kHz (*3)	16 bits	n/a	400 V DC	0.002 Hz	Depends on mode	Yes	n/a
NEW	Acceleration	U8979	Charge Unit	2 ch	200 kS/s	DC to 50 kHz (DC) 1 Hz to 50 kHz (AC)	16 bits	±0.5% f.s. (Voltage) ±2.0% f.s. (Acceleration)	40 V DC		nds on ion sensor	Yes	Supports TEDS
	Logic	8973	LOGIC UNIT	4 probes	n/a	n/a	n/a	n/a	n/a	n/a	n/a	No	9320-01,9327, Requires 9320-01, 9327 or MR9321-01

(*1) Minimum resolution shows the highest sensitivity resolution. (*2) When using the 9665 (*3) Minimum pulse width 2 μs

Target	Model No.	Description	Channels	Output	Frequency	Output range
Voltage	MR8791	PULSE GENERATOR UNIT	8 ch	Pulse, pattern	0.1 Hz to 20 kHz (pulse) 10 Hz to 120 kHz (pattern clock)	Logic output (Amplitude: 0 to 5 V), Open collector output
Voltage	MR8790	WAVEFORM GENERATOR LINIT	4 ch	DC, sine wave	DC, 1 Hz to 20 kHz	Output: -10 V to 10 V (Amplitude setting range:



Unit Advantages

Ideal for simulation testing that involves signal generation and measurement







U8794 for generating voltage, current, and resistance

MR8790 for generating waveform signals


MR8791 for generating pulse signals

Generate voltage/current signals, pulses and simulated resistance

Use generator units in place of the sensor output for simulation testing or board testing lines using generated signals. Combine a generator unit and measurement unit to perform generation and measurement with a single test system.

VIR GENERATOR UNIT U8794

Output DC voltage, DC current, and resistance.





Electronic circuitry built with compact resistors



Traditional switching resistors are large and take up space. 8 channels with 1 unit

Easily configure output settings and monitor measured values

You can easily set the constant voltage, constant current, or resistance value to output for each channel. Internal voltage, current, and resistance values can be displayed on the same screen.

Ideal for testing that requires simulated signals

When used as an ECU testing device, generate simulated signals from various sensors, which is indispensable for testing electronic parts and maintaining equipment.

Generator units can simulate a variety of sensor signals

ECU type	Sensor function	Sensor type	Generator unit
	Air flow sensor	Voltage	U8794
	Throttle sensor	Voltage	U8794
	O2 sensor	Voltage	U8794
Engine	Knock sensor	Voltage	MR8790
management	Crank angle sensor	Voltage	MR8791
system	Camshaft sensor	Voltage	MR8791
	Water temperature sensor	Resistance	U8794
	Intake air temperature sensor	Resistance	U8794
Driving management system	Torque sensor G sensor Steering angle sensor Speed sensor	Voltage	MR8790 MR8791 U8794
Safety & comfort	Ultrasonic/radar sensor Vibration sensor	Voltage	MR8790



Testing electronic parts

Use the recorder's internal voltage monitor and current monitor to test electronic parts. Or, check resistance values and diode direction characteristics based on the output current and measured voltage.

Testing and maintaining equipment

1.888.610.7664



Simultaneous sampling on all channels across all units




Measure up to 200 V U8975 Measure at 24-bit resolution U8991

Measure with high sensitivity at 100 mV f.s.: U8978

Ideal for measurements that require simultaneity

All channels are equipped with an A/D converter and measurement timings are synchronized, eliminating sampling time difference between units and channels. This delivers accurate time measurement for cursor readout and time difference measurements.




Record briefly at high speed, record for a long time at low speed

Use high-speed sampling to capture inverter waveforms, and low-speed sampling to measure RMS values on multiple channels.

Maximum recording time to internal memory

	When using a	When using a	4-channel unit
Sampling rate	2-channel unit	When using U8975, U8978	When using U8991
Sampling rate	Recording length: 10 M points	Recording length: 5 M points	Recording length: 2 M points
20 MS/s	0.5 s	0.25 s	0.1 s
10 MS/s	1 s	0.5 s	0.2 s
5 MS/s	2 s	1 s	0.4 s
2 MS/s	5 s	2 s	1 s
1 MS/s	10 s	5 s	2 s
500 kS/s	20 s	10 s	4 s
200 kS/s	50 s	25 s	10 s
100 kS/s	1 m 40 s	50 s	20 s
50 kS/s	3 m 20 s	1 m 40 s	40 s
20 kS/s	8 m 20 s	4 m 10 s	1 m 40 s
10 kS/s	16 m 40 s	8 m 20 s	3 m 20 s
5 kS/s	33 m 20 s	16 m 40 s	6 m 40 s
2 kS/s	1 h 23 m 20 s	41 m 40 s	16 m 40 s
1 kS/s	2 h 46 m 40 s	1 h 23 m 20 s	33 m 20 s
500 S/s	5 h 33 m 20 s	2 h 46 m 40 s	1 h 6 m 40 s
200 S/s	13 h 53 m 20 s	6 h 56 m 40 s	2 h 46 m 40 s
100 S/s	1 d 3 h 46 m 40 s	13 h 53 m 20 s	5 h 33 m 20 s
50 S/s	2 d 7 h 33 m 20 s	1 d 3 h 46 m 40 s	11 h 6 m 40 s
20 S/s	5 d 18 h 53 m 20 s	2 d 21 h 26 m 40 s	1 d 3 h 46 m 40 s
10.9/e	11 d 13 h /6 m /0 e	5 d 18 h 53 m 20 e	2 d 7 h 33 m 20 e



Instantaneous measurement of various inverter waveforms

Simultaneously measure and record multiple phenomena, such as the voltage, current, torque, and rotation signal on the primary and secondary sides of an inverter, from high voltage to minute voltage.

Highly accurate measurement of RMS values




www.calcert.com

Measurement and Analysis Functions

Triggers that detect targeted events

Set triggers on any channel to record data whenever an event occurs. This setting can be configured for all channels.




Setting multiple triggers for a single channel


Set up to 4 triggers for a single channel.

Sometimes the cause of issues are unclear, preventing you from setting up the proper trigger to capture the necessary waveforms and conduct further analysis. By being able to set glitch, level, windowin, and window-out triggers for the same input waveform, for instance, you can broaden the scope of your investigation and increase your chances of catching the signal anomalies.





Setting Screen with Easy-to-Understand Trigger System Chart



Warning function using trigger settings

Trigger settings are used to issue a warning if the setting range is exceeded.

For example, during an immunity test, this function can be used to notify the user when the variable limit value of the measured voltage is exceeded. In such cases, a window out trigger is used.


Output warning

- (1) When a waveform exceeds the upper and/or lower limits of the setting range, an event mark is displayed on the screen and an alarm sounds. When the waveform is once again within the upper and/or lower limits of the setting range, the alarm stops and an event mark is displayed on the screen.
- (2) In each case, the time, channel, type of trigger, and voltage measurement value are displayed on the top right side of the screen. * Effective for sampling at 100 KS/s or less.


When unsure about trigger level

Setting trigger level automatically

Take a preliminary measurement of a specified number of samples before the actual measurement, and use the average of those values to set the trigger level. This function is useful both for the warning function and for normal triggers.



Warning function settings are the same as for triggers, and easy to use.




www.calcert.com

Calculation function with high analytical performance

Waveform processing

In addition to calculating numerical values such as average values and RMS values, up to 16 types of simultaneous processing are available by combining calculations in the waveform dimension with differential arithmetic, including the four arithmetic operations, between channels.



Simultaneously make up to 16 waveform calculations by combining the four arithmetic operations and 11 types of calculations

Four arithmetic operations (addition, subtraction, multiplication, and division)	Parallel displacement along time axis (SLI)
Absolute value (ABS)	Differentiation (primary (DIF), secondary (DIF2))
Exponentiation (EXP)	Integration (primary (INT), secondary (INT2))
Common logarithm (LOG)	Trigonometric functions (SIN, COS, TAN)
Square root (SQR), cube root (CBR)	Reverse trigonometric functions (ASIN, ACOS, ATAN, ATAN2)
Moving average (MOV)	MR8990 DIGITAL VOLTMETER UNIT time shift for PLC delay (PLCS)

Numerical calculations

The measured waveforms are analyzed with numerical parameters.

The MR8740T features several new numerical calculations including

The MR8740T features several new numerical calculations including overshoot and undershoot calculations.

In addition to analog and logic channels, the recorder performs calculations on waveform processing results. It also features a numerical judgment function.

Simultaneous numerical calculations of up to 16 out of a total of 33 computations

Average value	Duty ratio
RMS value	Pulse count
Peak to peak value	Four arithmetic operations
Maximum value	Time difference
Time to maximum value	Phase difference
Minimum value	High-level
Time to minimum value	Low-level
Period	Median value
Frequency	Amplitude
Rise time	Overshoot
Fall time	Undershoot
Standard deviation	+Width
Area value	-Width
X-Y area value	Burst width
Specified level time	Integration values
Specified time level	XY waveform angle
Pulse width	

Find a specific waveform within large amounts of measurement data

Set the peak values or trigger conditions you want to search for to have the relevant data retrieved and displayed automatically.


Our new Memory HiCorder HiConcierge function automatically calculates the characteristics of the reference waveform you have set and searches all of the measured data to detect any waveforms with low similarity as anomalous waveforms.

This drastically reduces the amount of time required to search for anomalies by eliminating the need to scroll through measured waveforms and checking them visually.


Auto search of anomalous waveforms with Concierge

Memory HiCorder Concierge

A new waveform search function that finds anomalous waveforms in all of the measured data. This function is ideal for situations where it is difficult to set the right triggers before measuring because the nature of potential anomalies cannot be predicted.



 ${\bf Memory\ HiCorder\ Concierge\ Waveform\ Search\ Screen}$



Rich set of search methods

Peak search

Search for the maximum value, minimum

Trigger search

Set trigger conditions for all of the measured

Jump

Jump to an event mark you made while

1.888.610.7664



Smart Links with Monitors and PCs





Easily check measured waveforms and the settings of communication commands


When building a testing system, use a monitor to easily evaluate captured waveforms in full detail and review the settings for the communication commands sent from a PC. After the system is built, detach the monitor to maximize the use of resources in other applications, while continuing to control the MR8740T with only the PC. Or, if control is not necessary, use only the MR8740T with a monitor to take measurements and observe waveforms in standalone mode.

* A display with a resolution of 1920 x 1080 or better is recommended.




Display system for efficient work

Configure various settings while viewing a variety of information on a single screen. Improve work efficiency by reducing the need to switch or scroll through screens in order to check the settings for each channel.



Waveform analysis with 8 cursors

When building a system or analyzing faulty parts, perform a detailed check of waveforms in order to verify proper operation. Use multiple cursors on the MR8740T to smoothly analyze and evaluate actual waveforms.



LabView compatibility

NEW

The MR8740T can be controlled with LabVIEW. Search for "MR8740-50" under "Download Software" in the "Support" section of Hioki's website and download the LabVIEW driver.



Control the MR8740T with a single computer

Connect the MR8740T to a computer via LAN in order to control it with communication commands. This allows you to configure, generate, measure, and acquire data



Standard recorder when control via PC is not required

If the unit will be used only as a basic recorder and there is no need to use a computer for control, use only the MR8740T together with a monitor to take and

High-speed communication function

A 1000 BASE-TX LAN terminal is equipped as standard.

FTP server function


The content of the MR8740T's memory (USB memory and internal SSD) can be copied to the computer.


FTP transfer function





Interface





2 USB 2.0 connector x2

Max. 27 units can be installed Model 8973 can only be installed in slots 25 to 27

3 Activate button

ctivates the unit, or places it in standby

4 POWER lamp Indicates the unit is activated or in standby

5 DIAG light

Space for units

6 Command error lamp

7 Air vents

For reducing the internal temperature

8 PS2 connector Not operational with this system

9 USB 2.0 connector x2 For connecting a USB memory stick, USB mouse, or USB keyboard

10 COM terminal Not operational with this system

11 HDMI terminal

For connecting to monitors using an HDMI cable Max. resolution: 3840 x 1260

12 VGA terminal

For connecting to monitors using an RGB cable Max. resolution: 2560 x 1600

13 Display Port terminal

For connecting to monitors using a Display Port cable Max. resolution: 4096 x 2160

14 1000 BASE-T connector For connecting to the network via a LAN cable

USB 3.0 connector x4

For connecting a USB memory stick, USB mouse, or USB keyboard

16 Audio terminals

Not operational with this systen

17 External control terminals For inputting various external signals to control the device

18 Model No., Serial No.

Numbers for identifying the unit

19 Main power switch

For turning the power ON or OFF

* Place the unit in standby before turning the power OFF

20 Power inlet

Connect the included power cord

LEDs indicate unit status

The POWER STANDBY lamp and DIAG lamp indicate the basic status. The CMD ERR lamp lights when an error or warning occurs.

LED name	Color/ flashing	Meaning when on	How to turn off
	Orange	Power standby	Main power switch OFF
POWER STANDBY	Green	Power ON	Activate switch OFF *
STANDET	Green/ flashing	Power ON (warming up)	Activate switch OFF *
DIAG	See below		-
CMD ERR	Red	Syntax error in command received, or warning occurred	*Goes off with CLS

^{*} If the POWER STANDBY lamp is steady or flashing green, do not turn the main power switch OFF

DIAG LED Mode Table

Display order of priority	Color/ flashing	Status	Supplement
1	Red	Ambient temperature too high (environmental temperature > 35°C/95°F)	
2	Purple	Ambient temperature too low (environmental temperature < 10°C/50°F)	
3	O Yellow	CPU load factor 80% or more	The average load factor is updated every 0.5 seconds.
	Blue	The instrument is in the trigger standby state.	
4	Green	Recording in progress	
	Pink	Recording finished	New command received, switches to normal display.
5	O White	Normal operation in progress (stopped)	

Internal battery

The MR8740T is equipped with a battery (sealed lead acid battery) for shutting down the Windows operating system when the power supply is cut off. This allows the unit to be shut down normally even when there is an unexpected power failure or a breaker trips.

Using the battery to shut down normally if there is a power failure



- Breaker OFF - Power outage

(for 150 ms or longer) - Power cord disconnected



* If the main power switch is switched off while the recorder is in operation, the internal battery will not turn on, preventing the recorder from shutting down normally. Before turning the main power off, be sure to first put the recorder in standby



Environment	Expected service life
Environmental temperature: 25°C/77°F (when the power is turned off once/day)	2 years
Environmental temperature: 25°C/77°F (when the power is turned off 5 times/year)	4 years

External control terminals


Connect an external device to the external control terminal in order to use that external device to start and stop the measurements made by the unit.


	No.	Terminal name	Operation
	1	GND	-
	2	IN1	Start/stop measurements, save,
$\supset \mid$	3	IN2	forced termination, event input
	4	GND	-
	5	OUT1	Judgment output, occurrence of errors,
	6	OUT2	busy, trigger standby
$\supset \mid$	7	GND	-
	8	EXT.TRIG	Inputs signal as an external trigger source
	9	TRIG.OUT	Outputs a signal when triggering occurs
	10	GND	-
	11	EXT.SMPL	Inputs external sampling signals

Analysis software

Wave Viewer Wv (Bundled software) Download free updates from the HIOKI website.

The MR8740T ships standard with Wave Viewer Wv, an application for displaying and converting waveforms. The application allows you to review waveforms stored in binary data captured with the MR8740T on a PC and convert files to CSV format so that they can be loaded by Excel.





Sample Wy Screen

Sample Excel Screen

• Wave Viewer (Wv) Brief Specifications

Operating environment	Windows 10 / 8 / 7 (32 / 64-bit)
Functions	- Simple display of waveform files - Convert binary data files to text format, CSV, etc Scroll function, enlarge/reduce display, jump to cursor/trigger position, etc.

WAVE PROCESSOR 9335 (Software sold separately)

Waveform display, calculation, and printing functionality

• 9335 Brief Specifications

Operating environment Windows 10 / 8 / 7 (32 / 64-bit) Display functions: Waveform display, X-Y display, Cursor function, etc - File loading: Readable data formats (.MEM, .REC, .RMS, .POW) / Maximum loadable file size: Maximum file size that can be saved by a given device (file size may

Product Specifications

Recording method	Ins (Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year) Memory Recorder				
	With ANALOG UNIT 8966 installed: Up to 54 analog channels				
No. of Channels	With LOGIC UNIT 8973 inserted: Up to 48 analog channels + 48 logic channels				
No. of Charmers	With ANALOG UNIT U8975 / U8978 / U8991 installed: Up to 108 analog channel With LOGIC UNIT 8973 inserted: Up to 96 analog channels + 48 logic channels				
	* Logic units are limited to slots 25 to 27 only.				
Maximum sampling rate	20 MS/s (with ANALOG UNIT 8966, all channels at the same time) External sampling 10 MS/s				
Memory capacity	1 G words				
, ,	Increase the recording length per channel by limiting the number of modules in use				
	27 modules: Using all modules; 16 modules: using modules 1 through 16; 8				
	modules: using modules 1 through 8; 4 modules: using modules 1 through 4				
	16 modules 8 modules 4 modules				
Modules					
	16MW/ch 32MW/ch 64MW/ch				
Operating	*Measurement will be disabled for modules other than those shown above.				
environment	Indoors, Pollution Degree 2, altitude up to 2000 m (6562.20 ft)				
Operating temperature and humidity range	0°C to 40°C (32°F to 104°F), less than 80% RH (no condensation)				
Storage temperature					
and humidity range	-10°C to 50°C (14°F to 122°F), 80% RH or less (no condensation)				
Compliance	Safety: EN 61010-1:2010				
standards	EMC EN 61326-1: 2013 Class A				
Dielectric withstand voltage	1620 V AC 1 minute (sensed current: 10 mA) between main unit and power supp				
	Rated supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations for rated				
Power supply	supply voltage)				
Maximum rated	Rated power supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500				
power consumption	400 VA				
Clock	Auto-calendar, leap-year correcting 24-hour clock				
Backup battery life	Approx. 10 years (at 23°C (73°F)) for clock and settings				
Battery service life	Approx. 2 years (discharged once/day, 23°C (73°F)) *Reference: Approx. 4 years when discharged 5 times/year				
	when discharged 5 times/year 426 mm ±2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x 505				
Dimensions	±2 mm (19.88 in ±0.08 in) D (excluding protrusions)				
Mass	14.0 kg ±0.5 kg (493.8 oz ±17.6 oz) (main unit only)				
Product warranty period	20.8 kg ±1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)				
	1 year Power cord, Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-F				
Accessories	application disk (CD-R), blank panel (blank slot only), rack installation hardware				
Accuracy					
Accuracy guarantee conditions	Temperature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less				
Time axis accuracy	±0.001%				
Clock precision	±0.001%				
System (ATX moth	nerboard)				
CPU	Intel Core i5, or a product with similar specifications				
A 4 - 1	DDR48GB				
Main memory					
OS	Windows 10				
OS Startup disk	Windows 10 SSD 120 GB				
OS Startup disk LAN interface					
OS Startup disk LAN interface Compatibility					
OS Startup disk LAN interface	SSD 120 GB				
OS Startup disk LAN interface Compatibility specifications	SSD 120 GB IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions	IEEE 802.3 Eihernet 1000BASE-T, 100BASE-TX, 10BASE-T				
OS Startup disk LAN interface Compatibility specifications Number of ports	SSD 120 GB IEEE 802.3 Eihernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility	SSD 120 GB IEEE 802.3 Eihernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices	SSD 120 GB IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector	SSD 120 GB IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected Monitor output	SSD 120 GB				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected Monitor output	SSD 120 GB				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termin	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 1al Push-button type Maximum input.				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termin	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better nal Push-button type Maximum input +10 V DC voltage				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termin	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 13 Push-button type Maximum input voltage +10 V DC Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termin	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 13 Push-button type Maximum input voltage +10 V DC Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termit Terminal block	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 13 Push-button type Maximum input voltage +10 V DC Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level Response 50 ms or more during high periods, 50 ms or more during low pulse width periods Pulse interval 200 ms or greater				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termit Terminal block	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 1al Push-button type Maximum input voltage How To				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termit Terminal block	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 1al Push-button type Maximum input voltage Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level Response 50 ms or more during high periods, 50 ms or more during low periods Pulse interval 200 ms or greater Number of terminals				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termit Terminal block	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Pesolution: 3840 x 2160 dots (Max.) Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 1al Push-button type Maximum input voltage Input voltage Response pulse width Periods Pulse interval 200 ms or more during high periods, 50 ms or more during low periods Pulse interval 200 ms or greater Number of terminatios START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output)				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termit Terminal block	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 409 6 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 12 Push-button type Maximum input voltage 10 to V to 10 V for high level, 0 V to 0.8 V for low level Response pulse width periods 10 ms or more during high periods, 50 ms or more during low periods 10 ms or greater Number of terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Output type Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 12 Push-button type Maximum input voltage Input voltage Input voltage Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level Pulse interval 200 ms or more during high periods, 50 ms or more during low periods Pulse interval 200 ms or greater Number of terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V DC, 5 mA 200 mW				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connected devices Connector Monitor output Output type External I/O termit Terminal block	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 12 Push-button type Maximum input voltage Input volta				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 12 Push-button type Maximum input voltage Input volta				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Pesolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 1al Push-button type Maximum input voltage Response pulse width Periods Pulse interval 200 ms or more during high periods, 50 ms or more during low periods Pulse interval 200 ms or greater Number of terminals START, STOP, START/STOP, SAVE, ABORT, event Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 50 V DC, 50 mA, 200 mW Number of terminals 2 Euroctions Judgment (PASS), judgment (FAIL), occurrence of errors,				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 13 Push-button type Maximum input voltage Response pulse width periods Pulse interval 20 ms or more during high periods, 50 ms or more during low periods Pulse interval 20 ms or greater Number of termials Functions START, STOP, START/STOP, SAVE, ABORT, event Output voltage Maximum input voltage Voltage Number of terminals 50 V DC, 50 mA, 200 mW Voltage Number of terminals 50 V DC, 50 mA, 200 mW Voltage victor input feature of errors, busy, trigger standby				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Pesolution: 3840 x 2160 dots (Max.) Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 1al Push-button type Maximum input voltage Response pulse width Periods Pulse interval 200 ms or more during high periods, 50 ms or more during low periods Pulse interval 200 ms or greater Number of terminals START, STOP, START/STOP, SAVE, ABORT, event Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 50 V DC, 50 mA, 200 mW Number of terminals 2 Eurocines 50 Judgment (PASS), judgment (FAIL), occurrence of errors,				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 12 Push-button type Maximum input voltage Input voltage Input voltage Input voltage Input voltage Som sor more during high periods, 50 ms or more during low periods Pulse interval Number of terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage Maximum input voltage Maximum input voltage Maximum input voltage Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby Maximum input voltage AN / OFF				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 10 Push-button type Maximum input voltage Input voltag				
OS Startup disk LAN interface Compatibility specifications Number of ports Functions Connector USB interface Compatibility specifications Connected devices Connector Monitor output Output type External I/O termit Terminal block External input	IEEE 802.3 Ethernet 1000BASE-T, 100BASE-TX, 10BASE-T 2 DHCP, DNS, FTP, HTTP RJ-45 USB 3.0 compliant x 4, USB 2.0 compliant x 4 Keyboard, mouse, USB memory stick Series A receptacle VGA Resolution: 2560 x 1600 dots (Max.) HDMI Resolution: 3840 x 2160 dots (Max.) Recommended resolution: 1920 x 1080 dots or better 12 Push-button type Maximum input voltage Input voltage Input voltage Input voltage Input voltage Som sor more during high periods, 50 ms or more during low periods Pulse interval Number of terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage Maximum input voltage Maximum input voltage Maximum input voltage Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby Maximum input voltage AN / OFF				

	Output voltage	Open drain output (active low, with 5 V voltage output)
	Output voltage Maximum input	4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level
Trigger output	voltage	50 V DC, 50 mA, 200 mW
	Output pulse width	Level or pulse selection possible Level: Sampling period x data number after trigger Pulse: 2 ms ±1 ms
	Maximum input	+10 V DC
	voltage	
External sampling	Input voltage Response	2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ns or more during high periods, 50 ns or more during low
	pulse width	periods
	Maximum input	10 MHz
	frequency	External sampling clock input, rising/falling selection possible
Trigger		
Trigger type	Digital comparis	
Trigger conditions		dition for trigger sources and interval trigger
	Analog, logic Max. 108 chann	els
Trigger source		riggers can be set for each logic probe.
		gers can be set for each logic probe. ction is activated if all trigger sources are turned off.
	External trigger	
	Level trigger	Triggering occurs when the set level rises (falls). Triggering occurs when peak voltage drops below the set level.
	Voltage drop trigger	(For a 50 Hz / 60 Hz commercial power supply only).
	angger	* Not available with MR8990, U8991, or 8970
	Window trigger	Triggering occurs when leaving (OUT) or entering (IN) the trigger level upper limit and lower limit setting areas.
		Sets the period reference value and cycle range.
	Period trigger	Triggering occurs when the rising (falling) reference value period is measured and determined to be outside or within th
Analog triggers	. s.isa ingger	cycle range.
3335.0		* Not available with MR8990, U8991, or 8970
	Olitada dei erren	Sets the reference value and pulse width (glitch width). Triggering occurs if the value is below the set pulse width from
	Glitch trigger	rising or falling of the reference value.
		* Not available with MR8990 or U8991 Specifying events (1 to 4000)
	Specifying	Counts the number of times conditions were fulfilled for each
	events	trigger source. Triggering occurs when the set number of times is reached.
		*Not available when the trigger conditions are set to AND
Logic trigger	Pattern trigger u	
Forcible trigger		le triggering can be prioritized over all trigger sources.)
Interval trigger		ible at specified measuring intervals (hours, minutes, or seconds) ditions are fulfilled when the measuring process starts.
		trigger conditions are met at the set measuring intervals.
Trigger filter Level setting	OFF, 10, 20, 50,	100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 samples
resolution	1 LSB (12/16-bit i	unit)
Pre-trigger		value set in 1% steps available),
Trigger timing	START	ecording time for pre-trigger
	Incompatible wit	are displayed/saved, an event mark is
Warning function	If trigger condition	displayed, and an alarm sounds. ons are no longer met: Channel numbers and measured value are displayed/saved, an event mark is displayed, and the alarm stops.
		uiopiaveu, ai iu (I le didi I I Stups.
	ON/OFF (trigger	function, warning function)
Auto trigger level	Several data sar	function, warning function) nples are taken, and the average value is set as the criteria for
Auto trigger level	Several data san the window out t	function, warning function) nples are taken, and the average value is set as the criteria for
Auto trigger level Waveform screer	Several data san the window out t Number of samp	function, warning function) nples are taken, and the average value is set as the criteria for rigger.
	Several data sar the window out t Number of samp	function, warning function) nples are taken, and the average value is set as the criteria for rigger.
	Several data sar the window out t Number of samp	function, warning function) mples are taken, and the average value is set as the criteria for rigger. less: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet.
Waveform screer	Several data sar the window out t Number of samp Waveform display in chronological order	function, warning function) mples are taken, and the average value is set as the criteria for rigger. less: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens
Waveform screer	Several data sar the window out to Number of samp Waveform display in chronological order Max. 16 sheets	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel.
Waveform screen Display format Sheet function	Several data sar the window out the window out the window out the window out the window of the windo	function, warning function) mples are taken, and the average value is set as the criteria for rigger. leles: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet.
Waveform screen Display format	Several data sar the window out the window out the Number of samp ware for the window out the Number of samp ware for the window of the window	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens *Displays up to 64 channels per sheet. *Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform
Waveform screen Display format Sheet function	Several data sar the window out t Number of samp Waveform display in chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are e screen, whereas	function, warning function) mples are taken, and the average value is set as the criteria for rigger. leles: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet.
Waveform screen Display format Sheet function Zoom display	Several data sar the window out the window out the Number of samp Waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are concern, whereas Displays wavefor Waveform waveforms waveform with the window waveform waveform with window waveform waveform with window waveform waveform waveform with window waveform waveform with window waveform waveform waveform with window waveform waveform waveform with window waveform wave	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen.
Waveform screen Display format Sheet function Zoom display	Several data sar the window out the window out the Number of samp waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are of screen, whereas Displays waveform color"	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. Trms over the entire waveform screen. Fixed colors (32 colors)
Waveform screen Display format Sheet function Zoom display	Several data sar the window out t Number of samp the window out t Number of samp display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are coreen, whereas Displays waveform color Interpolation	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. Tims over the entire waveform screen. Fixed colors (32 colors) Linear
Waveform screen Display format Sheet function Zoom display	Several data sar the window out the window out the Number of samp waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are of screen, whereas Displays waveform color"	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. Trms over the entire waveform screen. Fixed colors (32 colors)
Waveform screen Display format Sheet function Zoom display	Several data sar the window out the Number of samp. Waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are concern, whereas Displays waveform color Interpolation Variable	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform
Waveform screen Display format Sheet function Zoom display Full screen display	Several data sar the window out the window out the Number of samp was the window of the Number of samp display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are a screen, whereas Displays wavefor Waveform color Interpolation Variable display	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON
Waveform screen Display format Sheet function Zoom display Full screen display	Several data sar the window out the window out the Number of samp Waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are concern, whereas Displays wavefor Waveform Color Interpolation Variable display Vernier Grid Logic display	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF/ON
Waveform screen Display format Sheet function Zoom display Full screen display	Several data sar the window out the window out thou window out thou window out thou window out the window of the window out of the window out of the window out of the window out	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF / ON Wide, Standard, Narrow
Waveform screen Display format Sheet function Zoom display Full screen display	Several data sar the window out the window out the Number of samp. Waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are of screen, whereas Displays waveform color linterpolation Variable display Vernier Grid Logic display width Waveform	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens
Waveform screen Display format Sheet function Zoom display Full screen display	Several data sar the window out the window out the Number of samp waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are concern, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF / ON Wide, Standard, Narrow
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display	Several data sar the window out the window out the Number of samp was the window out the Number of samp was the window out the window out the Number of samp was the window out the window	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. Tissed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF / ON Wide, Standard, Narrow Displays waveforms upside down. * Not available with 8967, 8970, or 8973
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display Enlarge / Reduce Waveform scrolling	Several data sar the window out the window out the Number of samp was a sample of the Number of samp display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are correct, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can be Scroll left or right Always displays	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display	Several data sar the window out the window out the Number of samp was the window out the Number of samp was the window out the Number of samp was the window order. Waveforms are a screen, whereas Displays waveform color Interpolation Variable display width waveform color Interpolation Variable display width waveform inversion Zoom ratio can be Scroll left or right Always displays The drawing star	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF / ON Wide, Standard, Narrow Displays waveforms upside down. * Not available with 8967, 8970, or 8973 be adjusted as necessary. t by with mouse clicks and scroll back while measuring.
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display Enlarge / Reduce Waveform scrolling Roll display Level monitor	Several data sar the window out the window out the Number of samp was the window out the Number of samp display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are of screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can the Scroll left or right Always displays The drawing star The roll cantot to Numerical	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens *Displays up to 64 channels per sheet. *Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustable input waveform (Adjustment range, 50% to 200% of the input) OFF / ON Wide, Standard, Narrow Displays waveforms upside down. *Not available with 8967, 8970, or 8973 be adjusted as necessary. tby with mouse clicks and scroll back while measuring. the latest data by following the measuring process. rt position (left or right edge) can be selected.
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display Enlarge / Reduce Waveform scrolling Roll display	Several data sar the window out thumber of samp the window out thumber of samp display in chronological order Max. 16 sheets "The display form on the display form on the display form on the display form on the display swaveform color on the display with the display of the di	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens *Displays up to 64 channels per sheet. *Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF / ON Wide, Standard, Narrow Displays waveforms upside down. *Not available with 8967, 8970, or 8973 be adjusted as necessary. tby with mouse clicks and scroll back while measuring. the latest data by following the measuring process. rt position (left or right edge) can be selected. be displayed when the overlay function is turned on.
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display Enlarge / Reduce Waveform scrolling Roll display Level monitor	Several data sar the window out the window out the Number of samp was the window out the Number of samp display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are of screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can the Scroll left or right Always displays The drawing star The roll cantot to Numerical	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. rms over the entire waveform screen. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustable input waveform (Adjustable input waveform (Adjustable with 8967, 8970, or 8973) Displays waveforms upside down. * Not available with 8967, 8970, or 8973 De adjusted as necessary. It by with mouse clicks and scroll back while measuring. the latest data by following the measuring process. It position (left or right edge) can be selected. De displayed when the overlay function is turned on. Up to 8 cursors can be displayed.
Waveform screen Display format Sheet function Zoom display Full screen display Waveform display Enlarge / Reduce Waveform scrolling Roll display Level monitor	Several data sar the window out thumber of samp the window out thumber of samp display in chronological order Max. 16 sheets "The display form on the display form on the display form on the display form on the display waveform sare of screen, whereas Displays waveform color interpolation variable display vernier Grid Logic display width Waveform inversion Zoom ratio can the screen display of the display o	function, warning function) mples are taken, and the average value is set as the criteria for rigger. ples: Select from 100, 200, 300, 400, and 500 1 screen, 2 screens, 4 screens, 8 screens, 16 screens *Displays up to 64 channels per sheet. *Multiple sheets can be set for the same channel. at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. Fixed colors (32 colors) Linear Always ON Adjustable input waveform (Adjustment range: 50% to 200% of the input) OFF / ON Wide, Standard, Narrow Displays waveforms upside down. *Not available with 8967, 8970, or 8973 be adjusted as necessary. tby with mouse clicks and scroll back while measuring. the latest data by following the measuring process. rt position (left or right edge) can be selected. be displayed when the overlay function is turned on.

1.888.610.7664



Setting screen				
3	Real-time		10 M, 5 M, 2 M, 1 M, 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 t, 50 k, 20 k, 10 k, 5	
	sampling	Externa	al sampling: Max. 10 MHz depending on external sampling	
			al input signal um configurable sampling speed	
		[Using i	internal SSD as save destination]	
Sampling speed		64 ch	s (up to 12 channels), 2 MS/s (13 to 32 channels), 1 MS/s (33 to annels), 500 kS/s (65 or more channels)	
	With real-time saving enabled		USB Drive Z4006 as save destination] s (up to 12 channels), 500 kS/s (13 to 24 channels), 200 kS/S	
	*: Values in parentheses indicate	(25 to	64 channels), 100 kS/s (65 or more channels) FTP transmission as save destination]	
	number of channels	200 ks	S/s (up to 12 channels), 100 kS/s (13 to 24 channels), 50 kS/s	
		*USB r	64 channels), 20 kS/s (65 or more channels) nemory stick performance is guaranteed only when	
			cted via USB 3.0 connector. le all channel counts if the U8991 is installed.	
		[Fixed r	recording lengths]	
			ısing 27 modules: 2 M (with U8991), 5 M (with U8975, MR8990), (54 channels) [points]	
			ısing 16 modules: 5 M (with U8991), 10 M (with U8975, 90), 20 M (32 channels) [points]	
		When u	sing 8 modules: 10 M (with U8991), 20 M (with U8975,	
		When u	90), 50 M (16 channels) [points] Ising 4 modules: 20 M (with U8991), 50 M (with U8975,	
	Real-time		90), 100 M (8 channels) [points] pecified recording lengths]	
Maximum recording length	sampling	When u	ising 27 modules: 4194300 (with U8991), 8388600 (with U8975,	
		When u	90), 16777200 (54 channels) [points] Ising 16 modules: 8388600 (with U8991), 16777200 (with U8975,	
			90), 33554400 (32 channels) [points] Ising 8 modules: 16777200 (with U8991), 33554400 (with U8975,	
		MR89	90), 67108800 (16 channels) [points] using 4 modules: 33554400 (with U8991), 67108800 (with U8975,	
		MR89	90), 134217600 (8 channels) [points]	
	With real-time		configurable in units of 100 points. Inned by space available on save destination, file system,	
	saving enabled	and nu	imber of measurement channels	
Repeat measurement			eat measurement, user-specified count cified count settings are not available when real-time saving	
measurement	is enabled.	and off	set, 2-point input, Model, Output rate, dB, Rating	
Scaling	* Model: Select a	model to	configure the scaling settings automatically.	
	Title comments,		I automatic scaling are available when a current unit is used. Il comments	
Comments	Channel number waveform screen		channel comments are added on the setting screen and	
Help	Displays the inst		manual	
Saving	000		1000 (100 00)	
	USB MEMORY		al SSD (480 GB)	
Save destination	STICK Sending to FTP		h a LAN connection	
	Sending to FTF			
File format	Sending by email Send file to specified email address			
	FAT FAT32 NTF	S exFA	AT	
Filename	FAT, FAT32, NTF Alphanumeric ar			
Filename Processing identical	Alphanumeric ar Adding a serial r	nd Japa number	anese input at the beginning before saving (Date and time added after	
Filename	Alphanumeric an Adding a serial r the file when trans ON / OFF	nd Japa number sferred b	anese input at the beginning before saving (Date and time added after y FTP)	
Filename Processing identical filenames	Alphanumeric ar Adding a serial r the file when trans ON / OFF * Automatically sa	nd Japa number sferred b	anese input at the beginning before saving (Date and time added after	
Filename Processing identical	Alphanumeric at Adding a serial r the file when trans ON / OFF * Automatically sa measuring proor * Settings files are	nd Japa number sferred b wes the ess.	anese input at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a sported.	
Filename Processing identical filenames	Alphanumeric at Adding a serial r the file when trans ON / OFF * Automatically sa measuring proof * Settings files are * If a memory divis	nd Japa number sferred b wes the ess. not sup	anese input at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start	
Filename Processing identical filenames Auto saving	Alphanumeric ar Adding a serial r the file when trans ON / OFF * Automatically sa measuring proce * Settings files are * If a memory division while data is beil Deletes the files	nd Japa number sferred b wes the ess. not sup sion is se ng saver with the	at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a ported. at, it is possible for measurement of the next block to start to oldest creation dates and saves data when there is no	
Filename Processing identical filenames	Alphanumeric ar Adding a serial r the file when trans ON / OFF * Automatically sa measuring proc * Settings files are * If a memory divi while data is bei Deletes the files free space left or * Enabled for auto	nd Japa number sferred b wes the ess. not sup sion is se ng saver with the n the sp	at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start do boldest creation dates and saves data when there is no specified media at the save destination.	
Filename Processing identical filenames Auto saving	Alphanumeric ar Adding a serial ri the file when trans ON / OFF * Automatically sa measuring proce * Settings files are * If a memory divis while data is beil Deletes the files free space left or * Enabled for auto Settings data	nd Japa number sferred b wes the ess. not sup sison is se ng saver with the not the sp saving .SET	at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a uported. It, it is possible for measurement of the next block to start d. oldest creation dates and saves data when there is no pecified media at the save destination.	
Filename Processing identical filenames Auto saving	Alphanumeric at Adding a serial rathe file when the file and the file file file and the file file file file file file file fil	nd Japa number sferred b wes the ess. not sup sison is se ng saver with the not the sp saving .SET	at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start do boldest creation dates and saves data when there is no specified media at the save destination.	
Filename Processing identical filenames Auto saving Deleting and saving	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically sa measuring proc ** Settings files are ** If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index	nd Japan number sferred b wes the ess. not sup sion is se ng saver with the n the sp saving .SET Binary	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. rformat (MEM), text format (CSV) d saving (IDX)	
Filename Processing identical filenames Auto saving	Alphanumeric at Adding a serial rithe file when the file series are a file a memory divinile data is bei Deletes the files free space left or E-nabled for auto Settings data Measurement data Index Displayed images	nd Japan number sferred b wes the ess. not sup sion is se ng saver with the n the sp saving .SET Binary	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. c) oldest creation dates and saves data when there is no specified media at the save destination.	
Filename Processing identical filenames Auto saving Deleting and saving	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically sa measuring proc. ** Settings files are "If a memory divition while data is bei Deletes the files free space left out Settings data Measurement data Index Displayed images Numerical	nd Japan number sferred b wes the ess. not sup sion is se ng saver with the n the sp saving .SET Binary	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. rformat (MEM), text format (CSV) d saving (IDX)	
Filename Processing identical filenames Auto saving Deleting and saving	Alphanumeric at Adding a serial rathe file when the file and	nd Japan number sferred b wes the ess. not sup- sion is sing saver with the not the sp saving .SET Binary Divide .BMP, .CSV	an ease input at the beginning before saving (Date and time added after y FTP) data obtained for the recording length at the end of a uported. et, it is possible for measurement of the next block to start d. e oldest creation dates and saves data when there is no ecified media at the save destination. of format (MEM), text format (.CSV) d saving (.IDX)PNG, JPG	
Filename Processing identical filenames Auto saving Deleting and saving	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically sa measuring proc ** Settings files are ** If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe **	nd Japan number sferred b wes the ess. not sup- sion is sen my saver with the not saving .SET Binary Divide .BMP, .CSV	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. of format (MEM), text format (CSV) d saving (IDX) .PNG, .JPG TUP.SET It the channels available or from the displayed channels	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically se measuring proc ** Settings files are ** If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement demander of the setting of the setting selection of the selecti	nd Japanumber sterred by the second state of t	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. of format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels end data. format) is culled according to the specified culling value	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proce *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement de	nd Japanumber sterred by the session is started by the session is star	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. rformat (MEM), text format (CSV) d saving (IDX) .PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving.	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically sa measuring proc ** Settings files are ** If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement different selection of the se	nd Japanumber sterred by the session is started by the session is star	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. of format (MEM), text format (CSV) d saving (IDX) .PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format is culled according to the specified culling value aving. Division method	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving	Alphanumeric at Adding a serial rathe file when the file serial file and the file serial file se	nd Japanumber sterred by the session is started by the session is star	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. rformat (MEM), text format (.CSV) d saving (.IDX) .PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically sa measuring proc ** Settings files are ** If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement different selection of the se	nd Japanumber sterred by the session is started by the session is star	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. It, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no recified media at the save destination. If format (MEM), text format (CSV) d. d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels rent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data,	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving	Alphanumeric at Adding a serial rithe file when the file serial file and the file serial file file serial file serial file file serial file file serial file file file file file file file fil	nd Japanumber sterned by the second state of t	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. et oldest creation dates and saves data when there is no secified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels sent data. format) is culled according to the specified culling value awing. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data. EVERY 60,000 points of data, EVERY 1,000,000 points of data.	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d(from 2 to 1000) b Types of saved Binary format *Text format *Numerical calculation results Startup *Select a channe when saving me Measurement de format *Select a channe when saving me Text format *Selec	nd Japa umber deferred by the session is a session in the session in the session is a session in the session in the session is a session in the session in the session in the session is a session in the sessio	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data Every 1,000,000 points of data OFF, By the calculation number	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division	Alphanumeric at Adding a serial rithe file when trans on NOFF sa wearuing process a measuring process settings files are sift a memory division while data is being being the series of the series o	and Japas Japas Long Terror by the sess. In the space of the sess. In the space of the sess of the sess. Long Savet of the sess of th	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data Every 1,000,000 points of data OFF, By the calculation number	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement (from 2 to 1000) b	nd Japa umber efferred b ves the sass. not support sass. SET Binary Divide START If rom all customer sass. Gata ullation ullation	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. t, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no secified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format is culled according to the specified culling value awing. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 46,000 points of data, Every 1,000,000 points of data OFF, By the calculation number	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proce *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement determined the files of	nd Japa umber efferred b wes the sass. not supsion is six west he sass. not supsion is six on the sass. not supsion is six on the sass. SET Binary Divide BMP, CSV START If from all control of the sass ure manual at (rext effers sass under the sass u	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (.CSV) d saving (.IDX) .PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 16,000 points of data, Every 1,000,000 points of data OFF, By the calculation number s calculation results are saved. a new file or add data to an existing file when starting to es SAVE operation to save data to a save destination, under	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement (from 2 to 1000) b	nd Japas was the sass. not sup sass. SET Binary Divide BMP, CSV START from al assurem assurem tal (text action sassurem co or create Use this afflence a filence	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) disaving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data, Every 1,000,000 points of data OFF, By the calculation number s clackulation results are saved. a new file or add data to an existing file when starting to escave, and with saving settings that have been pre-set.	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proce *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement determined the files of	nd Japa nd Japa nd Japa number efferred b number	an the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (.CSV) d saving (.IDX) .PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 16,000 points of data, Every 1,000,000 points of data OFF, By the calculation number s calculation results are saved. a new file or add data to an existing file when starting to es SAVE operation to save data to a save destination, under	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files SAVE operation	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement different of the files o	nd Japa west he vest he sass. not support sass. SET Binary Divide BMP, CSV START If from all additional sass. Select tables a filena select sass. Select "Enab"	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data OFF, By the calculation number solution results are saved. a new file or add data to an existing file when starting to estave and with saving settings that have been pre-set. the full range or a specific segment. led only when data is saved with the SAVE operation.	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files SAVE operation Loading data	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically se measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement de (from 2 to 1000) b Types of saved Binary format *Text format *Numerical calculation results Startup Select a channe Measurement de (from 2 to 1000) b Types of saved Binary format *Numerical calculation results *Numerical cal	md Japas west he- sess. not support gs saving Self Internation Select *Enab	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data OFF, By the calculation number solution of the specified culling the saved and the saved and the saving settings that have been pre-set. the full range or a specific segment. led only when data is saved with the SAVE operation. all SSD (480 GB)	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files SAVE operation	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement did (from 2 to 1000) b Types of saved Binary format *Text format *Numerical calculation results Startup Select a channe when saving me Select whether the saving me Settings of the saving me Select whether the saving saving format *Select whether the saving sa	md Japas west he- sess. not sup- sess. SET Binary Divide BMP, CSV STARI from al assurem Life and sup- sess. CSV STARI from al assurem Life and sup- sess. Life and	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data OFF, By the calculation number solution results are saved. a new file or add data to an existing file when starting to estave and with saving settings that have been pre-set. the full range or a specific segment. led only when data is saved with the SAVE operation.	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files SAVE operation Loading data Loading source	Alphanumeric at Adding a serial rithe file when trans ON / OFF *Automatically sa measuring proc *Settings files are *If a memory division while data is bei Deletes the files free space left or *Enabled for auto Settings data Measurement data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement de (from 2 to 1000) b Types of saved Binary format Text format Numerical calculation *Select a channe when saving me Measurement de (from 2 to 1000) b Types of saved Binary format Numerical calculation *Select whether the measure. Instant saving Saving range SSD USB MEMORY	nd Japa west he sess. not sup gesses. SET Binary Divide BMP, CSV START If from al ada detata ullation Use th a filena Select "Enab Interna Z4006 SET	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start of the spossible for measurement of the next block to start of the oldest creation dates and saves data when there is no ecified media at the save destination. Format (MEM), text format (CSV) disaving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. Format is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data. OFF, By the calculation number Solic calculation results are saved. a new file or add data to an existing file when starting to estave data to a save destination, under ame, and with saving settings that have been pre-set. the full range or a specific segment. led only when data is saved with the SAVE operation. all SSD (480 GB) 5 (16 GB)	
Filename Processing identical filenames Auto saving Deleting and saving Types of saved data Saving channels Culled data saving File division Specifying files SAVE operation Loading data	Alphanumeric at Adding a serial rithe file when trans ON / OFF ** Automatically sa measuring proce ** Settings flies are ** If a memory division while data is bei Deletes the files free space left on Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement de (from 2 to 1000) b Types of saved Binary format Text format ** Numerical calculation results Startup Select a channe when saving me Select when he saving me Select when he saving me Select whether the measure. Instant saving Saving range SSD MEMORY STICK Settings data	md Japa west he sess. not sup gesses. SET Binary Divide BMP, CSV START If rom an and and and Use th a filena Select "Enab Interna Z4006 SET Binary	at the beginning before saving (Date and time added after by FTP) data obtained for the recording length at the end of a sported. et, it is possible for measurement of the next block to start d. coldest creation dates and saves data when there is no excified media at the save destination. format (MEM), text format (CSV) d saving (IDX) PNG, JPG TUP.SET If the channels available or from the displayed channels ent data. format) is culled according to the specified culling value aving. Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data OFF, By the calculation number solution of the specified culling to the specified culling value aving. a calculation results are saved. a new file or add data to an existing file when starting to the SAVE operation to save data to a save destination, under ame, and with saving settings that have been pre-set. the full range or a specific segment. led only when data is saved with the SAVE operation. all SSD (480 GB)	

	I		
Calculation items	average value, I frequency (*), pe value, time differ minimum value, arithmetic opera XY waveform an * Calculations for	ue, maximum value, minimum value, high level, low level, AMS value, standard deviation, rise time (*), fall time (*), priod (*), pulse duty ratio (*), pulse count, area value, X-Y area rence (*), phase difference (*), time to maximum value, time to specified level time, specified time level, pulse width (*), four titions, median value, amplitude, integration value burst width (*), rgle, overshoot, undershoot, + Width (*), - Width (*) statistical function	
Numerical judgment	Targeted waveforms Judgment settings Stop	Analog channels, logic channels, waveform processing channels ON / OFF PASS, FAIL, PASS&FAIL	
Waveform proces	conditions		
Maximum number			
of calculations	16 formulas		
Calculation range	Full range or Sp	ecified segments	
Maximum recording length Standard operator	2,000,000 point +,-,×,÷	s	
Calculation items	Absolute value, square root, logarithm, exponentiation, SIN, ASIN, COS, ACOS, TAN, ATAN, differentiation, secondary differentiation, integration, secondary integration, moving average, slide, PLCS		
Momory cogmont		ring average, slide, PLCS	
Memory segment Max. divisions	1024 blocks		
Block search		data that is saved in divided memory block.	
Past waveform		measured waveform data into the desired block area and	
comparison		creen to the current waveform.	
Bulk save	Saves a huge ra	ange of data in all blocks	
Display	Specify a block	to display.	
Waveform search			
	Triages	Level, window-in, window-out	
	Trigger	If a logic channel is chosen as the target channel, searches can be made using logic triggers.	
Search methods	Peak	Maximum, minimum, local maximum, local minimum Histogram or standard deviation	
	Concierge	*Choose to compare to corresponding fundamental waves or immediately prior waveforms.	
	Jump	Event mark, cursor, time (specified as absolute time, relative time, or number of points), trigger point, search mark	
	Full range	All data stored in internal memory	
Search range	Specified	Choose a range specified by A/B or C/D.	
	interval		
	Up to 10,000 poil	nts	
Search count		cified number of search targets remain in the search range after	
Continuous search	If a minimum spe	cified number of search targets remain in the search range after rch, you can continue to search waveform data after the last search	
	If a minimum spe performing a sea point.		
Continuous search	If a minimum spe performing a sea point.	rch, you can continue to search waveform data after the last search	
Continuous search Display method	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se	rch, you can continue to search waveform data after the last search h location to display the data. The pling rate and measurement range for the input waveform are st.	
Continuous search Display method Other Auto range	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se * Not available wi	rch, you can continue to search waveform data after the last search h location to display the data. npling rate and measurement range for the input waveform are tt. th external sampling	
Continuous search Display method Other	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se * Not available wi	rch, you can continue to search waveform data after the last search h location to display the data. pling rate and measurement range for the input waveform are st. th external sampling , Alarm and operation	
Continuous search Display method Other Auto range	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically see * Not available wi OFF, Alarm only	rch, you can continue to search waveform data after the last search h location to display the data. pling rate and measurement range for the input waveform are st. th external sampling , Alarm and operation	
Continuous search Display method Other Auto range Beep sound	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se 'Not available wi OFF, Alarm only Sending e-mails Sending	rch, you can continue to search waveform data after the last search h location to display the data. pling rate and measurement range for the input waveform are st. th external sampling , Alarm and operation s via SMTP	
Continuous search Display method Other Auto range Beep sound	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are st. the external sampling the theorem and operation as via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a	
Continuous search Display method Other Auto range Beep sound Sending e-mails	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data Memory check,	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation size SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. initialization, setting initialization, complete initialization LAN check, media check	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are t. th external sampling , Alarm and operation s via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. initialization, setting initialization, complete initialization LAN check, media check	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data Memory check, Japanese, Engli	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are t. th external sampling , Alarm and operation s via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. initialization, setting initialization, complete initialization LAN check, media check	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data Memory check, Japanese, Engli Displays the det	rch, you can continue to search waveform data after the last search in location to display the data. Inpling rate and measurement range for the input waveform are st. the external sampling and operation is via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. initialization, setting initialization, complete initialization LAN check, media check is the sarch waveful and warnings when they occur.	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se * Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data Memory check, Japanese, Engli Displays the det	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are t. th external sampling the additional sampling the Alarm and operation size SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display	If a minimum spe performing a sea point. Specify a search Available Available The optimal san automatically se "Not available will off, Alarm only Sending e-mails Sending e-mails Sending sent data Waveform data Memory check, Japanese, Engli Displays the det Hours, sexages ON/OFF	rch, you can continue to search waveform data after the last search in location to display the data. Inpling rate and measurement range for the input waveform are st. the external sampling and operation is via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. initialization, setting initialization, complete initialization LAN check, media check is the sarch waveful and warnings when they occur.	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available with offer a search offer and a search offer and a search offer and a search offer and a search offer a	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are st. th external sampling Alarm and operation s via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check isth tails of errors and warnings when they occur. Imal time, date, data values	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available with open and automatically se should be sending e-mails Sending e-mails Sending e-mails Sending with sending e-mails Sending e-mails Sending e-mails Sending better the sending bett	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are st. th external sampling Alarm and operation s via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. imal time, date, data values It permitted the permitted the permitted the permitted during the measuring process, the unit is	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission	If a minimum spe performing a sea point. Specify a search available The search and search are search as a	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are st. th external sampling Alarm and operation svia SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted tings are changed during the measuring process, the unit is Settings cannot be changed during the measuring process.	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings	If a minimum spe performing a sea point. Specify a search Available The optimal san automatically se "Not available with open and automatically se should be sending e-mails Sending e-mails Sending e-mails Sending with sending e-mails Sending e-mails Sending e-mails Sending better the sending bett	rch, you can continue to search waveform data after the last search h location to display the data. Inpling rate and measurement range for the input waveform are st. th external sampling Alarm and operation svia SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted tings are changed during the measuring process, the unit is Settings cannot be changed during the measuring process.	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission	If a minimum spe performing a sea point. Specify a search and a sea point. Specify a search and a search an	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are est, the external sampling. Alarm and operation is via SMTP. Automatic saving, saving with the SAVE operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check is the saved waveful and the saved waveful at the saved wavefu	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current	If a minimum spe performing a sea point. Specify a search point. Specify a search point. Specify a search point search point. Specify a search point search p	rch, you can continue to search waveform data after the last search in location to display the data. Inpling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation is via SMTP. Automatic saving, saving with the SAVE operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check is the tails of errors and warnings when they occur. In all time, date, data values. It permitted the the measuring process, the unit is settings cannot be changed during the measuring process.	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current	If a minimum spe performing a sea point. Specify a search point point point. Sending e-mails Sending e-mails Sending e-mails Sending e-mails Sending e-mails Sending bending e-mails Sending bending be	rch, you can continue to search waveform data after the last search h location to display the data. Impling rate and measurement range for the input waveform are et. th external sampling Alarm and operation svia SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted tings are changed during the measuring process, the unit is Settings cannot be changed during the measuring process. It time. Imbinations of Current Unit 8971, 3ch Current Unit 8977 Max. 4 Max. 3	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections	If a minimum spe performing a sea point. Specify a search point point point point. Sending e-mails Sending e-mails Sending timing. Sent data Waveform data Memory check, Japanese, Engli Displays the def Hours, sexages ON/OFF Black or white Permitted: or No "Permitted: Set the date and the point poi	rch, you can continue to search waveform data after the last search h location to display the data. Impling rate and measurement range for the input waveform are st. th external sampling Alarm and operation svia SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted tings are changed during the measuring process, the unit is settings cannot be changed during the measuring process. It time. Imbinations of Current Unit 8971, 3ch Current Unit 8977 Max. 4 Max. 3 Max. 3 Supported locations (slots 25 to 27)	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections	If a minimum spe performing a sea point. Specify a search point. Specify a search point. Specify a search point and automatically search point. Sending e-mails Sending e-mails Sending e-mails Sending timing. Sending e-mails Sending e-mails Sending timing. Sending e-mails Sending e-mails Sending e-mails Sending timing. Sending e-mails Sending	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation. In a sia SMTP. Automatic saving, saving with the SAVE operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check is the saved waveful and waveful and the saved data. In a sia SMTP. It is a specified to the main text or files specified by a type of saved data. In the saved data. In the saved data. In the saved data. In the saved data walues. It is a settings are changed during the measuring process, the unit is settings are changed during the measuring process. It is a settings cannot be changed during the measuring process. It is a settings cannot be changed during the measuring process. It is a settings are changed during the measuring process. It is a settings are changed during the measuring process. It is a settings are changed during the measuring process. It is a settings are changed during the measuring process. It is a settings are changed during the measuring process. It is a settings are changed during the measuring process. It is a setting a set of the setting and the setting a setti	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections	If a minimum spe performing a sea point. Specify a search point point point. Sending e-mails. Set the date and up to 9 with contained. Set the date and up to 9 with contained. Sending e-mails. Set the date and up to 9 with contained. Sending e-mails.	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted tings are changed during the measuring process, the unit is settings are changed during the measuring process. It ime. Imbinations of Current Unit 8971, 3ch Current Unit 8977 Max. 4 Max. 3 Max. 3 Supported locations (slots 25 to 27)	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections Module limitations	If a minimum speperforming a sea point. Specify a search specify and search specify and specifical specific	rch, you can continue to search waveform data after the last search in location to display the data. Inpling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation is via SMTP. Automatic saving, saving with the SAVE operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check is the tails of errors and warnings when they occur. It permitted things are changed during the measuring process, the unit is settings cannot be changed during the measuring process. It time. It ime. It measurement Unit 8971, 3ch Current Unit 8977. Max. 4 Max. 3 Max. 3 Max. 3 Supported locations (slots 25 to 27) POWER ON Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is off)	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections Module limitations POWER LED display	If a minimum spe performing a sea point. Specify a search point point point point. Sending e-mails sending e-mails sending e-mails sending e-mails sending e-mails sending bent point. Sending bent data waveform data. Memory check, Japanese, Engli Displays the det Hours, sexages ON/OFF Black or white Permitted or No "Permitted or No "Permitted." Not permitted: Set the date and Up to 9 with coil service point po	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. the external sampling (Alarm and operation so via SMTP) Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted times are changed during the measuring process, the unit is settings are changed during the measuring process. It ime. Initializations of Current Unit 8971, 3ch Current Unit 8977 Max. 4 Max. 3 Max. 3 Supported locations (slots 25 to 27) POWER ON Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is on) Main power supply is off (the power switch on the rear is off) Syntax error in command received "Goes off with a CLS command.	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections Module limitations	If a minimum spe performing a sea point. Specify a searcl Available The optimal san automatically se "Not available winder of the search of t	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation is via SMTP. Automatic saving, saving with the SAVE operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check ish. Italis of errors and warnings when they occur. Imal time, date, data values. It permitted tings are changed during the measuring process, the unit is settings cannot be changed during the measuring process. It time. It may be changed during the measuring process. It time. Max. 4 Max. 3 Max. 3 Supported locations (slots 25 to 27) POWER ON Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is on) Main power supply is off (the power switch on the rear is off) Syntax error in command received	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections Module limitations POWER LED display	If a minimum spe performing a sea point. Specify a search point point point point point and an automatically se "Not available wi OFF, Alarm only Sending e-mails Sending e-mails Sending e-mails Sending e-mails Sending e-mails Sending bending timing Sent data Waveform data Memory check, Japanese, Engli Displays the det Hours, sexages ON / OFF Black or white Permitted or No "Permitted: Set the date and Up to 9 with core started. "Not permitted: Set the date and Up to 9 with core search point of the date and Current Unit unit Us977 3ch Current Unit Green Green Green Green (flashing) Orange Not on	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation. In a sia SMTP. Automatic saving, saving with the SAVE operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check is the saved saved waveful and the saved waveful at the sav	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections Module limitations POWER LED display	If a minimum spe performing a sea point. Specify a search point point point point. Sending e-mails Sending e-mails Sending timing. Sending e-mails Sending bending permit point. Sending timing Sending e-mails Sending e-mails Sending timing. Sending e-mails Sending e-mails Sending timing. Sending e-mails Sending e-mails Sending timing. Displays the del Hours, sexages. ON / OFF Black or white Permitted or No "Permitted: if set restarted. "Not permitted: if set restarted." "Not permitted: Set the date and Up to 9 with con 8971 Current Unit. U8977 3ch Current Unit. 8973 Logic Unit. Green Green (flashing) Orange Not on	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. the external sampling. Alarm and operation. Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization. LAN check, media check ish tails of errors and warnings when they occur. Implication of Current Unit 8971, 3ch Current Unit 8977. Max. 4. Max. 3. Max. 3. Supported locations (slots 25 to 27). POWER ON. Aging in progress (for 30 minutes after the power is turned on). STANDBY (the power switch on the rear is on). Main power supply is off (the power switch on the rear is off). Syntax error in command. Or when a warning occurs. Ambient temperature is too low (< 10°C / 50°F). Ambient temperature is too low (< 10°C / 50°F).	
Continuous search Display method Other Auto range Beep sound Sending e-mails Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission Time settings Number of current sensor connections Module limitations POWER LED display	If a minimum spe performing a sea point. Specify a search point point point point point a san automatically se "Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data Memory check, Japanese, Engli Displays the det Hours, sexages ON/OFF Black or white Permitted or No "Permitted or No "Permitted if set restarted. "Not permitted: Set the date and Up to 9 with con 8971 Current Unit UB977 3ch Current Unit B973 Logic Unit Green (flashing) Orange Not on Red Not on Red	rch, you can continue to search waveform data after the last search in location to display the data. Impling rate and measurement range for the input waveform are st. th external sampling Alarm and operation sia SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check ish tails of errors and warnings when they occur. Imal time, date, data values It permitted tings are changed during the measuring process, the unit is Settings cannot be changed during the measuring process. It time. Imbinations of Current Unit 8971, 3ch Current Unit 8977 Max. 4 Max. 3 Max. 3 Supported locations (slots 25 to 27) POWER ON Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is on) Main power supply is off (the power switch on the rear is off) Syntax error in command received "Goes off with a CLS command. Or when a warning occurs No error or warning Ambient temperature is too high (> 35°C / 95°F)	

1.888.610.7664



Option Specifications (sold separately)

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz)



ANALOG UNIT 89	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Securacy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for voltage measurement	
Input terminals	Isolated BNC connector (input impedance 1 M Ω , input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 k/500 kHz	
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)	
Maximum sampling rate	20 MS/s (simultaneous sampling in 2 channels)	
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)	
Frequency characteristics	DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)	
Input coupling	AC/DC/GND	
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106~mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



4ch ANALOG UNI	T U8975 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH atter 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4, for voltage measurement
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$, input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	4, 10, 20, 40, 100, 200 V f.s., 6 ranges AC voltage for possible measurement/display: 140 V rms Low-pass filter: 5/500/5 k/200 kHz
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneous sampling in 4 channels)
Measurement accuracy	±0.1% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB
Input coupling	DC/GND
Maximum input voltage	200 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106~mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



4CH ANALOG UN	IT U8978	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4, for	r voltage measurement
Input terminals	Max. rated voltage to	tor (input impedance 1 M Ω , input capacitance 30 pF), ground: 30 V AC or 60 V DC for direct input, 300 V AC, DC (CAT ith the 9665 (Between each input channel and the main unit, and between
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40 V f.s Low-pass filter: 5/500	s., 9 ranges
Measurement resolution	1/32,000 of measuren	nent range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneous s	ampling in 4 channels)
Measurement accuracy	±0.3% f.s. (with filter 5	Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB	
Input coupling	DC/GND	-
Maximum input voltage	40 V DC (with direct in	nput), 400 V DC (with 9665)

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 260 g (9.2 oz) Accessories: None



DIGITAL VOLTMI MR8990	ETER UNIT (Accuracy at 23 ±5°C/73 ±9°F, 80% RH after 30 minutes of warm- up time and calibration, Accuracy guaranteed for 1 year, Post- adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for DC voltage measurement
	Banana input connectors (Input impedance: 100 M Ω or higher with 100 mV f.s. to 10 V f.s. range, otherwise 10 M Ω)
Input terminals	Max, rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)
Integration time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)
Response time	2 ms +2 x integration time or less (rise - f.s. \rightarrow + f.s., fall + f.s. \rightarrow - f.s.)
Basic measurement accuracy	±0.01% rdg, ±0.0025% f.s. (at range of 1000 mV f.s.)
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in) W × 19.8 mm (0.78 in) H × 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



DIGITAL VOLTME	TER UNIT U8991 30 minutes of warm-up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4, for DC voltage measurement
Input terminals	Isolated BNC connectors (Input impedance: $100~M\Omega$ or higher with $1~V~f.s.$ to $10~V~f.s.$ range, otherwise $10~M\Omega$) Max. rated voltage to ground: $100~V~AC$, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	1 10 100 V fs 3 ranges

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



DC/RMS UNIT 897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable		
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$, input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/100 kHz		
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)		
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)		
RMS measurement	RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz) ±3% f.s. (1 kHz to 100 kHz) Response time: SLOW 5 s (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale), FAST 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2		
Frequency characteristics	DC to 400 kHz -3 dB (with AC coupling: 7 Hz to 400 kHz -3 dB)		
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)		

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



HIGH RESOLUTI 8968	ON UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement		
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$, input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 kHz		
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)		
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)		
Frequency characteristics	DC to 100 kHz -3 dB (with AC coupling: 7 Hz to 100 kHz -3 dB)		
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)		

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



3CH CURRENT UN U8977	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 3, Current measurement with optional current sensor		
Input terminals	Dedicated connector terminal (ME15W) (input impedance 1 MΩ, common GND with recorder)		
Compatible current sensors	9272-05, CT6841-05, CT6843-05, CT6844-05, CT6845-05, CT6862-05, CT6863-05, 9709-05, CT6904, CT6865-05, CT6875, CT6876 (Direct connection) CT7631, CT7636, CT7642, CT7731, CT7736, CT7742, CT7044, CT7045, CT7046 (Connection using optional CONVERSION CABLE CT9920)		
Measurement range	-Directly connected current sensor: Automatically identify rating of compatible current sensors Using 9272-05 (20 A), CT6841-05: 2 A to 100 A f.s., 6 ranges Using CT6862-05: 4 A to 200 A f.s., 6 ranges Using CT6862-05: 4 A to 200 A f.s., 6 ranges Using 9272-05 (200 A), CT6843-05; CT6863-05: 20 A to 1000 A f.s., 6 ranges Using CT6844-05, CT6845-05, CT6865-05, CT6876: 80 A to 4000 A f.s., 6 ranges Using CT6846-05, CT6865-05, CT6876: 80 A to 4000 A f.s., 6 ranges Current sensors connected using CT9920: Select conversion rate or model Using CT7631, CT7731: 200 A, 1 ranges Using CT7636, CT7736: 200 A to 1000 A, 3 ranges Using CT7642, CT7742: 2000 A/4000 A, 2 ranges Using CT7642, CT7742: 2000 A/4000 A, 2 ranges Using CT7044, CT7045; CT7046: 2000 A to 10,000 A, 3 ranges		
Measurement accuracy (with 5 Hz filter ON) Note: Add the accuracy and attributes of the current sensor being used.	±0.3% f.s. Frequency characteristics: DC to 2 MHz ±3 dB		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	5 MS/s (simultaneous sampling in 3 channels)		
Other functions	Input coupling: DC/GND, Low-pass filter: 5/500/5 k/200 kHz		

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: CONVERSION CABLE 9318 \times 2 (To connect the current sensor to the 8971)



CURRENT UNIT	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Postadjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, Current measurement with optional current sensor		
Input terminals	Sensor connector (input impedance 1 MΩ, exclusive connector for current sensor via the CONVERSION CABLE 9318, common GND with recorder)		
Compatible current sensors	CT6862, CT6863, 9709, CT6865, CT6841, CT6843, CT6844, CT6845, CT6846, 9272-10 (To connect to the 8971 via the CONVERSION CABLE 9318)		
Measurement range	Using 9272-10 (20 A), CT6841: 2 A to 100 A f.s., 6 ranges Using CT6862: 4 A to 200 A f.s., 6 ranges Using 9272-10 (200 A), CT6843, CT6863: 20 A to 1000 A f.s., 6 ranges Using CT6844, CT6845, 9709, CT6846*1, CT6865*1: 40 A to 2000 A f.s., 6 ranges **I: The conversion ratio needs to be set to 2 for scaling.		
Measurement accuracy (with 5 Hz filter ON)	±0.65% f.s. RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 10 kHz) DMS representations 100 ms (rich time from 0 to 0.05% of full conta)		

1.888.610.7664



www.calcert.com


accuracy	
Maximum input voltage	100 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



HIGH-VOLTAGE U	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable Max. rated voltage to ground: 1000 V AC, DC for measurement category III, 600 V AC, DC for measurement category IV		
Input terminals	Banana input terminal (Input impedance: 4 MΩ, Input capacitance: 5 pF)		
Measurement range	4, 10, 20, 40, 100, 200, 400, 1000 V fs. (DC mode), 8 ranges 10, 20, 40, 100, 200, 400, 1000 V fs. (RMS mode), 7 ranges Low-pass filter: 5/50/5005 K/50 kHz		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	1 MS/s		
Measurement accuracy	±0.25% f.s. (with filter 5 Hz, zero position accuracy included)		
RMS measurement	RMS accuracy: ±1.5% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 100 kHz) Response time: High speed 150 ms, medium speed 500 ms, low speed 2.5 s		
Frequency characteristics	DC to 100 kHz -3 dB		
Input coupling	DC/GND		
Maximum input voltage	1000 V DC, 700 V AC		

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 245 g (8.6 oz) Accessories: CONVERSION CABLE L9769 \times 2 (Cable length: 60 cm)



Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 204.5 mm (8.05 in) D, approx. 240 g (8.5 oz) Accessories: Ferrite clamp \times 2



TEMP UNIT 8967	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm- up time and zero adjustment; Accuracy guaranteed for 1 year, Post- adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for temperature measurement with thermocouple (voltage measurement not available)		
Input terminals	Thermocouple input: Push-button terminal block, Recommended wire diameter: single-wire 0.14 to 1.5 mm², braided wire 0.14 to 1.0 mm² (conductor wire diameter ϕ 0.18 mm or more), AWG 26 to 16 Input impedance: min. 5 m Ω (with line fault detection ON/OFF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Temperature measurement range Note: Upper and lower limit values depend on the thermocouple	200°C (392°F) f.s. (-100°C to 200°C (-148°F to 392°F)), 1000°C (1832°F) f.s. (-200°C to 1000°C (-328°F to 1832°F)), 2000°C (3632°F) f.s. (-200°C to 2000°C (-328°F to 3632°F)), 3 ranges Measurement resolution: 1/20,000 of measurement range (using 16-bit A/D conversion)		
Thermocouple range (JIS C 1602-1995) (ASTM E-988-96)	K: -200°C to 1350°C (-328°F to 2462°F), R: 0°C to 1700°C (32°F to 3092°F), F: -200°C to 1100°C (-328°F to 2012°F), S: 0°C to 1700°C (32°F to 3092°F), E: -200°C to 800°C (-328°F to 1472°F), B: 400°C to 1800°C (752°F to 3272°F), N: -200°C to 1300°C (-328°F to 2372°F), W (WRe5-26): 0°C to 2000°C (32°F to 3632°F)		
	Reference junction compensation: internal/external (switchable), line fault detection ON/OFF possible		
Data refresh rate	3 methods, Fast: 1.2 ms (digital filter OFF), Normal: 100 ms (digital filter 50/60 Hz), Slow: 500 ms (digital filter 10 Hz)		
Measurement accuracy	Thermocouple K, J, E, T, N: ±0.1% f.s. ±1°C (±1.8°F), (±0.1% f.s. ±2°C (±3.6°F) at -200°C to 0°C (328°F to 32°F)) Thermocouple R, S, B, W: ±0.1% f.s. ±3.5°C (±6.3°F) (at 0°C (32°F) to less than 400°C (752°F), However, no accuracy guarantee at less than 400°C (752°F) for B), ±0.1% f.s. ±3°C (±5.4°F) (at 400°C (752°F) or more) Reference junction compensation (BJC] accuracy: ±1.5°C (±2.7°F) (added to measurement accuracy with internal reference junction compensation)		

Dimensions/mass: approx. 106 mm (4.17 in) W × 19.8 mm (0.78 in) H × 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



FREQ UNIT 8970	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80 % RH after 30 minutes of warm- up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage input based frequency measurement, rotation, power frequency, integration, pulse duty ratio, pulse width		
Input terminals	Isolated BNC connector (input impedance 1 MQ, input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Frequency mode	Measurement range: Between DC to 100 kHz (minimum pulse width 2 μs), 20 Hz to 100 kHz f.s, 8 ranges Accuracy: ±0.1% f.s. (exclude 100 kHz range), ±0.7% f.s. (100 kHz range)		
Rotation mode	Measurement range: Between 0 to 2 million rotations/minute (minimum pulse width 2µs), 2 kr/min to 2 Mr/min f.s, 7 ranges Accuracy: ±0.1% f.s. (exclude 2 Mr/min range), ±0.7% f.s. (2 Mr/min range)		
Power frequency mode	Measurement range: 50 Hz (40 to 60 Hz), 60 Hz (50 to 70 Hz), 400 Hz (390 to 410 Hz), 3 ranges Accuracy: ±0.03 Hz (50, 60 Hz), ±0.1 Hz (400 Hz range)		
Integration mode	Measurement range: 40 k-counts f.s. to 20 M-counts f.s. 6 ranges Accuracy: ±0.0025% f.s.		
Duty ratio mode	Measurement range: Between 10 Hz to 100 kHz (minimum pulse width 2 μs), 100% f.s. Accuracy: ±1% (10 Hz to 10 kHz), ±4% (10 kHz to 100 kHz)		
Pulse width mode	Measurement range: Between 2 μs to 2 s, 10 ms to 2 s f.s. Accuracy: ±0.1% f.s.		

Dimensions/mass: approx. 106~mm (4.17 in) W imes 19.8 mm (0.78 in) H imes 196.5 mm (7.74 in) D, approx. 190 g (6.7 oz) Accessories: None



LOGIC UNIT 8973	
Measurement functions	No. of channels: 16 channels (4 ch/1 probe connector × 4 connectors)
	Mini DIN connector (for HIOKI logic probes only) Compatible logic probes: 9320-01, 9327, MR9321-01

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



CHARGE UNIT U897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for acceleration measurement		
Input terminals	Voltage input / pre-amp embedded input: Metal BNC connector (Under voltage input: input impedance 1 M Ω , input capacitance 200 pF or less) Charge input: Miniature connector (#10-32UNF) Max. rated voltage to ground: 30 V AC or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage) *Voltage input terminal GND and charge input terminal GND for the same channel are shared.		
Suitable transducer	Charge output type acceleration detector Pre-amp embedded acceleration detector		
Measurement range Charge input (Miniature connector) Pre-amp embedded input (BNC connector)	I (m/s²) to 200 k (m/s²) f.s., 12 ranges x 6 types Charge input sensitivity: 0.1 to 10 pC (m/s²) Pre-amp embedded sensor input sensitivity: 0.1 to 10 mV //(m/s²) Amplitude accuracy: ±2% f.s. Frequency characteristics: (1.5) to 50 kHz -3 dB (charge input) Low-pass filter: 5005 kHz Pre-amp supply power: 3.5 mA ±20%, 22 V ±5% Maximum input charge: ±500 pC (6 ranges on high sensitivity side), 50.000 pC (6 ranges on low sensitivity side)		
Measurement range Voltage input (BNC connector)	10 mV to 40 V f.s., 12 ranges, DC amplitude accuracy: ±0.5% f.s. Frequency characteristics: DC to 50 kHz -3 dB (with DC coupling), 1 Hz to 50 kHz -3 dB (with AC coupling) Low-pass filter: 5/500/5 kHz, input coupling: AC/DC/GND Maximum input voltage: 40 V DC		
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	200 kS/s		
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)		
TEDS	IEEE 1451.1.4 class 1 support (Support for sensor information reading and automatic sensitivity setting)		

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



WAVEFORM GEN MR8790	ERATOR UNIT	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Output terminal	No. of channels: 4, SMB terminal (Output impedance: 1 Ω or less) Max. rated voltage to ground: 33 V rms AC or 70 V DC	
Output voltage range	-10 V to 10 V (Amplitude setting range: 0 V to 20 V p-p, Setting resolution: 1 mV)	
Max. output current	5 mA	
Output function	DC, Sine wave (Output freque	ency range: 0 Hz to 20 kHz)
Accuracy	Amplitude accuracy: ±0.25% of setting ±2 mV p-p (1 Hz to 10 kHz) Offset accuracy: ±3 mV DC output accuracy: ±0.6 mV	
Other	Self-test function (Voltage, C	urrent)

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



PULSE GENER	ATOR UNIT MR8791 (Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less with no condensation; accuracy guaranteed for 1 year)
Output terminal	No. of channels: 8, Connector: SCSI-2, half pitch, 50-pin Max. rated voltage to ground: 33 V rms AC or 70 V DC (between unit and output channels) Logic output/Open collector output
Output mode 1	Pattern output: Read frequency: 0 Hz to 120 kHz, 2048 logic patterns
	Pulse output: Frequency 0 Hz to 20 kHz, Duty 0.1% to 99.9%
Output mode 2	Logic output: Output voltage level: 0 V to 5 V (H level: 3.8 V or more, L level: 0.8 V or less)
	Open collector output: Absolute maximum rated voltage for collector/emitter 50 V Overcurrent protection: 100 mA
Other	Self-test function

Dimensions/mass: approx. 106 mm (4.17 in) W \times 19.8 mm (0.78 in) H \times 196.5 mm (7.74 in) D, approx. 280 g (9.9 oz) Accessories: None




VIR GENERAT	FOR UNIT U8794	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less with no condensation; accuracy guaranteed for 1 year)	
Output terminal	No. of channels: 8 (each c Max. rated voltage to gro	hannel is isolated), Connector: 25-pin D-sub ound: 25 V	
Output items	DC voltage, DC current,	DC voltage, DC current, resistance (simulated output)	
	DC voltage: -0.100 0 V to	DC voltage: -0.100 0 V to +5.300 0 V (setting resolution: 0.1 mV)	
Output range	1 mA range: -1.000 00 m 250 μA range: -250. 00 μ 50 μA range: -50. 000 μΑ	A to +5.000 0 mA, Setting resolution: 0.1 μA A to +1.000 00 mA, Setting resolution: 0.01 μA A to +250.00 μA, Setting resolution: 0.01 μA to +50.000 μA, Setting resolution: 0.001 μA 2, Setting resolution: 0.001 μA	
	DC voltage: 5 V range, ±	0.035% of setting $\pm 800 \mu\text{V}$	

1.888.610.7664



Other functions	Slope, Level, Hold, Smoothing, Low-pass filter, Switchable DC/AC input coupling,		$50 \mu A$ range: $\pm 0.050\%$ of setting $\pm 40 n A$
	Frequency dividing, Integration over-range keep/return	Other	Self diagnostic, switch output terminals, estimate target connection, cancel offset

System Chart of Options



not quaranteed for storage media made by other manufacturers. You may be



USB DRIVE Z4006

Using highly durable and reliable SLC flash memory

PC Software (free)



Waveform Viewer Wv

Software for checking waveforms with binary data on a PC, saving data in CSV format, and transferring to spreadsheet programs

Operating environment Windows 10/8/7 (32/64-bit) Functions:

- Simple display of waveform files
 Convert binary data files to text format, CSV, etc.
- Scroll function, enlarge/reduce display, jump to cursor/trigger position, etc.



WAVE PROCESSOR 9335

PC display for massive amounts of waveform data and more

Logic signal measurement



LOGIC PROBE 9327
4-channel type, for voltage/contact signal ON/
OFF detection (response pulse width 100 ns
or more, miniature terminal type)



LOGIC PROBE MR9321-01 4 isolated channels, ON/OFF detection of AC/ DC voltage (miniature terminal type)



LOGIC PROBE 9320-01 4-channel type, for voltage/contact signal ON/ OFF detection (response pulse width 500 ns or more, miniature terminal type)



CONNECTION CABLE L9795-01

Max. rated voltage to ground: 33 V AC rms or 70 V DC SMB terminal - alligator clip Cable length: 1.5 m (4.92 ft)



CONNECTION CABLE L9795-02

Max. rated voltage to ground: 33 V AC rms or 70 V DC SMB terminal - BNC terminal Cable length: 1.5 m (4.92 ft)

Input modules

Input cords not included. Please purchase them separately. When using the 9709 with CURRENT UNIT 8971, up to a total of



ANALOG UNIT 8966

2 ch, voltage input, 20 MS/s, (DC to 5 MHz)



4ch ANALOG UNIT U8975

4 ch, voltage input, 5 MS/s, (DC to 2 MHz) $\,$



4CH ANALOG UNIT U8978

4 ch, voltage input, 5 MS/s, (DC to 2 MHz), highest sensitivity range 100 mV f.s.



HIGH RESOLUTION UNIT 8968 2 ch, voltage input, 1 MS/s (DC to 100 kHz)



DC/RMS UNIT 8972

2 ch. voltage/1 MS/s. (DC to 400 kHz) RMS rectifier (DC, 30 to 100 kHz)



HIGH-VOLTAGE UNIT U8974

2 ch, voltage input, max. 1000 V DC and 700 V AC



DIGITAL VOLTMETER UNIT MR8990

2 ch, high-precision DC voltage, 0.1 μV resolution, maximum sampling rate 500 times/s



DIGITAL VOLTMETER UNIT U8991

4 ch, high-precision DC voltage, 1 µV resolution, maximum sampling rate 50 times/s



CURRENT UNIT 8971

2 ch, for measuring current using dedicated current sensors, 2 CONVERSION CABLES 9318 included, for use with up to 4 units



3CH CURRENT UNIT U8977

3 ch, for measuring current using dedicated current sensors, can be directly connected to ME15W (12-pin) connector-type sensors, for use with up to 3 units



TEMP UNIT 8967

2 ch, thermocouple temperature input



STRAIN UNIT U8969 2 ch, strain gauge type converter amp

CONVERSION CABLE L9769



(for STRAIN UNIT U8969 only, included)

FREQ UNIT 8970

2 ch. for measurement of frequency, RPM, pulse, etc.



2 ch, for acceleration measurement, supports charge output, pre-amp output, and voltage output



LOGIC UNIT 8973

4 terminals, 16 ch, up to 3 units (slots 25 to 27 only)

Output modules

* Output cords not included. Please purchase them separately * Configure settings with communication commands.



WAVEFORM GENERATOR UNIT MR8790 4ch, DC output ±10 V, Sine wave output 1 Hz to 20 kHz



PULSE GENERATOR UNIT MR8791 8ch, Pulse output 0.1 Hz to 20 kHz, Pattern output



VIR GENERATOR UNIT U8794

8ch, DC voltage output, DC current output, resistance output (simulated resistance)

SCI Monitor 4.0

HSCI-4.0-CAN FD



HSCI-4.0-SENT HSCI-4.0-LIN

CAN monitors, LIN monitors, and SENT monitors that are the same size as the MR8740T unit can be purchased from Nihon System Eight Co., Ltd. Power is supplied to a monitor when it is installed on the MR8740T. Note that it will not be



Por details, see product information on Hioki's website.

* Voltage is limited to the specifications of the **INPUT CORD (A)** CONNECTION CORD L9790 ALLIGATOR CLIP L9790-01 Red/black set attaches to the ends of the cables L9790 GRABBER CLIP 9790-02 * When this clip is attached to the end of the L9790, input is limited to CAT II 300 V. Red/black set. CONTACT PIN 9790-03 Red/black set attaches to the ends of the cables L9790 Voltage is limited to the specifications of th input modules in use. INPUT CORD (B) CONNECTION CORD L9198 φ 5.0 mm (0.20 in) dia., cable allowing for up to 300 V input, 1.7 m (5.58 ft) length, small alligator clip CONNECTION CORD L9197 ϕ 5.0 mm (0.20 in) dia., cable allowing for up to 600 V input, 1.8 m (5.91 ft) length, detachable large alligator clips are bundled GRABBER CLIP 9243 Attaches to the tip of the L9197, red/black set, full length: 196 mm (7.72 in) Voltage is limited to the specifications of th INPUT CORD (C) 10:1 PROBE 9665 Max. rated voltage to ground is same as for input module, max. input voltage 1 kV rms (up to 500 kHz), 1.5 m (4.92 ft) length 100:1 PROBE 9666 Max. rated voltage to ground is same as for input module, max. input voltage 5 kV peak (up to 1 MHz), 1.5 m (4.92 ft) length Voltage to ground is within this product's specifications. *Separate power source is also INPUT CORD (D) DIFFERENTIAL PROBE P9000-01

(Wave Only) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

DIFFERENTIAL PROBE P9000-02

(Switch between Wave/RMS) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

DIFFERENTIAL PROBE 9322 AC, 2 kV DC, Frequency bands

AC ADAPTER 9418-15

CONNECTION CABLE L4940

EXTENSION CABLE L4931

ALLIGATOR CLIP L4935

BUS BAR CLIP L4936

GRABBER CLIP 9243

CAT III 600 V

Banana plug - banana plug, Cord length 1.5 m (4.92 ft)

Extend the length of banana plug cables, Cable length: 1.5 m (4.92 ft)

Attach to the tip of banana plug cables, CAT IV 600 V, CAT III 1000 V

Attach to the tip of banana plug cables,

Attach to the tip of banana plug cables, CAT III 1000 V


Attach to the tip of banana plug cables, red/black set, full length: 196 mm (7.72 in), CAT III 1000 V

MAGNETIC ADAPTER L4937

AC ADAPTER Z1008

100 to 240 V AC

10 mA class to 500 A (High speed) Custom cable For P9000. Inquire with your local Hioki distributor.



U8977 only

railable CONVERSION CABLE CT9901 is required in precision current sensor equipped with a ME15W -05 type) with the CURRENT UNIT 8971. Sk is not required in order to use a sensor equipped with terminal with the 8971, the CONVERSION CABLE 9318 with the 8971) is required for that setup. ME15W (12-pin) - PL23 (10-pin) conversion

Other current sensor types The MEMORY HICORDER can be used with

various types of current sensors and probes

General-purpose current measurement *PL14 terminal type AC/DC AUTO 7FRO CURRENT SENSOR CT 7731 DC, 1 Hz to 5 kHz, 100 A AC/DC AUTO ZERO CURRENT SENSOR CT7736

DC, 1 Hz to 5 kHz, 600 A AC/DC AUTO ZERO CURRENT SENSOR CT7742 DC, 1 Hz to 5 kHz, 2000 A

AC/DC CURRENT SENSOR CT7631

AC/DC CURRENT SENSOR CT7636 DC. 1 Hz to 10 kHz. 600 A

AC/DC CURRENT SENSOR CT7642 DC, 1 Hz to 10 kHz, 2000 A

AC FLEXIBLE CURRENT SENSOR CT7044 100 mm (3.94 in), 6000 A

AC FLEXIBLE CURRENT SENSOR CT7045 180 mm (7.09 in), 6000 A AC FLEXIBLE CURRENT SENSOR CT7046

254 mm (10.00 in), 6000 A eparately available CONVERSION CABLE CT9920 is red in order to connect a PL14 terminal general-purpose nt sensor to the CURRENT UNIT U8977.

PL14 - ME15W (12-pin) conversion

CONVERSION CABLE CT9920 Convert PL14 terminal to ME15W (12-pin)

Leak Current *For commercial power lines, 50/60 Hz CLAMP ON LEAK HITESTER 3283

10 mA range / 10 μA resolution to 200 A range, with monitor / analog output 1 V f.s. **OUTPUT CORD L9095**

Connect to BNC terminal, 1.5 m (4.92 ft) length

AC ADAPTER 9445-02 100 to 240 V AC, 9 V/ 1 A

Precautions for connecting current sensors and current probes

*Depending on the combination of current sensors and current probes, physical and space limitations may prevent simultaneous connection. Hioki can assist with special order conversion cables please inquire with your local distributor.

*A total of 9 current sensors and current probes can be connected simultaneously to the Memory HiCorder. (Total with the CURRENT UNIT U8977, CURRENT UNIT 8971, and PROBE POWER UNIT Z5021 connected)

*Three U8977 current units and four 8971 current units can be simultaneously connected to the Memory

*Only the U8977 can use the CT9920 to convert a PL14 connector sensor. The 8971 does not support this combination.

*The 9318 is bundled with the CURRENT UNIT 8971.

CLAMP ON PROBE 3273-50

CLAMP ON PROBE 3276

CLAMP ON PROBE 3274

CLAMP ON PROBE 3275

Frequency characteristics: DC to 50 MHz

Frequency characteristics: DC to 100 MHz

Frequency characteristics: DC to 10 MHz wideband response, up to 150 A rms

Frequency characteristics: DC to 2 MHz

wideband response, up to 500 A rms

wideband response, 10 mA-class up to 30 A rms

wideband response, 10 mA-class up to 30 A rms

Non-contact voltage measuring

NON-CONTACT AC VOLTAGE PROBE SP3000-01 5 V rms rated, 10 Hz to 100 kHz band width

NON-CONTACT AC VOLTAGE PROBE SP3000 Sold individually

AC VOLTAGE PROBE SP9001

(1) Bus powered USB cable

(2) USB(A)- Micro B cable

(3) 3-prong cable

Sold individually

Other options for input

CONNECTION CORD L9217 Cord has insulated BNC connectors at both ends, signal output use, 1.6 m (5.25 ft) length

CONVERSION ADAPTER 9199 Receiving side banana terminal, output BNC terminal

Temperature sensor



THERMOCOUPLE *For reference only. Please purchase locally.

INPUT CORD (E)

INPUT CORD (F)

INPUT CORD (G) * For the MR8990 *Voltage is limited to the specifications of the input modules in use.

1.888.610.7664



www.calcert.com

INPUT CORD (H)

sales@calcert.com

voltage: CAT IV 600 V, CAT III 1000 V

The MR8740T supports your testing technologies with simultaneously sampled measurements across multiple channels.







Set examples

Multi-channel measurement for ECU development

In addition to the measurement of 68 analog channels + 24 logic channels, the MR8740T can also generate waveforms on 4 channels, generate pulses on 8 channels, and output DC voltage/DC current/ simulated resistance on 40 channels. This allows the simultaneous testing of multiple points, such as for high-performance boards, with a single unit.

MEMORY HICORDER	MR8740-50	1 unit
4ch ANALOG UNIT	U8975	17
CONNECTION CORD	L9790	68
ALLIGATOR CLIP	L9790-01	68
WAVEFORM GENERATOR UNIT	MR8790	1
CONNECTION CABLE	L9795-01	4
PULSE GENERATOR UNIT	MR8791	1
VIR GENERATOR UNIT	U8794	5
LOGIC UNIT	8973	3
LOGIC PROBE	9327	3

Support for a wide range of multi-channel measurements

High speed, isolation, and high precision are achieved even with multi-channel measurement.

High-speed isolated recording across 108 channels at 5 MS/s

MEMORY HICORDER	MR8740-50	1 unit
4ch ANALOG UNIT	U8975	27
CONNECTION CORD	L9790	108
ALLIGATOR CLIP	L9790-01	108

High-precision voltage measurements across 108 channels at a sampling rate of 50 times/s

MEMORY HICORDER	MR8740-50	1 unit
DIGITAL VOLTMETER UNIT	U8991	27
CONNECTION CORD	L9790	108
ALLIGATOR CLIP	L9790-01	108

Multi-channel strain measurements across 54 channels with a strain gauge converter

MEMORY HICORDER	MR8740-50	1 unit
STRAIN UNIT	U8969	27
CONVERSION CABLE	L9769	54