

# **UAT-600** Series **Underground Utilities Locator**

### Accurately and safely pinpoint underground utilities before you dig

Accidentally hitting a utility line during a project can lead to costly repairs and create hazardous public safety situations. Digging in the wrong place can also lead to unnecessary delays and costs for your project, and ultimately, your company. Avoid this disruption with the rugged and durable Amprobe UAT-600 Series, designed to accurately pinpoint underground utilities and buried services up to 20 feet deep.

Designed for electricians with a CAT IV 600 V rating, the locating kits come complete and ready for use with a Transmitter,

Receiver, test lead kit, batteries and additional fuses, all in a mobile, protective duffle bag. The UAT-620 kit also includes a Signal Clamp for transmitting a signal when it is not possible to make electrical contact with the cable to be traced. For applications where ground fault locating is required, use the UAT-600 Transmitter in combination with the optional A-Frame accessory.

# Features and Highlights

- · Multiple tracing modes allow you to locate and trace energized and de-energized utilities in a variety of applications
- The intuitive Transmitter automatically chooses the correct locating function based on the connected accessory and includes selectable 8/33 kHz frequencies
- The Receiver's high-contrast display allows for clear viewing in full sunlight and features an automatic backlight for shaded and dark areas
- Rated CAT IV 600 V, ensuring safety when working with energized cables
- Semi-automatic gain control quickly detects tracing signal and allows precise adjustment of the receiver sensitivity
- Accurate depth measurement to 20 ft
- Rugged, durable construction: water and dust resistant to IP54 and drop proof to 3.28 ft (1 m)
- Use the Signal Clamp to induce a signal without making electrical contact (UAT-620)
- Ground fault locating with the optional A-Frame accessory
- Comes as a complete kit, ready for use



many years to come.

# **AMPROBE**'



#### AF-600 A-Frame

#### (Optional accessory not included in UAT-600 Series Kits)

The AF-600 A-Frame cable ground fault finder is specifically designed for the Amprobe UAT-600 series. In combination with the Transmitter, it will pinpoint the place where a cable metal conductor (either a sheath or a metallic conductor of the wire) touches the ground. It can also detect other conductors to ground faults such as pipeline coating defects.

	AF-600 A-Frame		
Tracing mode (de-energized)	8 kHz		
Locating mode	Ground fault locating		
Sensitivity (typical)	Cable locate mode at 1 meter depth: 10 uA Fault locate mode: up to 2 M $\Omega$ fault		
Display backlight	Automatic		
Audio indication	Speaker indicates left/right by pulsed/ continuous tone		
Compatible transmitter	UAT-600-T Transmitter		
Display	1.28 in, 128 x 128 BW outdoor LCD display with auto backlight		
Update rate	Instantaneous		
Operating temperature and humidity	-4 °F to 122 °F (-20 °C to 50 °C), ≤90% RH		
Storage temperature and humidity	-40 °F to 140 °F (-40 °C to 60 °C), ≤90% RH		
Operating altitude	< 6561 ft (< 2000 m)		
Pollution degree	2		
Water and dust resistance	IP54		
Drop proof	3.28 ft (1 m)		
Power supply	(6) 1.5 V AA alkaline batteries		
Auto power off	15 minutes idle		
Battery life	Approx. 60 hours at 70 °F (21 °C) (Typical)		
Certifications	. <b>©</b> .; <b>C</b> € <b>△</b> .		
Safety compliance	IEC 61010-1, CSA/UL 61010-1		
Size (H x W x L)	Approx. 14 x 9 x 4.7 in (355 x 230 x 120 mm)		
Weight	Approx. 4.2 lb (1.9 kg) (batteries installed)		

#### \*AF-600 A-Frame includes:

- A-Frame Receiver
- (6) 1.5 V AA (IEC LR6) Batteries
- Carrying Case
- User Manual



#### (included in the UAT-620 Kit only)

The Signal Clamp accessory provides an efficient and safe method of applying a locate signal to a cable, enabling the Transmitter to induce a signal through the insulation into the wires or pipes. The clamp works on low impedance closed circuits only.



### Test Leads Kit

(included in both UAT-600 Series Kits)

	UAT-600 Series	
Measurement category	CAT IV 600 V	
Operating voltage and current	Test leads: 600 V, 10 A max. Clips : 600 V, 10 A max.	
Leads length	11.5 ft (3.5 m)	
Compatible transmitter	UAT-600-T Transmitter	
Operating temperature and humidity	-4 °F to 122 °F (-20 °C to 50 °C), ≤90% RH	
Storage temperature and humidity	-40 °F to 140 °F (-40 °C to 60 °C), ≤90% RH	
Operating altitude	< 6561 ft (< 2000 m)	
Pollution degree	2	
Water and dust resistance	IP54	
Drop proof	3.28 ft (1 m)	
Certifications	. <b>©</b> C € . & . [6]	
Safety compliance	IEC 61010-031 CSA/UL 61010-031	
Size (H x W x L)	Approx. 9 x 3.5 x 3.1 in (230 x 90 x 80 mm)	
Weight	Approx. 1.1 lb (0.5 kg)	

#### \*TL-UAT-600 Test Leads Kit includes:

- Black test lead with detachable black alligator clip
- Red test lead with permanently attached red alligator clip
- · Ground stake

# AMPROBE



Trace an individual utility by connecting the transmitter directly with the test leads



The Transmitter will automatically change modes based on which accessory is plugged in



The Receiver's high contrast LED screen is easy to read in full sunlight

#### Main applications

- Locate energized 50/60 Hz cables carrying current
- Identify the location of all metallic utilities: pipes\*, energized and de-energized cables
- Trace individual pipes\* or cables (energized or de-energized) \*Tracing of non-metallic pipes and conduits is possible after inserting metal fish tape or cable

### Three testing modes for wide range of applications

- Passive power mode (50/60 Hz) tracing energized lines conducting current (no Transmitter necessary)
- Passive radio mode (RF) using surrounding radio waves to trace underground utilities (no Transmitter necessary)
- Active mode using UAT-600-T Transmitter

#### Three active modes using the **UAT-600-T Transmitter**

- Induction the Transmitter will automatically start to radiate a signal around it using an internal antenna, used for tracing individual cables where there is no access to the line to connect test leads or a clamp
- **Direct connection with test leads** - the most reliable method to trace individual cable or a pipe
- Clamp (Included in the UAT-620 kit, optional for the UAT-610 kit) - provides an efficient and safe method of applying a locate signal to a cable, where it is not possible/safe to gain access to a cable for making an electrical contact

#### Special applications

- 2 frequency options: 8 kHz and 33 kHz
- Locate non-metallic pipes and sewer lines
- Take depth and current measurements
- Measure voltage, resistance and output current
- Advanced locating with two people
- Locate ground faults with the AF-600 A-Frame accessory

### Customers who use Amprobe **Underground Locators**

- **Commercial and Residential Construction** Contractors
- Water, Gas and Electric Installation & **Repairs Crews**
- Pipe Laying Contractors
- Cable TV & Telecommunication Companies
- Electricians & General Contractors

#### **Features**

	UAT-600-R Receiver	UAT-600-T Transmitter	SC-600 Signal Clamp
Measurement category	CAT IV 600 V	CAT IV 600 V	CAT IV 600 V
Operating voltage/current	0 to 6	600 V	0 to 600 V, 100 A max.
Operating frequency/tracing modes	Active tracing: 33 kHz and 8 kHz Passive tracing: 50/60 Hz and Radio	Energized circuit Induction mode: 33 kHz Direct connection modes: 8 kHz and 33 kHz Clamp mode: 8 kHz and 33 kHz De-Energized circuit Induction mode: 33 kHz Direct connection modes: 8 kHz, 33 kHz, A-Lo/A-Hi A-Frame: 8 kHz Clamp mode: 8 kHz and 33 kHz	33 kHz and 8 kHz
Locating modes	-	Peak and Null	-
Depth measurement and accuracy	Up to 20 ft 4 in to 10 ft: ± 3 % 10 ft to 20 ft: ± 5 %	-	-
Display backlight	Automatic	Yes	-
Audio indication	Increasing closer to the signal	Fast beeps showing the better signal is applied	-



# **Specifications**

	UAT-600-R Receiver	UAT-600-T Transmitter	SC-600 Signal Clamp
Transmitting mode power output	-	Max. 3 watts	-
Output voltage	_	Max. 50 V rms	-
Output current	-	Max. 250 mA rms, constant current in 5 steps	-
Signal voltage output (nominal)	-	-	23 V rms at 8 kHz 30 V rms at 33 kHz
Mains voltage measurement	-	0 V to 600 V, 50 Hz to 60 Hz Resolution: 1 V Accuracy: ± 10%	-
Resistance measurement (De-energized circuit)	-	0 $\Omega$ to 999 k $\Omega$ Range: 0 $\Omega$ to 999 $\Omega$ (resolution: 5 $\Omega$ ) Range: 1 k $\Omega$ to 999 k $\Omega$ (resolution: 1 k $\Omega$ ) Accuracy: ± 10%	-
Output hazardous voltage warning	_	≥ 30 V rms	_
Mains hazardous voltage warning	_	≥ 30 V rms	_
Sensitivity adjustment (gain control)	Yes	-	_
Sensitivity at 1 m (typical)	Power: 2 mA Radio: 20 μA 8 kHz: 5 μA 33 kHz: 5 μA	-	-
Display	4.3 in, 320 x 240 BW outdoor LCD display with auto backlight	LCD display (LED backlight) 2.4 in x 1.3 in	-
Update rate	Instantaneous	Current (mA): 10 ms Voltage (V): 15 ms Resistance (Ω): 330 ms	-
Operating temperature and humidity		-4 °F to 122 °F (-20 °C to 50 °C), ≤90% RH	
Storage temperature and humidity		-40 °F to 140 °F (-40 °C to 60 °C), ≤90% RH	
Operating altitude	< 6561 ft (< 2000 m)		
Pollution degree	2		
Water and dust resistance		IP54	
Drop proof		3.28 ft (1 m)	
Power supply	(6) 1.5 V AA alkaline batteries	(8) 1.5 V D cell alkaline batteries	-
Auto power off	15 minutes idle	-	-
Battery life	Approx. 35 hours at 70 °F (21 °C) (Typical)	Approx. 16 hours at 70 °F (21 °C) (Typical)	_
Overload protection	-	600 V rms Fuse FF 500 mA, 1000 V, IR 30 kA, 6.3×32 mm	-
Certifications	. <b>©</b> :. ( € △ 🎉	. <b>©</b> :. ( € .	. <b>©</b> :. ( € .
Safety compliance	IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033	IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033 IEC 61010-031, CSA/UL 61010-031 (test leads)	IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033
Size (H x W x L)	Approx. 11.9 x 4.7 x 30.7 in (302 x 120 x 779 mm)	Approx. 14 x 9 x 4.7 in (355 x 230 x 120 mm)	Approx. 11.6 x 7.1 x 1.4 in (295 x 180 x 37 mm)
Weight	Approx. 4.2 lb (1.9 kg) (batteries installed)	Approx. 7.0 lb (3.2 kg) (batteries installed)	Approx. 1.9 lb (0.85 kg)

### Included in UAT-600 Series Kits

	UAT-610	UAT-620
UAT-600-R Receiver	1	1
UAT-600-T Transmitter	1	1
CC-UAT-600 Carrying Case	1	1
TL-UAT-600 Test Leads Kit*	1	1
FP-UAT-600 Replacement Fuse	2	2
User Manual	1	1
Quick Reference Guide	1	1
1.5 V AA (IEC LR6) Batteries (Receiver)	6	6
D-Cell Batteries (Transmitter)	8	8
SC-600 Signal Clamp	-	1

#### \*TL-UAT-600 Test Leads Kit includes:

- Black test lead with detachable black alligator clip
- Red test lead with permanently attached red alligator clip
- Ground stake

## **Optional Accessories**

	Description
AF-600*	A-Frame fault locator to pinpoint ground faults where current is leaking to ground
BR-600-R	Rechargeable battery for Receiver
BR-600-T	Rechargeable battery for Transmitter
EPS-600	2-port charger for Receiver and Transmitter batteries
TL-7000-25M	Extension test lead, 80' (25 m)

#### \*AF-600 A-Frame includes:

- A-Frame Receiver
- (6) 1.5 V AA (IEC LR6) Batteries
- Carrying Case
- User Manual