



USER MANUAL

BLUETOOTH KEYBOARD



**SONEL S.A.
Wokulskiego 11
58-100 Świdnica**

Version 1.2 10.02.2020

Introduction

Bluetooth Keyboard is a universal tool, but its use as a device intended for the cooperation with MPI-530 / 530-IT meters, manufactured by Sonel S.A., has been described in this manual.

This manual is a supplement to the information contained in the MPI-530 / 530-IT Meter User Manual, which should be read carefully.

Package content

- Bluetooth Keyboard.
- USB power cord.
- User manual

Description

- Transmission standard: Bluetooth V3.0.
- 49 buttons.
- Built-in rechargeable Li-ion battery, charged via Micro USB port.
- Two LEDs to indicate status.
- Built-in intelligent power management for longer working hours between battery charges.
- Operating range: 10 metres
- Charging time: 3-4 hours.
- Operating temperature range: -10°C ... +55°C

Establishing a connection with the meter

Note: Before first use, please charge the keyboard (internal battery).




Fig. 1. Location of the pairing/connecting button.

1. Turn on the keyboard by sliding the **ON/OFF** switch to the **ON** position - after a while, the LED lights up for 3 seconds.
2. Press and hold for a moment the "pairing/connecting" button – The LED will flash (double flash, pause, etc.). The keyboard will wait for the connection with the meter up to three minutes. Then the LED stops flashing.
3. Now the keyboard is in the pairing/connecting mode and it waits for the connection with the meter - the details of how to proceed can be found in the MPI-530 / 530-IT Meter User Manual.

Note:

If the battery is discharged, the green LED will be lit.

Charging rechargeable battery

In order to charge the keyboard (internal battery), connect the keyboard to the USB port using the cord supplied with the keyboard.

Charging is indicated by illumination of the red LED. When the device is fully charged, the LED goes out.

Access to the extended keyboard characters

Note:

Not all characters and symbols on the keyboard are supported by the MPI-530 / 530-IT meter. Symbols used in MPI-530 / 530-IT are shown in Fig. 2.




Fig. 2. The view of the keys used while cooperating with the MPI-530 / 530-IT meter.

1. Access to the characters and features described on the keyboard in red is obtained by pressing and holding the **Fn** key before pressing the target key.
2. For capital letters, press and hold the **Shift** key before pressing the letter button.